

Managing the Hardware Management Console



ESCALA

Managing the Hardware Management Console

Hardware

May 2009

BULL CEDOC
357 AVENUE PATTON
B.P.20845
49008 ANGERS CEDEX 01
FRANCE

REFERENCE
86 A1 42EV 05

The following copyright notice protects this book under Copyright laws which prohibit such actions as, but not limited to, copying, distributing, modifying, and making derivative works.

Copyright © Bull SAS 2009

Printed in France

Trademarks and Acknowledgements

We acknowledge the rights of the proprietors of the trademarks mentioned in this manual.

All brand names and software and hardware product names are subject to trademark and/or patent protection.

Quoting of brand and product names is for information purposes only and does not represent trademark misuse.

The information in this document is subject to change without notice. Bull will not be liable for errors contained herein, or for incidental or consequential damages in connection with the use of this material.

Contents

Managing the Hardware Management Console	1
Introduction to the Hardware Management Console	1
User interface style for the HMC	1
Predefined user IDs and passwords.	1
Tasks and roles	2
Starting the HMC.	3
Using the Web-based user interface.	3
Task bar	4
Navigation pane	4
Welcome.	4
Systems Management	5
Servers	5
Frames	9
Custom Groups	10
System Plans	11
HMC Management	12
Service Management	12
Updates	12
Work pane.	13
Working with Tables	13
Selecting Rows	13
Filtering	13
Sorting	13
Column configuration	13
Views menu	14
Status bar	14
Status: Unacceptable	14
Status: Attention LEDs.	14
Status: Serviceable Events	14
Status Overview	14
Systems Management for Servers	15
Properties	15
Update Password	15
Operations	16
Power On	16
Power Off	16
Power Management	17
LED Status	17
Schedule Operations	18
Advanced System Management	19
Utilization Data	20
Rebuild.	20
Change Password	20
Configuration	20
Create Logical Partition	20
System Plans	21
Shared processor pool management	21
Virtual Network Management	21
Partition Availability Priority	21
View Workload Management Groups.	22
Manage Custom Groups	22
Manage Partition Data.	22
Manage System Profiles	23
Viewing HMC connection status	24
View service processor connection status	24
Resetting or removing connections	25

Disconnecting another HMC	25
Adding a managed system	25
Correcting a connection problem	25
Correcting a No connection state for a managed system	25
Correcting an Incomplete state for a managed system	26
Correcting a Recovery state for a managed system	27
Correcting an Error state for a managed system	27
Correcting a Failed Authentication state for a managed system	27
Correcting a new connection problem between the HMC and a managed system	28
Hardware Information	28
Adapters	28
Host Ethernet Adapter (HEA)	29
Host Channel Adapter (HCA)	29
Virtual IO Adapters	29
View Hardware Topology	30
Updates	30
Serviceability	30
Manage Serviceable Events	30
Create Serviceable Event	31
Reference Code History	31
Control Panel Functions	32
Hardware	32
Add FRU	32
Add Enclosure	32
Exchange FRU	32
Exchange Enclosure	32
Remove FRU	33
Remove Enclosure	33
Power On/Off IO Unit	33
Manage Dumps	33
Collect VPD	34
Edit MTMS	34
FSP Failover	34
Capacity on Demand	34
Systems Management for Partitions	35
Properties	35
Change Default Profile	35
Operations	35
Activate	35
Restart	36
Shut Down	36
Manage Attention LED	37
Schedule Operations	37
Delete	38
Configuration	38
Manage Profiles	38
Manage Custom Groups	39
Save Current Configuration	39
Hardware Information	39
Adapters	39
Host Ethernet Adapter (HEA)	39
Host Channel Adapter (HCA)	39
Switch Network Interface	40
Dynamic Logical Partitioning	40
Processor	40
Memory	40
Physical Adapters	40
Virtual Adapter	41
Host Ethernet	41
Console window	42
Serviceability	42

Manage Serviceable Events	42
Reference Code History	43
Control Panel Functions	43
Systems Management for Frames	43
Properties	43
Update Password	44
Operations	44
Initialize	44
Rebuild	44
Change Password	44
Power On/Off IO Unit	45
Configuration	45
Manage Custom Groups	45
Connections	45
Bulk Power Assembly (BPA) Status	45
Reset	46
Hardware Information	46
View RIO Topology	46
Serviceability	47
Manage Serviceable Events	47
Hardware	47
Add FRU	47
Add Enclosure	48
Exchange FRU	48
Exchange Enclosure	48
Remove FRU	48
Remove Enclosure	49
System Plans	49
View System Plan	49
Create System Plan	49
Deploy System Plan	50
Export System Plan	50
Import System Plan	50
Remove System Plan	51
HMC Management tasks	51
Back up HMC Data	51
Change Date and Time	52
Change Language and Locale	52
Change Network Settings	52
Change User Interface Settings	53
Change User Password	54
Create Welcome Text	54
Format Media	54
KDC Configuration	55
View KDC Server	56
Modify KDC Server	56
Add KDC server	57
Remove KDC server	57
Import Service Key	57
Remove Service Key	57
Configuring the HMC so that it uses LDAP authentication	58
Launch Guided Setup Wizard	58
Launch Remote Hardware Management Console	58
Lock HMC Screen	59
Logoff or Disconnect	59
Manage Certificates	59
Manage Data Replication	60
Managing Install Resources	60
Manage Task and Resource Roles	62
Manage User Profiles and Access	62
Manage Users and Tasks	63

Open 5250 Console	64
Open Restricted Shell Terminal	64
Remote Command Execution	64
Remote Operation	64
Remote Virtual Terminal	64
Restore HMC Data	65
Save Upgrade Data	65
Schedule Operations	65
Shut Down or Restart	66
Test Network Connectivity	66
Tip of the Day	67
View HMC Events	67
View Licenses	67
View Network Topology	67
Service Management tasks	68
Create Serviceable Event	68
Manage Serviceable Events	69
Load Serviceable Events	69
Manage Remote Connections	69
Manage Remote Support Requests	69
Format Media	70
Manage Dumps	70
Transmit Service Information	70
Manage Systems Call-Home	71
Manage Outbound Connectivity	71
Manage Inbound Connectivity	72
Manage Customer Information	72
Authorize User	73
Manage Serviceable Event Notification	73
Manage Connection Monitoring	74
Manage POWER4 Service Agent	74
Call-Home Setup Wizard	74
Updates	74
Update HMC	75
Managed System Updates	75
Change Licensed Internal Code for the current release	76
Upgrade Licensed Internal Code to a new release	77
Flash Side Selection	77
Check system readiness	77
View system information	78
HMC tasks and user roles and IDs	78
Remote operations	93
Using a remote HMC	94
Using a Web browser	94
Using the HMC remote command line	95
Setting up secure script execution between SSH clients and the HMC	95
Enabling and disabling HMC remote commands	96
Web browser requirements	97
Preparing to use the Web browser	97
Logging in to the HMC from a LAN-connected Web browser	97
Customizable data replication	98
Peer-to-Peer replication	98
Master-to-Slave replication	99
Data replication	100
Appendix. Notices	101
Trademarks	102
Terms and conditions	103

Managing the Hardware Management Console

This topic helps users to understand how to use the Hardware Management Console (HMC), describes the tasks you can use on the console, and describes how to navigate using the Web-based user interface.

Introduction to the Hardware Management Console

This section briefly describes some of the concepts and functions of the Hardware Management Console (HMC) and introduces the user interface that is used for accessing those functions.

The HMC is a system that controls managed systems, logical partitions, Capacity on Demand (CoD), and updates. To provide flexibility and availability, you can implement HMCs as a local HMC or a redundant HMC.

Local HMC

A local HMC is an HMC that is physically located close to the system it manages and is connected by either a private or public network. An HMC in a private network is a DHCP server for the service processors of the systems it manages. An HMC may also manage a system over an open network, where the managed system's service processor IP address has been assigned manually using the Advanced System Management Interface (ASMI).

Remote HMC

A remote HMC is an HMC that is not physically located near its managed systems. This could be in another part of the same room or data center, in another building, or even on another site. Typically, a remote HMC would be attached to its managed servers via a public network, but configurations with a remote HMC attached to a private network are also possible. Prior to HMC version 7, at least one local HMC was required. With Version 7, any or all HMCs may be remote.

Redundant HMC

A redundant HMC manages a system that is already managed by another HMC. When two HMCs manage one system, they are peers, and each can be used to control the managed system. One HMC can manage multiple managed systems, and each managed system can have two HMCs. If both HMCs are connected to the server using private networks, each HMC must be a DHCP server set up to provide IP addresses on two unique, nonroutable IP ranges.

The HMC allows you to configure and manage servers. One HMC can manage multiple servers, and dual HMCs can provide redundant support by managing the same system. To help ensure consistent function, each HMC is shipped preinstalled with the Hardware Management Console Licensed Machine Code Version 7.

User interface style for the HMC

This HMC uses a Web-based user interface. This interface uses a tree style navigation model providing hierarchical views of system resources and tasks to enable direct access to hardware resources and task management capabilities. It provides views of system resources and provides tasks for system administration.

See "Using the Web-based user interface" on page 3 for detailed information on how to use this HMC interface.

Predefined user IDs and passwords

Predefined user IDs and passwords are included with the HMC. It is imperative to your system's security that you change the hscroot predefined password immediately.

The following predefined user IDs and passwords are included with the HMC:

Table 1. Predefined HMC user IDs and passwords

User ID	Password	Purpose
hscroot	abc123	The hscroot user ID and password are used to log in to the HMC for the first time. They are case-sensitive and can only be used by a member of the super administrator role.
root	passw0rd	The root user ID and password are used by the service provider to perform maintenance procedures. They cannot be used to log in to the HMC.

Tasks and roles

Each HMC user can be a member of a different role. Each of these roles allows the user to access different parts of the HMC and perform different tasks on the managed system. HMC roles are either predefined or customized.

The roles discussed in this section refer to HMC users; operating systems running on logical partitions have their own set of users and roles. When you create an HMC user, you must assign that user a task role. Each task role allows the user varying levels of access to tasks available on the HMC interface. For more information about the tasks each HMC user role can perform, see “HMC tasks and user roles and IDs” on page 78.

You can assign managed systems and logical partitions to individual HMC users. This allows you to create a user that has access to managed system A but not to managed system B. Each grouping of managed resource access is called a managed resource role. To learn more about managed resource roles and how to create them, see “Manage Task and Resource Roles” on page 62.

The **predefined** HMC roles, which are the default on the HMC, are as follows:

Table 2. Predefined HMC Roles

Role	Description	HMC User ID
Operator	The operator is responsible for daily system operation.	hmcoperator
Super Administrator	The super administrator acts as the root user, or manager, of the HMC system. The super administrator has unrestricted authority to access and modify most of the HMC system.	hmcsuperadmin
Product Engineer	A product engineer assists in support situations, but cannot access HMC user management functions. To provide support access for your system, you must create and administer user IDs with the product engineer role.	hmcpe
Service Representative	A service representative is an employee who is at your location to install, configure, or repair the system.	hmcservicerep

Table 2. Predefined HMC Roles (continued)

Role	Description	HMC User ID
Viewer	A viewer can view HMC information, but cannot change any configuration information.	hmcviewer

You can create **customized** HMC roles by modifying predefined HMC roles. Creating customized HMC roles is useful for restricting or granting specific task privileges to a certain user. For more information about creating customized HMC roles, see “Manage Task and Resource Roles” on page 62.

Starting the HMC

Turn on the HMC by setting both the display and system unit to the *On* position. The initialization window, which includes the copyright information, is displayed. Learn about how to log in to the HMC interface.

When initialization is complete, the pre-login window is displayed.

Note: The pre-login window contains the link to log in to the HMC application, the ability to view the online help information, and the summarized status information for the HMC. You will need to log in to view the status information.

To log in to the HMC do the following:

1. In the pre-login window, click **Log on and launch the Hardware Management Console web application**.
2. Enter the user ID and password combination assigned to you.
3. Click **Logon**.

Note: If you previously disconnected from your session, the Choose a Disconnected Session window opens. Select the session you want to reconnect to and click **Reconnect**.

After you log in, the HMC workplace window opens and, if enabled, the **Tip of the Day** window appears. For more information about how to enable this feature, see “Tip of the Day” on page 67.

The HMC workplace window allows you to work with tasks for your console and managed systems. Not all tasks are available for each user ID. The user role assigned to your user ID determines what tasks you are able to perform. For example, if you are assigned a user ID with the operator role, you will have access to all the tasks that have *operator* access. See “HMC tasks and user roles and IDs” on page 78 for a listing of all tasks and the user roles for which the tasks are available.

If at any time you do not know or remember what user ID you are currently logged in to the HMC, look at the task bar on the top of the Welcome page or you can click **HMC Management** in the navigation pane. Then click **Manage Users and Tasks** from the work pane (see “Manage Users and Tasks” on page 63 for more information).

Using the Web-based user interface

You can use the Web-based user interface to perform tasks on the Hardware Management Console (HMC) or on your managed resources.

This user interface comprises several major components: the banner, the task bar, the navigation pane, the work pane, and the status bar.

The *banner*, across the top of the workplace window, identifies the product and logo. It is optionally displayed. Use the **Change User Interface Settings** task to change the setting.

The *task bar*, located below the banner, displays the names of any tasks that are running, the user ID you are logged in as, online help information, and the ability to logoff or disconnect from the console.

The *navigation pane*, in the left portion of the window, contains the primary navigation links for managing your system resources and the HMC. The items are referred to as nodes.

The *work pane*, in the right portion of the window, displays information based on the current selection from the navigation pane. For example, when **Welcome** is selected in the navigation pane, the Welcome window content is displayed in the work pane.

The *status bar*, in the bottom left portion of the window, provides visual indicators of current overall system status. It also contains a status overview icon which may be selected to display more detailed status information in the work pane.

You can resize the panes of the HMC workplace by moving the mouse pointer over the border that separates the navigation pane from the work pane until the mouse pointer changes to a double-pointed arrow. When the pointer changes shape, press and hold the left mouse button while dragging the mouse pointer to the left or right. Release the button and your navigation pane or work pane is now larger or smaller in size. You can also do this within the work pane border that separates the resources table from the tasks pad.

Task bar

The task bar provides the capability of an active task switcher.

The task bar can be used as a navigation aid to move between tasks that were launched and have not yet been closed. The task switcher does not pause or resume existing tasks. Clicking on a task in the task bar brings that task's window forward and gives it focus.

Note: Applet-based tasks such as AIX[®] terminal windows, 5250 console windows, or restricted shell windows do not support the task bar switching capabilities. Please use the window switching capabilities for local windows to switch to the windows for these tasks.

The right end of the task bar also contains the following information:

- Your *user ID*. If you click the user ID, the Change User Interface Settings window opens.
- **Help** displays information about all the tasks on the HMC and how to use the Web-based user interface on the HMC.
- If you click **Logoff**, the Logoff or Disconnect window opens.

Navigation pane

The navigation pane contains the primary navigation links for managing your system resources and the HMC. These include:

- "Welcome"
- "Systems Management" on page 5
- "System Plans" on page 11
- "HMC Management" on page 12
- "Service Management" on page 12
- "Updates" on page 12

Welcome

Welcome is the initial window that is displayed when you log on to the HMC.

The Welcome work pane lists the nodes of the navigation pane and their descriptions. It also includes the following Additional Resources:

Guided Setup Wizard

Provides a step-by-step process to configure your HMC.

HMC Operations Guide

Provides an online version of the *Managing the HMC* for system administrators and system operators using the HMC.

If you are accessing the HMC remotely, you can view the publication in PDF format or in HTML format (click **View as HTML**). If you are accessing the HMC locally, you can view the publication in HTML format.

HMC Readme

Provides hints and errata information about the HMC.

Online Information

Provides information about the HMC.

Note: The following information is only available when you are accessing the HMC remotely.

IBM® System Support

supplies support and technical information for IBM Systems

HMC Support

supplies support and technical information for the HMC

Education and Tutorials

supplies course materials for training and updating HMC skills

To see what level of the HMC you are currently using, point your mouse over **HMC Version** at the top of the work pane.

Systems Management

Systems Management contains a tree view of managed resources.

Servers:

Servers represents the servers that are managed by this HMC.

To add servers, you can use the **Add Managed System** task under the **Connections** category in the tasks pad.

When you click **Servers** from the navigation pane a listing of individually defined servers is displayed in table form in the work pane, and under the **Servers** node in the navigation pane.

Selecting a server:

Learn about the information displayed when you select a server.

To work with a server, you can perform one of the following actions:

- Select a server under the **Servers** node from the navigation pane.
- Click on a server name from the work pane table.
- Click in the **Select** column next to the server name in the work pane table.

The Servers work pane table displays the following attributes by default.

Name Specifies the user-defined name of the managed system.

Status Displays the current status of the managed system (for example, Operating, Power off,

Initializing) and, in addition, displays icons representing an unacceptable state or an active Attention LED. See “Status: Unacceptable” on page 14 or “Status: Attention LEDs” on page 14 for more information.

Available Processing Units

Displays the number of processing units that are available for assignment to logical partitions on the managed system. This is the total number of processing units that are activated on the managed system minus the number of processing units that are assigned to the logical partitions, including the logical partitions that are shut down, on the managed system. This number does not include any processing units that have not yet been activated with Capacity on Demand (CoD).

Available Memory

Displays the amount of memory that is available for assignment to logical partitions on the managed system. This is the total amount of memory that is activated on the managed system minus the amount of memory needed by managed system firmware minus the amount of memory that is assigned to the logical partitions, including the logical partitions that are shut down, on the managed system. This number does not include any memory that has not yet been activated with Capacity on Demand (CoD). The available memory amount can be shown in MB or GB. Click **MB** or **GB** in the Available Memory column title.

Reference Code

Displays the system reference codes for the server. Click the reference code in the table for a detailed description.

The Servers work pane table can also display the following optional attributes in the table.

Configurable Processing Units

Displays the configured processing units. Configured - Licensed and usable (not guarded) processing units.

Configurable Memory

Displays the configured memory. Configured - Licensed and usable (not guarded) memory.

Serial Number

Displays the serial number of the managed system.

Type-Model

Displays the type and model number of the managed system (for example, 9117-MMA).

CoD Processor Capable

Displays whether the managed system supports Capacity on Demand (CoD) for processors.

CoD Memory Capable

Displays whether the managed system supports CoD for memory.

Permanent Processors

Specifies the number of permanent licensed processors.

On/Off CoD Processors State

Displays the On/Off CoD processor state.

Trial CoD Processor State

Displays the Trial CoD processor state.

Reserved CoD Processor State

Displays the Reserved CoD processor state.

Utility CoD Processor State

Displays the Utility CoD processor state.

Permanent Memory (GB)

Displays the amount of permanent activated memory.

On/Off CoD Memory State

Displays the On/Off CoD memory state.

Trial CoD Memory State

Displays the Trial CoD memory state.

To show optional attributes, select the **Column configuration** icon on the table toolbar. This function allows you to select additional attributes that you want displayed as columns in the table. It also allows you to reorder the columns, see “Column configuration” on page 13 for more information.

You can also use **Views** from the table toolbar to display the **Default** server attributes in the table or to display the **Capacity On Demand** server attributes in the table. See “Views menu” on page 14 for more information.

Displaying server details:

Display a server’s properties.

To display details (properties) about a server, you can select the server by clicking in the **Select** column in the work pane table. Then you can either click **Properties** from the tasks pad or click on the double-arrow icon next to the server name and click **Properties** from the context menu. In both cases, the Properties window opens.

Launching tasks for managed objects:

After you have chosen the objects to work with, you are ready to perform the appropriate tasks on them. Learn about how to launch a task for your selected managed objects.

Appropriate tasks for a selected object are listed in the tasks pad, in context menus, and in the **Tasks** menu. If a particular task cannot be performed on an object, the task will not display.

Tasks pad:

This view contains available tasks for selected managed objects.

The **tasks pad** is displayed below the work pane when you have selected an object you want to work with.

Note:

1. Resize the tasks pad by moving the mouse pointer over the border that separates the work pane from the tasks pad.
2. Optionally display the tasks pad by using the **Change User Interface Settings** task. For more information, see “Change User Interface Settings” on page 53.
3. Expand or collapse all the task categories in the tasks pad by selecting **Expand All** or **Collapse All** from the tasks pad heading.

The tasks contained in this view meet the following characteristics:

- Tasks are available for the currently selected target objects in the navigation pane or the work pane table view. If multiple objects are selected in the work pane table, the intersection of the selected objects’ tasks is displayed. If there are no selections in the table, tasks are displayed for the object selected in the navigation pane.
- Tasks available are limited by the role of the user who is currently logged in.

The following is an example of using the *tasks pad* method:

1. Select a server in the work pane table (click the **Select** column).

2. Select a task group from the tasks pad (click the expand button or click the group name).

Note: After you have expanded the task groups, those groups remain open so that you can repeatedly open other tasks without having to reopen the task groups again.

3. Select a task that is displayed under the task group that you want to perform on that server. The task window opens.

Context Menu:

The **Context menu** lists the task groups appropriate for the selected object. Context menus are available only for table selections. For example, in the **Select** column of the Servers Work pane table, select the object you want to work with. The Context menu button (double right arrows) appears next to the object name you have selected. Click the button and the task groups menu appears for that particular object, as shown in Figure 1. Then select a task. If more than one object is selected, the tasks that appear in the Context menu(s) apply to all selections.




Figure 1. Context menu

Tasks menu:

The tasks menu is displayed on the table toolbar.

The tasks menu is available only for table selections. For example, in the **Select** column of the Servers work pane table, select the object you want to work with. Click **Tasks** for the list of the applicable task groups for the selected objects in the table. Select a task group, then select a task to open for the object. If more than one object is selected, the tasks that are displayed in the tasks menu apply to all selections.

Partitions:

When you select a managed server in the navigation pane, the work pane displays the list of partitions defined on the server.

The Partitions work pane table displays the following attributes by default:

Name Specifies the user-defined name of the logical partition.

ID Specifies the ID of the partition

Status Displays the current status of the partition (for example, running, not activated) and, in addition, displays icons representing an unacceptable state or active Attention LED. See “Status: Unacceptable” on page 14 or “Status: Attention LEDs” on page 14 for more information.

Processing Units

Displays the unit of measure for shared processing power across one or more virtual processors. Processing power can be specified in fractions of a processor.

Memory

Specifies the amount of memory allocated to the partition currently. The memory amount can be shown in MB or GB. Click **MB** or **GB** in the Memory column title.

Active Profile

Specifies the profile that was used to activate the partition last.

Environment

Specifies the type of object, logical partition, server, frame.

Reference Code

Displays the system reference codes for the partition. For POWER6™ systems, click the reference code in the table for a detailed description.

The Partitions work pane table can also display the following optional attributes in the table.

Processor

If the partition is using dedicated processors, this value indicates the number of processors currently allocated to the partition. If the partition is using shared processors, this value represents the virtual processors currently allocated to the partition.

Service Partition

Specifies whether the partition has service authority.

Configured

Specifies whether a partition is configured with all the required resources to power on.

Default Profile

Specifies the profile that is configured as the default profile. When users perform the **Activate** task from the partition, this profile is selected by default.

Optional attributes can be displayed when you select the **Column configuration** icon on the table toolbar. This function allows you to select additional attributes that you want displayed as columns in the table. It also allows you to reorder the columns, see “Column configuration” on page 13 for more information.

Displaying partition details:

Display a partition’s properties.

To display details (properties) about a partition you can select the partition by clicking in the **Select** column in the work pane table. Then you can either click **Properties** from the tasks pad or click on the double-arrow icon next to the partition name and click **Properties** from the context menu. You can also click on the partition name. In all cases the **Properties** window is displayed.

Frames:

The **Frames** node identifies the frames managed by this HMC.

Frames typically have dual Bulk Power Controllers (BPCs), however only one BPC is displayed as both BPCs share the same machine type, model, and serial number and function as redundant peers.

The Frames work pane table includes the following attributes:

Name Displays the defined name of the Frame.

Status Displays the status of the frame object. A frame is in an unacceptable state when it is in **No Connection** or **Incomplete** state. When either of these conditions occurs, a red X is displayed in the status cells next to the status text which identifies the state. Clicking on either the X or the status text opens information describing the unacceptable state and potential remedies.

Frame Number

Displays the number of the managed frame. You can modify the number.

Connection Status

Displays connection status of the frame (side A and B).

Custom Groups:

The **Custom Groups** node provides a mechanism for you to group system resources together in a single view.

Groups may be nested to create custom "topologies" of system resources.

Custom groups include the predefined groups **All Partitions** and **All Objects** and any user-defined groups that you created using the **Manage Custom Groups** task under the **Configuration** category in the tasks pad. The **All Partitions** group includes all the partitions defined to all servers managed by the HMC. The **All Objects** group is a collection of all the managed servers, partitions, and frames.

These system-defined groups (All Partitions and All Objects) cannot be deleted. However, if you do not want **All Partitions** or **All Objects** displayed under **Custom Groups**, do the following:

1. Open the **Change User Interface Settings** task from the HMC Management work pane.
2. Deselect **All Partitions node** and **All Objects node** in the **User Interface Settings** window.
3. Click **OK** to save the changes and close the window. Those groups are no longer displayed under **Custom Groups** in the navigation pane.

You can use the **Views** menu on the table toolbar to display your preferred table column configuration. For more information, see "Views menu" on page 14.

User-defined groups:

Create new groups and manage existing ones.

Click **Manage Custom Groups** task under the Configuration category from the tasks pad to create your own group that you want to work with.

To create a group, do the following:

1. Select one or more resources (for example: servers, partitions, frames) that you want to include in the group you want to work with.
2. Click **Manage Custom Groups**.
3. Select **Create a new group**, specify a group name and description, and then click **OK**. The new user-defined group is displayed in the navigation pane under **Custom Groups**.

You can also create a group by using the pattern match method. To use the pattern match method, do the following:

1. Without selecting an object, click **Manage Custom Groups** from the Custom Groups or Systems Management tasks pad.
2. From the Create Pattern Match Group window, select one or more group types that you want to create, specify a group name, description, and the pattern used to determine if an object should be part of the group. Click **OK** to complete. The new user-defined group is displayed in the navigation pane under the **Custom Groups** node.

Note: Patterns specified in the **Managed Resource Pattern** input field are regular expressions. For example, if you specified **abc.***, all the resources that begin with **abc** will be included in that group.

For more information, see “Manage Custom Groups” on page 22.

System Plans

You can display the plans and the tasks used to deploy system plans to managed systems.

A *system plan* contains a specification of the logical partition configuration of a single managed system. You can also use this node to import, export, and manage the files containing these system plans.

To display the plans and tasks:

1. In the navigation pane, select **System Plans**.
2. In the work pane, select a plan you want to work with by clicking in the **Select** column.
3. From the tasks pad, click one of the following tasks:
 - Create System Plan
 - Deploy System Plan
 - Export System Plan
 - Import System Plan
 - Remove System Plan
 - View System Plan

These tasks are described in further detail in “System Plans” on page 21. The table in the work pane displays the system plans that the HMC manages and attributes related to the system plans.

The following attributes are set as the defaults. However, you can select or deselect the attributes that you want displayed in the table by clicking the **Column configuration** icon on the table toolbar. You can also reorder the columns. For more information, see “Column configuration” on page 13.

Name Displays the system plan file name.

Description

Specifies a description of the system plan.

Source

Displays how the system plan was created.

Version

Displays version information about the system plan.

Last Modified Date

Specifies the date when the system plan was last modified.

The create and deploy System Plans tasks are also displayed for a server under the **Configuration** task group.

If there are no system plans available when you select **System Plans**, you can create or import a plan from the tasks listed in the tasks pad.

HMC Management

HMC Management contains a categorized view of HMC management tasks and their descriptions.

These tasks are used for setting up the HMC, maintaining its internal code, and securing the HMC.

To display the tasks in the work pane, do the following:

1. In the Navigation pane, select **HMC Management**.
2. In the work pane, click on the task you want to perform.
3. By default, a categorized listing of the tasks is displayed. The categories include:
 - Operations
 - Administration

To see the HMC level you are using, point your mouse over **HMC Version** at the top of the work pane.

If you want an alphabetic listing of the tasks, click **Alphabetical List** in the upper right corner of the work pane. Click **Categorized List** to go back to the task categories.

Note: If you are accessing the HMC remotely, some tasks do not display.

HMC Management tasks are described in further detail in “HMC Management tasks” on page 51 and a listing of the tasks and the default user roles that can use them are shown in Table 3 on page 78.

Service Management

Service Management contains a categorized or alphabetic view of tasks and their descriptions used to service the HMC.

To display the tasks in the work pane, do the following:

1. In the Navigation pane, select **Service Management**.
2. In the work pane, click on the task you want to perform.
3. By default, a categorized listing of the tasks appear. The category is Connectivity.

To see the HMC level you are using, point your mouse over **HMC Version** at the top of the work pane.

If you want an alphabetical listing of the tasks, click **Alphabetical List** in the upper right corner of the work pane. Click **Categorized List** to go back to the task categories.

Service Management tasks are described in further detail in “Service Management tasks” on page 68 and a listing of the tasks and the default user roles that can use them are shown in Table 3 on page 78.

Updates

Updates provides a way for you to access information on both HMC and system firmware code levels at the same time without performing a task.

The **Updates** work pane displays the HMC code level, and system code levels. You can also install corrective service by clicking **Update HMC**.

Note: Before performing HMC updates, see “Update HMC” on page 75.

To display the tasks, do the following:

1. In the navigation pane, select **Updates**.
2. Select a managed object.
3. In the tasks pad, click the task you want to perform.

These tasks can also be viewed under the **Updates** task group when you are working with managed objects displayed in **Systems Management**.

Work pane

The work pane displays a table of information based on the current selection in the navigation pane or status bar.

Selecting an object displays a configurable table in the work pane.

Working with Tables

The tool bar at the top of the table contains buttons used to select, filter, sort, and arrange the entries in the table.

Hovering over the toolbar buttons displays their functions. The toolbar also includes menus that are used with the information displayed in the tables. For more information, see “Tasks menu” on page 8 and “Views menu” on page 14.

Selecting Rows:

You can select more than one table row at a time.

Rows can be individually selected or a block of rows can be selected at once by first left-clicking the selection box of the first row in the desired block and then shift-clicking the selection box of the last row in the desired block. The **Select All** or **Deselect All** buttons can be used to select or deselect all objects in the table. The table summary at the bottom of the table includes the total number of items that are selected.

Filtering:

Learn more about how to define a filter for a column to limit the entries displayed in a table.

If you select the **Filter Row** button a row appears under the title row of the table. Select **Filter** under a column to define a filter for that column to limit the entries in a table. Tables can be filtered to show only those entries most important to you. The filtered view can be toggled on and off by selecting the check box next to the desired filter in the filter row. Select the **Clear All Filters** button to return to the complete listing. The table summary includes the total number of items that pass the filter criteria in addition to the total number of items.

Sorting:

The Edit Sort and Clear All Sorts buttons are used to perform multi-column sorts of objects in the table in ascending or descending order.

Click **Edit Sort** to define sorts for columns in a table. Alternatively, single column sorting can be performed by selecting the ^ in the column header to change from ascending to descending order. Click **Clear All Sorts** to return to the default ordering.

Column configuration:

The column configuration buttons give you the ability to select which columns to display for folders in the Systems Management tree view.

Click the **Configure Columns** button to arrange the columns in the table in a desired order or hide columns from view. All available columns are listed in the Columns list box by their column name. You select the columns you want displayed or hidden by checking or unchecking the box next to the column names. The column order is manipulated by clicking on a column name from the list box and using the arrow buttons to the right of the list to change the order of the selected column. When you have completed the configuration of the columns, click **OK**. The columns appear in the table as you specified.

If you want to go back to the original layout of the table, click the **Reset Column Order, Visibility, and Widths** button from the table toolbar. Select one or more of the properties you want to reset. Click **OK** to save this setting.

Views menu:

The Views menu is displayed on the toolbar and is only available for table selections when working with servers, custom groups, exceptions view, or attention LEDs view.

This table option allows you to display different sets of attributes (columns) in the table. You can also change the attributes for each view.

Status bar

The status bar in the bottom left pane provides a view of overall system status, including managed system resources and the HMC.

A status-sensitive title, background color, and indicator icons are part of the status bar. The status indicators appear in color when one or more objects go into unacceptable status, have attention LEDs, or have open serviceable events. Otherwise, the status icon is not available.

Click any of the individual icons in the status bar to view a listing of resources with specific status. For example, select the Unacceptable icon to view all resources in an unacceptable state. The results are displayed in a table in the work pane.

Status: Unacceptable

If any managed object is in unacceptable state, the Unacceptable indicator displays on the status bar.

When you select the **Unacceptable** indicator, it displays a table in the work pane of only the objects in an unacceptable state. By clicking on the icon, help information is opened describing the status of the server or partition. You can also use the **Views** menu to display your preferred table column configuration for these objects.

Status: Attention LEDs

If any managed object's Attention LED is activated, the Attention LED icon displays in the status bar.

When you select the Attention LED icon it displays a table in the work pane of only the objects in Attention LED. A help window opens when you click on the icon. You can also use the **Views** menu to display your preferred table column configuration for these objects.

Status: Serviceable Events

If at least one serviceable event for the HMC or a managed object is in an open state, the serviceable event icon displays in the status bar.

When you click the icon the **Manage Serviceable Events** window opens. This window displays all open events.

Status Overview

The Status Overview icon displays a detailed summary of system status in the work pane.

The **Status Overview** icon displays details about any errors, attention LEDs active, or open serviceable events found for the HMC or managed objects. It also summarizes the total number of errors, attention LEDs, and open serviceable events by object type. Object types include the server, partition, frames, and the HMC. When any of these conditions are present, links are available to display all objects with the particular state in the work pane.

Systems Management for Servers

Systems Management displays tasks to manage servers, logical partitions, and frames. Use these tasks to set up, configure, view current status, troubleshoot, and apply solutions for servers.

To perform these tasks, see “Launching tasks for managed objects” on page 7. The tasks listed in the tasks pad change as selections are made in the work area. The context is always listed at the top of the tasks pad in the format *Task: Object*. These tasks are listed when a managed system is selected.

Properties

Display the selected managed system’s properties. This information is useful in system and partition planning and resource allocation.

These properties include the following:

General

The **General** tab displays the system’s name, serial number, model and type, state, attention led state, service processor version, maximum number of partitions, assigned service partition (if designated), and power off policy information.

Processor

The **Processor** tab displays information about the managed system’s processors including maximum number of processors per partition, installed processing units, deconfigured processing units, available processing units, configurable processing units, minimum number of processing units per virtual processor and maximum number of shared processor pools. A table displays partition processor usage.

Memory

The **Memory** tab displays information about the managed system’s memory including installed memory, deconfigured memory, available memory, configurable memory, memory region size, current memory available for partition usage, and system firmware current memory. A table displays partition memory usage.

I/O The **I/O** tab displays the physical I/O resources for the managed system. The assignment of I/O slots and partition and adaptor-type information are displayed, grouped by units. Select the link in the **Slot** column to display the physical I/O properties of each resource. Select **I/O Pools** to display all of the I/O pools found in the system and the partitions that are participating in the pools.

Power-On Parameters

The **Power-On Parameters** tab displays both the default manufacturing settings and the current managed system settings for boot mode. Changing these setting in the **Next** column will take effect on the next restart of the managed system.

Capabilities

The **Capabilities** tab displays the runtime capabilities of this server. Select **Help** for more information on the capabilities listed.

Advanced

The **Advanced** tab displays huge page memory capabilities on the managed system, including available huge page memory, configurable huge page memory, current page size, and current maximum huge page memory. To change memory allocation on systems with huge page table support, set the Requested huge page memory (in pages) field to the desired memory. To change the requested value for huge page memory, the system must be powered off.

Update Password

Use the Update Password task to update HMC access and Advanced System Management Interface (ASMI) passwords on the managed system.

The first time you access a managed system using an HMC, the system prompts you to enter passwords for each of the following:

- Hardware Management Console: HMC access
- Advanced System Management Interface: General
- Advanced System Management Interface: Admin

If you are using an HMC to access the managed system before all required passwords have been set, enter the appropriate password for each password that is presented in the Update Password task.

If another HMC subsequently needs access to this managed system, upon attempting to access this HMC the user is presented with the Update Password Failed Authentication window, which will prompt for the HMC access password you entered.

In the event that the HMC access password changes while you are logged in to the managed system, your HMC will discover that it can no longer authenticate after it attempts to reconnect to that managed system. This will result in a state of *Failed Authentication* for that managed system. You will be required to enter the new password before any actions can be performed.

Operations

Operations contains the tasks for operating managed systems.

Power On

Use the **Power On** task to start a managed system.

Choose from three different options to start your managed system:

- **Partition standby:** When the Partition standby power-on is completed, the system will be in standby mode. Partition standby mode allows you to create and activate logical partitions.
- **System profile:** Powers on the system according to a predefined set of system profiles. Select the system profile that you want to use from the list.
- **Partition auto start:** Powers on the managed system to partition standby mode and then activates all partitions that are marked as auto start or those partitions that were running when the system shut down. For example, if you create a partition with four processors, dynamically remove one processor from the logical partition, and then shut down the system, the partition auto start option activates this partition with three processors because the three-processor configuration was the last configuration used. The HMC ignores whatever is specified in the profile for the partition. You can create and activate logical partitions in partition auto start mode.

Note: If you have AIX preinstalled on this system, do the following:

1. Power using the Partition standby power on option. Do not use the Partition autostart option.
2. Select the partition from which to boot.
3. Select the **Exit MDC** option.

Power Off

Shut down the managed system. Powering off the managed system will make all partitions unavailable until the system is again powered on.

Before you power off the managed system, ensure that all logical partitions have been shut down and that their states have changed from Running to Ready. For more information on shutting down a logical partition, see “Shut Down” on page 36

If you do not shut down all logical partitions on the managed system before you power off the managed system, the managed system shuts down each logical partition before the managed system itself powers off. This can cause a substantial delay in powering off the managed system, particularly if the logical

partitions are not responsive. Further, the logical partitions might shut down abnormally, which could result in data loss and further delays when you activate the logical partitions once more.

Choose from the following options:

Normal power off

The Normal power off mode shuts down the system's operations in a controlled manner. During the shutdown, programs running active jobs are allowed to perform cleanup (end-of-job processing).

Fast power off

The Fast power off mode shuts down the system by stopping all active jobs immediately. The programs running those jobs are not allowed to perform any cleanup. Use this option when you need to shut down the system because of an urgent or critical situation.

Power Management

You can reduce the manage system's processor power consumption by enabling power saver mode.

To enable power saver mode, do the following:

1. In the navigation area, expand **Systems management**.
2. In the navigation area, expand **Servers**.
3. Select the server that you want to enable to use power saver mode.
4. In the tasks area, expand **Operations**.
5. Click **Power Management**.
6. Select your desired power saver mode, and click **OK**.

LED Status

View system attention LED information, light specific LEDs to identify a system component, and test all LEDs on a managed system.

The system provides several LEDs that help identify various components, such as enclosures or field replaceable units (FRUs), in the system. For this reason, they are called *Identify* LEDs. Individual LEDs are located on or near the components. The LEDs are located either on the component itself or on the carrier of the component (for example, memory card, fan, memory module, or processor). LEDs are either green or amber. Green LEDs indicate either of the following:

- Electrical power is present.
- Activity is occurring on a link. (The system could be sending or receiving information.)

Amber LEDs indicate a fault or identify condition. If your system or one of the components on your system has an amber LED turned on or blinking, identify the problem and take the appropriate action to restore the system to normal.

You can activate or deactivate the following types of identify LEDs:

Identify LED for an enclosure

If you want to add an adapter to a specific drawer (enclosure), you need to know the machine type, model, and serial number (MTMS) of the drawer. To determine whether you have the correct MTMS for the drawer that needs the new adapter, you can activate the LED for a drawer and verify that the MTMS corresponds to the drawer that requires the new adapter.

Identify LED for a FRU associated with a specified enclosure

If you want to attach a cable to a specific I/O adapter, you can activate the LED for the adapter that is a field replaceable unit (FRU), and then physically verify where to attach the cable. This can be especially useful when you have several adapters with open ports.

You can deactivate a system attention LED or a logical partition LED. For example, you might determine that a problem is not a high priority and decide to repair the problem at a later time. However, you want to be alerted if another problem occurs, so you must deactivate the system attention LED so that it can be activated again if another problem occurs.

Choose from the following options:

View System Attention LED

Displays the current system attention LED and corresponding partition LED states for the selected system. From this task, you can activate or deactivate system attention LEDs.

Identify LED

Displays the current Identify LED states for all the location codes contained in the selected enclosure. From this task, you can select a single location code or multiple location codes to operate against and activate or deactivate the LED(s) by selecting the corresponding button.

Test LED

Initiates an LED Lamp Test against the selected system. All LEDs will activate for several minutes.

Schedule Operations

Create a schedule for certain operations to be performed on the managed system without operator assistance.

Scheduled operations are helpful for situations where automatic, delayed, or repetitious processing of system operations is necessary. A scheduled operation is started at a specified time, without operator assistance to perform the operation. A schedule can be set for one operation or repeated many times.

For example, you could schedule power on or off operations for a managed system.

The Scheduled Operations task displays the following information for each operation:

- The processor that is the object of the operation.
- The scheduled date
- The scheduled time
- The operation
- The number of remaining repetitions

From the Scheduled Operations window you can do the following:

- Schedule an operation to run at a later time
- Define operations to repeat at regular intervals
- Delete a previously scheduled operation
- View details for a currently scheduled operation
- View scheduled operations within a specified time range
- Sort scheduled operations by date, operation, or managed system

You can schedule an operation to occur once or you can schedule it to repeat. You must provide the time and date that you want the operation to occur. If you want the operation to repeat, you will be asked to select the following:

- The day or days of the week that you want the operation to occur. (optional)
- The interval, or time between each occurrence. (required)
- The total number of repetitions. (required)

The operations that you can schedule for the managed system include the following:

Activate on a System Profile

Schedules an operation on a selected system for scheduling activation of a selected system profile.

Backup Profile Data

Schedules an operation to back up profile data for a managed system

Power Off Managed System

Schedules an operation for a system power off at regular intervals for one or more managed systems.

Power On Managed System

Schedules an operation for a system power on at regular intervals for one or more managed systems.

Manage Utility CoD processors

Schedules an operation for managing how your Utility CoD processors are used.

Manage Utility CoD processor minute usage limit

Creates a limit for Utility CoD processor usage.

Modify a Shared Processor Pool

Schedules an operation for modifying a shared processor pool.

Move a partition to a different pool

Schedules an operation for moving a partition to a different processor pool.

Change power saver mode on a managed system

Schedules an operation for changing a managed system's power saver mode.

To schedule operations on the managed system, do the following:

1. In the Navigation area, click **Systems Management**.
2. In the work pane, select one or more managed systems.
3. In the tasks pad, select the **Operations** task category, then click **Schedule Operations**. The Customize Scheduled Operations window opens.
4. From the Customize Scheduled Operations window, click **Options** from the menu bar to display the next level of options:
 - To add a scheduled operation, click **Options** and then click **New...**
 - To delete a scheduled operation, select the operation you want to delete, point to **Options** and then click **Delete**.
 - To update the list of scheduled operations with the current schedules for the selected objects, point to **Options** and then click **Refresh**.
 - To view a scheduled operation, select the operation you want to view, point to **View** and then click **Schedule Details...**
 - To change the time of a scheduled operation, select the operation you want to view, point to **View** and then click **New Time Range...**
 - To sort the scheduled operations, point to **Sort** and then click one of the sort categories that appears.
5. To return to the HMC workplace, point to **Operations** and then click **Exit**.

Advanced System Management

The HMC can connect directly to the Advanced System Management (ASM) interface for a selected system.

ASM is an interface to the service processor that allows you to manage the operation of the server, such as auto power restart, and to view information about the server, such as the error log and vital product data.

To connect to the Advanced System Management interface, do the following:

1. From the **System Management** tasks list, select **Operations**.
2. From the **Operations** task list, select **Advanced System Management (ASM)**.

Utilization Data

You can set the HMC to collect resource utilization data for a specific managed system or for all systems the HMC manages.

The HMC collects utilization data for memory and processor resources. You can use this data to analyze trends and make resource adjustments. The data is collected into records called events. Events are created at the following times:

- At periodic intervals (hourly, daily, and monthly)
- When you make system-level and partition-level state and configuration changes that affect resource utilization
- When you start up, shut down, and change the local time on the HMC

You must set the HMC to collect utilization data for a managed system before utilization data can display for the managed system.

- Use the **Enable** task to enable the collection of utilization data on a selected managed system.
- Use the **Change Sampling Rate** task to change the utilization sampling intervals.
- Use the **Disable** task to disable the collection of utilization data on a selected managed system.
- Use the **View** task and specify the time span desired to view the collected data for a selected managed system. Restrict the amount of data returned by specifying a maximum number of events.

Rebuild

You can extract the configuration information from the managed system and rebuild the information on the Hardware Management Console (HMC).

This task does not disrupt the operation of the running server.

Rebuilding the managed system updates the information on the HMC about the managed system. Rebuilding the managed system is useful when the state of the managed system is Incomplete. The Incomplete state means that the HMC cannot gather complete information from the managed system about logical partitions, profiles, or resources.

Rebuilding the managed system is different from refreshing the HMC window. When the managed system is rebuilt, the HMC extracts the information from the managed system. You cannot start other tasks while the HMC rebuilds the managed system. This process can take several minutes.

Change Password

Change the HMC access password on the selected managed system

After the password is changed, you must update the HMC access password for all other HMCs from which you want to access this managed system.

Enter the current password. Then enter a new password and verify it by entering it again.

Configuration

Configuration contains the tasks for configuring your managed system and partitions.

Create Logical Partition

Access the LPAR Wizard to create a new logical partition (LPAR) on your managed system.

Ensure you have logical partition planning information before you use this wizard. Logical partition planning information can be found at the System Planning Tool (SPT) Web site: <http://www.ibm.com/systems/support/tools/systemplanningtool/>. The SPT is available to assist you in system planning, design, validation and to provide a system validation report that reflects your system requirements while not exceeding system recommendations.

For more information about creating logical partitions, see Logical Partitioning.

System Plans

Record or import specifications for logical partitions, partition profiles, or hardware specifications on a chosen system.

A *system plan* is a specification of the logical partition configuration of a single managed system. A system plan is stored in a file that is called a *system-plan* file and has a file suffix of *.sysplan*. A system-plan file can contain more than one system plan, although multiple plans in a single file are not common.

The **System Plans** tasks creates a record of the hardware and partition configuration of a managed system at a given time. It records specifications for the logical partitions and partition profiles on the selected system. It can also record hardware specifications that the HMC is able to detect.

To maximize the information that the HMC can obtain from the managed system, power on the managed system and activate the logical partitions on the managed system before creating the new system plan.

The **System Plans** tasks are the same tasks that are available from the **System Plans** node from the navigation pane and are documented here: “System Plans” on page 49.

Shared processor pool management:

You can assign a specific amount of the processing capacity in a shared processor pool to each logical partition that uses shared processors.

Shared processors are physical processors whose processing capacity is shared among multiple logical partitions. By default, all physical processors that are not dedicated to specific logical partitions are grouped together in a *shared processor pool*. This task allows you to view information about your shared processor pool and to make changes to that pool.

Detailed information about configuring shared processor pools is available. For more information, see Configuring shared processor pools using the HMC version 7 release 3.2.0, or later.

Virtual Network Management:

Learn more about managing Virtual Switch (VSwitch) and Virtual Local Area Network (VLAN) configuration.

Virtual adapters in a partition are associated with a Virtual Network (VLAN). A VLAN allows a physical network to be divided administratively into separate logical networks. In effect, these logical networks operate as if they are physically independent of each other. Multiple VLAN logical devices can be configured on a single partition. Each VLAN logical device constitutes an additional Ethernet adapter instance. These logical devices can be used to configure the same types of Ethernet IP interfaces as are used with physical Ethernet adapters.

Virtual Switches (VSwitches) allow you to create multiple VLAN adapters in a partition and allow these adapters to route through different physical adapters to the external network. One VSwitch (VSwitch0) is defined by default.

Detailed information about Virtual Ethernet is available. For more information, see Configuring a virtual Ethernet adapter using the HMC.

Partition Availability Priority:

Use this task to specify the partition-availability priority of each logical partition on this managed system.

The managed system uses partition-availability priorities in the case of processor failure. If a processor fails on a logical partition, and there are no unassigned processors available on the managed system, the logical partition can acquire a replacement processor from logical partitions with a lower partition-availability priority. This allows the logical partition with the higher partition-availability priority to continue running after a processor failure.

You can change the partition availability priority for a partition by selecting a partition and choosing an availability priority from those listed.

Use the online Help if you need additional information about prioritizing partitions.

View Workload Management Groups:

Display a detailed view of the workload management groups you have specified for this managed system.

Each group displays the total number of processors, processing units for partitions using shared mode processing, and the total amount of memory allocated to the partitions in the group.

Manage Custom Groups:

You can report status on a group basis, allowing you to monitor your system in a way that you prefer.

You can also nest groups (a group contained within a group) to provide hierarchical or topology views.

One or more user-defined groups might already be defined on your HMC. Default groups are listed under **Custom Groups** node under **Server Management**. The default groups are **All Partitions** and **All Objects**. You can create others, delete the ones that were created, add to created groups, create groups using the pattern match method, or delete from created groups by using the **Manage Custom Groups** task.

Use the online Help if you need additional information for working with groups.

Manage Partition Data

A partition profile is a record on the HMC that specifies a possible configuration for a logical partition. When you activate a partition profile, the managed system attempts to start the logical partition using the configuration information in the partition profile.

A partition profile specifies the desired system resources for the logical partition and the minimum and maximum amounts of system resources that the logical partition can have. The system resources specified within a partition profile includes processors, memory, and I/O resources. The partition profile can also specify certain operating settings for the logical partition. For example, you can set a partition profile so that, when the partition profile is activated, the logical partition is set to start automatically the next time that you power on the managed system.

Each logical partition on a managed system that is managed by an HMC has at least one partition profile. You can create additional partition profiles with different resource specifications for your logical partition. If you create multiple partition profiles, you can designate any partition profile on the logical partition to be the default partition profile. The HMC activates the default profile if you do not select a specific partition profile to be activated. Only one partition profile can be active at one time. To activate another partition profile for a logical partition, you must shut down the logical partition before you activate the other partition profile.

A partition profile is identified by partition ID and profile name. Partition IDs are whole numbers used to identify each logical partition that you create on a managed system, and profile names identify the partition profiles that you create for each logical partition. Each partition profile on a logical partition

must have a unique profile name, but you can use a profile name for different logical partitions on a single managed system. For example, logical partition 1 cannot have more than one partition profile with a profile name of normal, but you can create a profile named normal for each logical partition on the managed system.

When you create a partition profile, the HMC shows you all of the resources available on your system. The HMC does not verify if another partition profile is currently using a portion of these resources. Therefore, it is possible for you to overcommit resources. When you activate a profile, the system attempts to allocate the resources that you assigned to the profile. If you have overcommitted resources, the partition profile will not be activated.

For example, you have four processors on your managed system. Partition 1 profile A has three processors, and partition 2 profile B has two processors. If you attempt to activate both of these partition profiles at the same time, partition 2 profile B will fail to activate because you have overcommitted processor resources.

When you shut down a logical partition and reactivate the logical partition using a partition profile, the partition profile overlays the resource specifications of the logical partition with the resource specifications in the partition profile. Any resource changes that you made to the logical partition using dynamic logical partitioning are lost when you reactivate the logical partition using a partition profile. This is desirable when you want to undo dynamic logical partitioning changes to the logical partition. However, this is not desirable if you want to reactivate the logical partition using the resource specifications that the logical partition had when you shut down the managed system. Therefore, keep your partition profiles up to date with the latest resource specifications. You can save the current configuration of the logical partition as a partition profile. This allows you to avoid having to change partition profiles manually.

If you shut down a logical partition whose partition profiles are not up to date, and the logical partition is set to start automatically when the managed system starts, you can preserve the resource specifications on that logical partition by restarting the entire managed system using the partition autostart power-on mode. When the logical partitions start automatically, the logical partitions have the resource specifications that the logical partitions had when you shut down the managed system.

Use the Manage Partition Data tasks to do the following:

- Restore partition data. If you lose partition profile data, use the restore task in one of three ways:
 - Restore partition data from a backup file. Profile modifications performed after the selected backup file was created will be lost.
 - Restore merged data from your backup file and recent profile activity. The data in the backup file takes priority over recent profile activity if the information conflicts.
 - Restore merged data from recent profile activity and your backup file. The data from recent profile activity takes priority over your backup file if the information conflicts.
- Initialize a partition profile. Initializing the partition data for a managed system will delete all of the currently defined system profiles, partitions, and partition profiles.
- Backup a partition profile to a file.
- Delete a backup of partition data.

Use the online Help if you need additional information about managing partition data.

Manage System Profiles

A system profile is an ordered list of partition profiles that is used by the HMC to start the logical partitions on a managed system in a specific configuration. Learn about how you can manage these system profiles.

When you activate the system profile, the managed system attempts to activate each partition profile in the system profile in the order specified. A system profile helps you activate or change the managed system from one complete set of logical partition configurations to another.

You can create a system profile that has a partition profile that has overcommitted resources. You can use the HMC to validate the system profile against the currently available system resources and against the total system resources. Validating your system profile ensures that your I/O devices and processing resources are not overcommitted, and it increases the likelihood that the system profile can be activated. The validation process estimates the amount of memory needed to activate all of the partition profiles in the system profile. It is possible that a system profile can pass validation and yet not have enough memory to be activated.

Use this task to do the following:

- Create new system profiles.
- Create a copy of a system profile.
- Validate the resources specified in the system profile against the resources available on the managed system. The validation process indicates whether any of the logical partitions in the system profile are already active and whether the uncommitted resources on the managed system can meet the minimum resources specified in the partition profile.
- View the properties of a system profile. From this task, you can view or change an existing system profile.
- Delete a system profile.
- Activate a system profile. When you activate a system profile, the managed system will attempt to activate the partition profiles in the order specified in the system profile.

Use the online Help if you need additional information about managing system profiles.

Viewing HMC connection status

You can view the HMC connection status to service processors or frames, reset those connections, connect another HMC to the selected managed system, or connect another managed system to the HMC.

If you have selected a managed system in the work area, the following tasks pertain to that managed system. If you have selected a frame, the tasks pertain to that frame.

Note: If you remove a connection between the HMC and a managed system and you plan to reconnect the managed system to the HMC in the future, you must clear the connection history before reconnecting the managed system. To do this, use the `mksysconn -o auto` command from a restricted shell. For more information about how to open a restricted shell, see “Open Restricted Shell Terminal” on page 64.

View service processor connection status

View information about the status of the HMC connection to the service processors on the managed system.

To show the service processor connection status to the service processors on the managed system, do the following:

1. In the navigation area, expand **Systems management**.
2. In the navigation area, expand **Servers**.
3. Select the server for which you want to view service processor connection status.
4. In the tasks area, expand **Connections**.
5. Select **Service Processor Status**.

Resetting or removing connections

Reset or remove a managed system from the HMC interface.

To reset or remove connections, do the following:

1. In the navigation area, expand **Systems management**.
2. In the navigation area, expand **Servers**.
3. Select the server that you want to reset or remove.
4. In the tasks area, expand **Connections**.
5. Select **Reset or Remove Connections**.
6. Select an option and click **OK**.

Disconnecting another HMC

You can disconnect a connection between a selected HMC and the managed server.

To disconnect another HMC, do the following:

1. In the navigation area, expand **Systems management**.
2. In the navigation area, expand **Servers**.
3. Select the server for which you want to disconnect another HMC.
4. In the tasks area, expand **Connections**.
5. Select **Disconnect another HMC**.
6. Select an HMC from the list and click **OK**.

Adding a managed system

Add systems in the network to the list of systems managed by this HMC.

To add managed systems in the network to the list of systems managed by this HMC, do the following:

1. In the navigation area, expand **Systems management**.
2. In the navigation area, expand **Servers**.
3. Select the server.
4. In the tasks area, expand **Connections**.
5. Select **Add Managed System**.
6. Select an option, enter the required IP address information, and click **OK**.

Correcting a connection problem

To correct a connection problem between the HMC and the managed system or to correct the state of a managed system in *No Connection*, *Incomplete*, *Recovery*, *Error*, or *Failed Authentication* state, follow the procedures below.

Correcting a No connection state for a managed system:

The **No connection** state can occur when the HMC is not connected, or the handshake with the managed system failed.

Use this procedure for a system that was previously connected to the same HMC and is now in No connection state. If you have a new system, a new HMC, or have moved your system to a different HMC, refer to Correcting a connection problem between the HMC and a managed system.

1. From the **Systems Management - Servers** work pane, select the managed system.
2. Select **Connections - Service Processor Status**. Record the IP address of the service processor.
3. From the **HMC Management** work pane, select **Test Network Connectivity**.
4. Enter the IP address of the service processor and select **Ping**.

5. Choose from the following options:
 - If the ping is successful, go to step 6.
 - If the ping is not successful, go to step 7.
6. If the ping test is successful, perform the following steps:
 - a. In the **Systems Management - Servers** work pane, ensure that there are no reference codes displayed in the **Reference Code** column for the server in Incomplete state. **Note:** A steady reference code could indicate a hardware problem. If the reference code is a clickable link, click the reference code to display possible procedures to correct the problem. If the reference code is not a link or a solution is not presented, contact your next level of support or your hardware service provider.
 - b. Restart the HMC. For more information on restarting the HMC, see “Shut Down or Restart” on page 66.
 - c. If restarting the HMC does not resolve the problem, contact your next level of support or your hardware service provider.
7. If the ping test is not successful, perform the following steps:
 - a. In the **Systems Management - Servers** work pane, ensure that there are no reference codes displayed in the **Reference Code** column for the server in Incomplete state. **Note:** A steady reference code could indicate a hardware problem. If the reference code is a clickable link, click the reference code to display possible procedures to correct the problem. If the reference code is not a link or a solution is not presented, contact your next level of support or your hardware service provider.
 - b. If your system has a control panel, check to see if the power light is on. Choose from the following options:
 - If there is power to the managed system, go to step 8.
 - If there is no power to the managed system, “Power On” on page 16 the managed system. After the power is restored, wait 5 minutes for the service processor to re-IPL and the HMC to re-establish contact. If the system is equipped with redundant service processors, allow up to 20 minutes for this step.
8. Verify physical network connectivity:
 - a. Verify that the HMC and the service processor are correctly connected to your Ethernet network.
 - b. Verify that Ethernet link status is good on all network segments which exist between the HMC and the managed system.
 - c. If you think the network might be the problem, connect a cable from the HMC to the service processor and try pinging the failing system. Then choose from the following options:
 - If the ping is successful, put the cables back the way they were and correct the network problem. After the network problem is resolved, repeat this entire procedure.
 - If the ping is not successful, put the cables back the way they were and continue with step 8.d.
 - d. Reset the service processor using the following steps:
 - 1) “Power Off” on page 16 the server.
 - 2) Unplug the AC power cord and re-plug it back in.
 - 3) “Power On” on page 16 the server.
9. If the problem is not resolved by any of the above steps, contact your next level of support or your hardware service provider.

Correcting an Incomplete state for a managed system:

The **Incomplete** state can occur when the HMC failed to get all of the necessary information from the managed system.

To correct an **Incomplete** state, perform the following steps:

1. From the **Systems Management - Servers** work pane, select the managed system.
2. In the tasks pad, select **Operations - Rebuild**.
3. Select **Yes** to refresh the internal representation of the managed system on the HMC.
 - If the state remains **Incomplete**, rebuild the managed system several more times
 - If the state goes to **Recovery**, see “Correcting a Recovery state for a managed system.”
 - If the state does not remain in **Incomplete** or go to **Recovery**, continue with the next step.
4. In the tasks pad, select **Connections - Reset or Remove Connections** to reset the connection from the managed system to the HMC. If this fails, continue to the next step.
5. Restart the HMC. For more information on restarting the HMC, see “Shut Down or Restart” on page 66.
 - If the state goes to **Recovery**, see “Correcting a Recovery state for a managed system.”
 - If the state remains **Incomplete**, perform the following steps:
 - Verify that there is a redundant HMC.
 - Verify that no one is entering commands from the alternate HMC.
 - Repeat step 1 through 5. If it still fails, continue with the next step.
6. If the problem persists, contact your next level of support or your hardware service provider.

Correcting a Recovery state for a managed system:

The **Recovery** state can occur when the save area in the service processor assembly is not synchronized with the HMC.

To recover from the **Recovery** state, perform the following steps:

1. Restore partition data. For details, see the **Restore** task in “Manage Partition Data” on page 22. If this solves the problem, this ends the procedure.
2. If the problem is not resolved after restoring partition data, choose the option that describes what happened:
 - If the state remains **Recovery**, retry restoring partition data. If it fails a second time, follow the problem determination procedure for any reference codes you receive.
 - If the state changed to **Incomplete**, refer to “Correcting an Incomplete state for a managed system” on page 26.
 - If the state changed to **No Connection**, refer to “Correcting a No connection state for a managed system” on page 25.
3. If the problem persists, contact your next level of support or your hardware service provider.

Correcting an Error state for a managed system:

The **Error** state automatically generates a call to the service support center if the function is enabled.

If the automatic call support function is not enabled, contact your next level of support or your hardware service provider.

Correcting a Failed Authentication state for a managed system:

The **Failed Authentication** state can occur when the HMC access password for the managed system is not valid.

1. Do you have an HMC password?
 - **Yes:** Enter the HMC password and choose from the following options:
 - If the managed system goes to **Operating**, **Power Off**, or **Standby** state, the authentication was successful. This ends the procedure.

- If the managed system goes to **No connection**, **Incomplete**, **Recovery**, or **Error** state, refer to Correcting the managed system operating state.
 - **No:** Do you have an ASMI admin password?
 - **Yes:** Continue with step 2.
 - **No:** Contact your next level of support to request CE login. Then continue with step 2, using CE login instead of admin password for step 2.a.
2. Perform™ the following steps:
- a. Login to the ASMI with admin authority. See “Advanced System Management” on page 19.
 - b. Select **Login Profile**.
 - c. Select **Change Password**.
 - d. In the **User ID to change field**, select **HMC**.
 - e. Enter the ASMI’s admin password in the **Current® password for user ID admin** field. **Note:** Do not enter the HMC user password.
 - f. Enter the ASMI’s admin password.
 - g. Enter a new HMC access password twice and click **Continue**.
 - h. From the **Systems Management - Servers** work pane, select the managed system.
 - i. Select **Update password**.
 - j. Input the new password that was set in step 2.g. This ends the procedure.

Correcting a new connection problem between the HMC and a managed system:

Use this procedure if you have a new HMC, a new managed system, or have moved your managed system to a different HMC.

If your system was previously connected to the same HMC and is now in **No connection** state, refer to “Correcting a No connection state for a managed system” on page 25.

1. From the **Systems Management - Servers** work pane, select **Connections - Add Managed System** from the tasks pad. For more information, see “Viewing HMC connection status” on page 24. Does the system appear in the work pane?
 - **Yes:** This ends the procedure.
 - **No:** Continue with step 2.
2. Check for network problems, cables, switches, link lights on the service processor, and so on. Was there a problem?
 - **Yes:** Correct the problem and return to step 1.
 - **No:** Continue with step 3.
3. Reset the service processor to force it to request a new IP address using the following steps:
 - a. “Power Off” on page 16 the server.
 - b. Unplug the AC power cord and re-plug it back in.
 - c. “Power On” on page 16 the server.
4. Did resetting the service processor resolve the problem?
 - **Yes:** This ends the procedure.
 - **No:** Contact your next level of support.

Hardware Information

Display information about the hardware attached to a selected managed system.

Adapters

View information about the Host Ethernet Adapters (HEA, also referred to as Integrated Virtual Ethernet adapters) or Host Channel Adapters (HCA) for a selected managed system.

For more information about HEAs, see Host Ethernet Adapter.

Host Ethernet Adapter (HEA):

A Host Ethernet Adapter (HEA) allows multiple logical partitions to share a single physical Ethernet adapter.

Unlike most other types of I/O devices, you can never assign the HEA itself to a logical partition. Instead, multiple logical partitions can connect directly to the HEA and use the HEA resources. This allows these logical partitions to access external networks through the HEA without having to go through an Ethernet bridge on another logical partition.

Use the **Host Ethernet** task to display or configure the ports of the physical HEAs on a selected managed system.

To configure a physical port on an HEA, select the port from the list and select **Configure**.

Use the online Help for additional information on configuring HEA ports.

Host Channel Adapter (HCA):

Host Channel Adapters (HCAs) provide a managed system with port connections to other Microsoft® devices. That port can be connected to another HCA, a target device, or a switch that redirects the data coming in on one of its ports out to a device attached to another of its ports.

You can show a list of the HCAs for the managed system. You can select an HCA from the list to display the current partition usage for the HCA.

From this task you can display the following:

- The physical location of each HCA on the managed system.
- The number of globally unique identifiers (GUIDs) that are in use on each HCA.
- The number of GUIDs on each HCA that are available to be assigned to logical partitions.
- HMC management status. HCAs that are unable to be managed by an HMC are in an error state.
- The logical partition usage for a selected HCA.

Virtual IO Adapters

View the topology of currently configured virtual SCSI and virtual Ethernet adapters on a selected partition.

Use the **SCSI** task to view the topology of virtual SCSI adapters on a partition. The following information is displayed:

- Adapter name
- Backing device
- Remote partition
- Remote Adapter
- Remote Backing Device

Use the **Ethernet** task to view the current virtual Ethernet configuration for the partition. The following information is displayed:

- Adapter name
- Virtual LANs
- I/O Server
- Server Virtual Adapter
- Shared Adapter

Partitions assigned to a VLAN that is bridged have access to an external network via a physical shared Ethernet adapter owned by a Virtual I/O Server.

View Hardware Topology

Display the current hardware topology for the selected managed system and any discrepancies between the current topology and the last valid topology.

High Speed Link (HSL), also known as Remote I/O (RIO), resources provide the connection between system I/O busses and the system processor. HSL/RIO resources are normally configured in loops with the system unit having an HSL/RIO controller resource that handles routing of the data between the system processor and the system I/O busses. System I/O busses connect to the loop with HSL I/O adapter or RIO adapter resources.

Use this task to display the current RIO topology of the selected managed system. Current Topology displays the current topology. Any discrepancies between the current topology and the last valid topology are identified as errors. The following information is shown:

- The starting location of the physical RIO cable and the RIO connection (cable to port)
- The ending location of the physical RIO cable and the RIO connection (cable to port)
- Starting Node Type Displays the values of the node. Possible values are Local Bridge, Local NIC, Remote Bridge, and Remote NIC
- Link Status Displays the leading port status
- Cable Length Displays the length of the RIO cables. Errors occur when the actual cable lengths are different from the expected cable lengths
- The serial number of the power-controlling managed system
- The serial number of the function-controlling managed system

Updates

Perform a guided update of managed system, power, or I/O Licensed Internal Code.

These **Update** tasks are the same tasks that are available from the Updates node of the navigation pane and are documented here: “Managed System Updates” on page 75.

Serviceability

Problem Analysis on the HMC automatically detects error conditions and reports to you any problem that requires service to repair it.

These problems are reported to you as serviceable events. Use the **Manage Events** task to view specific events for selected systems. However, if you notice a problem occurred or you suspect a problem is affecting the system but Problem Analysis has not reported it to you, use the **Create Serviceable Event** task to report the problem to your service provider.

Manage Serviceable Events

Problems on your managed system are reported to the HMC as serviceable events. You can view the problem, manage problem data, call home the event to your service provider, or repair the problem.

To set the criteria for the serviceable events you to view, do the following:

1. From the tasks pad, open **Manage Serviceable Events**.
2. Provide event criteria, error criteria, and FRU criteria.
3. Click **OK**.
4. If you do not want the results filtered, select **ALL**.

The Serviceable Events Overview window displays all of the events that match your criteria. The information displayed in the compact table view includes the following:

- Problem Number
- PMH Number
- Reference Code - Click on the Reference code to display a description of the problem reported and actions that may be taken to fix the problem.
- Status of the problem
- Last reported time of the problem
- Failing MTMS of the problem

The full table view includes more detailed information, including reporting MTMS, first reported time, and serviceable event text.

Select a serviceable event and use the **Selected** drop down menu to:

- **View event details:** Field-replaceable units (FRUs) associated with this event and their descriptions.
- **Repair the event:** Launch a guided repair procedure, if available.
- **Call home the event:** Report the event to your service provider.
- **Manage event problem data:** View, call home, or offload to media data and logs associated with this event.
- **Close the event:** After the problem is solved, add comments and close the event.

Use the online Help if you need additional information on managing serviceable events.

Create Serviceable Event

Use this task to report a problem on your managed system to your service provider or to test problem reporting on your managed system.

Submitting a problem is dependent upon whether you have customized your HMC to use the Remote Support Facility (RSF) and if it is authorized to automatically call for service. If so, the problem information and service request is sent to the service provider automatically with a modem transmission.

To report a problem on your managed system:

1. Open the **Create Serviceable Event** task from the Service Management work pane.
2. From the **Report a Problem** window, enter a brief description of your problem in the **Problem Description** input field and then click **Request Service**.

or

To test problem reporting from the **Report a Problem** window:

1. Select **Test automatic problem reporting** and enter *This is just a test* in the **Problem Description** input field.
2. Click **Request Service**.

The problems are reported to the service provider for the managed system. Reporting a problem sends to the service provider the information you provide on the **Report a Problem** window, and machine information that identifies the console.

Use the online Help if you need additional information for reporting a problem or testing if problem reporting works.

Reference Code History

Reference codes provide general diagnostic, troubleshooting, and debugging information.

The most recent reference codes are displayed. To view a history of reference codes, enter the number of codes to retrieve from the history and select **Go**. If detailed information is available on the managed system you are viewing, select the desired reference code to view the details of a specific reference code.

Control Panel Functions

Learn more about how to display the available virtual control panel functions for the managed system.

(20) Type, Model, Feature displays the managed system's machine type, model, and feature code. Also displayed are the CEC IPL Type and the FSP IPL Type for the managed system.

Hardware

Add, exchange, or remove hardware from the managed system. Display a list of installed FRUs or enclosures and their locations. Select a FRU or an enclosure and launch a step-by-step procedure to add, exchange, or remove the unit.

Add FRU:

Locate and add a Field Replaceable Unit (FRU).

To add a FRU, do the following:

1. Select an enclosure type from the drop down list.
2. Select an FRU type from the list.
3. Click **Next**.
4. Select a location code from the displayed list.
5. Click **Add**.
6. Click **Launch Procedure**.
7. When you have completed the FRU installation process, click **Finish**.

Add Enclosure:

locate and add an enclosure.

To add an enclosure, do the following:

1. Select an enclosure type, then click **Add**.
2. Click **Launch Procedure**.
3. When you have completed the enclosure installation process, click **Finish**.

Exchange FRU:

Use the **Exchange FRU** task to exchange one FRU with another.

To exchange a FRU:

1. Select an installed enclosure type from the drop down list.
2. From the displayed list of FRU types for this enclosure, select an FRU type.
3. Click **Next** to display a list of locations for the FRU type.
4. Select a location code for a specific FRU.
5. Click **Add** to add the FRU location to **Pending Actions**.
6. Select **Launch Procedure** to begin replacing the FRUs listed in **Pending Actions**.
7. Click **Finish** when you have completed the installation.

Exchange Enclosure:

Use the **Exchange Enclosure** task to exchange one enclosure for another.

To exchange an enclosure:

1. Select an installed enclosure, then click **Add** to add the selected enclosure's location code to **Pending Actions**.
2. Click **Launch Procedure** to begin replacing the enclosures identified in **Pending Actions** in the selected system.
3. Click **Finish** when you have completed the enclosure replacement process

Remove FRU:

Use the **Remove FRU** task to remove a FRU from your managed system.

To remove a FRU:

1. Select an enclosure from the drop down list to display a list FRU types currently installed in the selected enclosure.
2. From the displayed list of FRU types for this enclosure, select an FRU type.
3. Click **Next** to display a list of locations for the FRU type.
4. Select a location code for a specific FRU.
5. Click **Add** to add the FRU location to **Pending Actions**.
6. Select **Launch Procedure** to begin removing the FRUs listed in **Pending Actions**.
7. Click **Finish** when you have completed the removal procedure.

Remove Enclosure:

Use the **Remove Enclosure** task to remove an enclosure.

To remove an enclosure:

1. Select an enclosure type, then click **Add** to add the selected enclosure type's location code to **Pending Actions**.
2. Click **Launch Procedure** to begin removing the enclosures identified in **Pending Actions** from the selected system.
3. Click **Finish** when you have completed the enclosure removal process.

Power On/Off IO Unit:

Use the **Power On/Off IO Unit** task to power on or off an IO unit.

Only units or slots that reside in a power domain can be powered on or off. The corresponding power on/off buttons will be disabled for location codes that are not controllable by the HMC.

Manage Dumps

Manage system, service processor, and power subsystem dumps for systems managed by the HMC.

system dump

A collection of data from server hardware and firmware, either after a system failure or a manual request. Only perform a system dump under the direction of your next level of support or your service provider.

service processor dump

A collection of data from a service processor either after a failure, external reset, or manual request.

power subsystem dump

A collection of data from Bulk Power Control service processor. This is only applicable to certain models of managed systems.

Use the Manage Dump task to do the following:

- Initiate a system dump, a service processor dump, or a power subsystem dump.
- Modify the dump capability parameters for a dump type before initiating a dump.
- Delete a dump.
- Copy a dump to media such as a DVD-RAM.
- Copy a dump to another system using FTP.
- Call home a dump by using the Call Home feature to transmit the dump back to your service provider, for example IBM Remote Support, for further analysis.
- View the offload status of a dump as it progresses.

Use the online Help if you need additional information for managing dumps.

Collect VPD

Copy Vital Product Data (VPD) to removable media.

The managed system has VPD that is stored internally. The VPD consists of information such as how much memory is installed, and how many processors are installed. These records can provide valuable information which can be used by remote service and service representatives so that they can help you keep the firmware and software on your managed system up to date.

Note: To collect VPD, you must have at least one operational partition. For more information, see Logical Partitioning.

The information in the VPD file can be used to complete the following types of orders for your managed system:

- Install or remove a sales feature
- Upgrade or downgrade a model
- Upgrade or downgrade a feature

Using this task, this information can be sent to removable media (diskette, DVD-RAM, or memory key) for use by you or your service provider.

Use the online Help if you need additional information for collecting VPD.

Edit MTMS

Edit or display the model, type, machine serial (MTMS) or configuration ID of an enclosure.

The MTMS value or configuration ID for an expansion unit may need to be edited during a replacement procedure.

Use the online Help if you need additional information for editing MTMS.

FSP Failover

Enable a secondary service processor if your managed system's primary service processor fails.

FSP Failover is designed to reduce customer outages due to service processor hardware failures. If a redundant service processor is supported for the current system configuration, select **Setup** to set up FSP Failover for the selected managed system. Select **Initiate** to initiate FSP Failover for the selected managed system.

Capacity on Demand

Activate inactive processors or memory that are installed on your managed server.

Capacity on Demand (CoD) allows you to nondisruptively activate (no boot required) processors and memory. Capacity on Demand also gives you the option to temporarily activate capacity to meet intermittent performance needs, to activate additional capacity on a trial basis, and to access capacity to support operations in times of need.

For more information about Capacity on Demand, see [Capacity on Demand](#).

Systems Management for Partitions

Systems Management displays tasks you can perform to manage servers, logical partitions, and frames. Use these tasks to set up, configure, view current status, troubleshoot, and apply solutions for partitions.

This chapter describes the tasks that display when you select a partition.

To launch these tasks, see “Launching tasks for managed objects” on page 7. The following sets of tasks are represented in the tasks pad, tasks menu, or context menu. The tasks listed in the tasks pad change as selections are made in the work area. The context is always listed at the top of the tasks pad in the format Task: Object. These tasks are listed when a partition is selected and the context is Tasks: *partition name*.

Properties

The **Properties** task displays the selected partition’s properties. This information is useful in resource allocation and partition management. These properties include:

General

The **General** tab displays the partition’s name, id, environment, state, resource configuration, operating system, the current profile used when starting the partition, and the system on which the partition is located.

Hardware

The **Hardware** tab displays the current usage of processors, memory, and I/O on the partition.

Virtual Adapters

The **Virtual Adapters** tab displays the current configuration of virtual adapters. Virtual adapters allow for the sharing of resources between partitions. From this tab, you can view, create, and edit virtual adapters on the partition.

Settings

The **Settings** tab displays the boot mode and keylock position of the partition. Also displayed are the current service and support settings for the partition.

Other The **Other** tab displays the partition’s Workload Management Group (if applicable), and the partition’s Power controlling partitions.

Change Default Profile

Change the default profile for the partition.

Select a profile from the drop down list to be the new default profile.

Operations

Operations contains the tasks for operating partitions.

Activate

Use the **Activate** task to activate a partition on your managed system in the **Not Activated** state.

A list of profiles is display that are valid to start the selected partition. Select from the list of profiles and click OK to activate the partition. Check **Open a terminal window or console** to do so.

Restart

Restart the selected logical partition or partitions.

For i5/OS® logical partitions, use this window only if you cannot restart the IBM i logical partition from the command line of the operating system. Using this window to restart an IBM i logical partition will result in an abnormal IPL.

Choose one of the following options (the Operating System option and the Operating System Immediate option are only enabled if Resource Monitoring and Control (RMC) is up and configured):

Dump The HMC shuts down the logical partition and initiates a main storage or system memory dump. For AIX and Linux® logical partitions, the HMC also notifies the logical partition that it will be shut down. For IBM i logical partitions, the processors are stopped immediately. After the shutdown is complete, the logical partition is immediately restarted. (IBM i logical partitions are restarted multiple times so that the logical partition can store the dump information.) Use this option if a portion of the operation system appears hung and you want a dump of the logical partition for analysis.

Operating System

The HMC shuts down the logical partition normally by issuing a shutdown -r command to the logical partition. During this operation, the logical partition performs any necessary shutdown activities. After the shutdown is complete, the logical partition is immediately restarted. This option is only available for AIX logical partitions. **Immediate:** The HMC shuts down the logical partition immediately. The HMC ends all active jobs immediately. The programs running in those jobs are not allowed to perform any job cleanup. This option might cause undesirable results if data has been partially updated. Use this option only after a controlled end has been unsuccessfully attempted.

Operating System Immediate

The HMC shuts down the logical partition immediately by issuing a shutdown -Fr command to the logical partition. During this operation, the logical partition bypasses messages to other users and other shutdown activities. After the shutdown is complete, the logical partition is immediately restarted. This option is only available for AIX logical partitions.

Dump Retry

The HMC retries a main storage or system memory dump on the logical partition. After this is complete, the logical partition is shut down and restarted. Use this option only if you have previously tried the Dump option without success. This option is only available for IBM i logical partitions.

Shut Down

Shut down the selected logical partition or partitions.

For IBM i logical partitions, use this window only if you cannot shut down the IBM i logical partition from the command line of the operating system. Using this window to shut down an IBM i logical partition will result in an abnormal IPL.

Choose from the following options:

Delayed

The HMC shuts down the logical partition using the delayed power-off sequence. This allows the logical partition time to end jobs and write data to disks. If the logical partition is unable to shut down within the predetermined amount of time, it will end abnormally and the next restart may be longer than normal.

Immediate

The HMC shuts down the logical partition immediately. The HMC ends all active jobs immediately. The programs running in those jobs are not allowed to perform any job cleanup.

This option might cause undesirable results if data has been partially updated. Use this option only after a controlled shutdown has been unsuccessfully attempted.

Operating System

The HMC shuts down the logical partition normally by issuing a shutdown command to the logical partition. During this operation, the logical partition performs any necessary shutdown activities. This option is only available for AIX logical partitions.

Operating System Immediate

The HMC shuts down the logical partition immediately by issuing a shutdown -F command to the logical partition. During this operation, the logical partition bypasses messages to other users and other shutdown activities. This option is only available for AIX logical partitions.

Manage Attention LED

Use the **Manage Attention LED** to activate or deactivate an attention LED on your partition.

All attention LEDs for the partitions on the managed system are listed. Select an LED and choose to activate or deactivate.

Schedule Operations

Create a schedule for certain operations to be performed on the logical partition without operator assistance.

Scheduled operations are helpful for situations where automatic, delayed, or repetitious processing of system operations is necessary. A scheduled operation is started at a specified time, without operator assistance to perform the operation. A schedule can be set for one operation or repeated many times.

For example, you could schedule an operation to remove resources from a logical partition or move resources from one logical partition to another.

The Scheduled Operations task displays the following information for each operation:

- The processor that is the object of the operation.
- The scheduled date
- The scheduled time
- The operation
- The number of remaining repetitions

From the Scheduled Operations window you can do the following:

- Schedule an operation to run at a later time
- Define operations to repeat at regular intervals
- Delete a previously scheduled operation
- View details for a currently scheduled operation
- View scheduled operations within a specified time range
- Sort scheduled operations by date, operation, or managed system

You can schedule an operation to occur once or you can schedule it to repeat. You must provide the time and date that you want the operation to occur. If you want the operation to repeat, you will be asked to select the following:

- The day or days of the week that you want the operation to occur. (optional)
- The interval, or time between each occurrence. (required)
- The total number of repetitions. (required)

The operations that you can schedule for a logical partition include the following:

Activate on an LPAR

Schedules an operation on a selected profile for activation of the selected logical partition.

Dynamic Reconfiguration

Schedules an operation for adding, removing, or moving a resource (processors or megabytes of memory).

Operating System Shutdown (on a partition)

Schedules a shutdown of the selected logical partition.

To schedule operations on the HMC, do the following:

1. In the Navigation area, click **Systems Management**.
2. In the work pane, select one or more partitions.
3. In the tasks pad, select the **Operations** task category, then click **Schedule Operations**. The Customize Scheduled Operations window opens.
4. From the Customize Scheduled Operations window, click **Options** from the menu bar to display the next level of options:
 - To add a scheduled operation, click **Options** and then click **New...**
 - To delete a scheduled operation, select the operation you want to delete, point to **Options** and then click **Delete**.
 - To update the list of scheduled operations with the current schedules for the selected objects, point to **Options** and then click **Refresh**.
 - To view a scheduled operation, select the operation you want to view, point to **View** and then click **Schedule Details...**
 - To change the time of a scheduled operation, select the operation you want to view, point to **View** and then click **New Time Range...**
 - To sort the scheduled operations, point to **Sort** and then click one of the sort categories that appears.
5. To return to the HMC workplace, point to **Operations** and then click **Exit**.

Delete

Use the **Delete** task to delete the selected partition.

The Delete task deletes the selected partition and all of the partition profiles associated with the partition from the managed system. When you delete a partition, all hardware resources currently assigned to that partition become available to other partitions.

Configuration

Configuration contains the tasks for configuring your partitions.

Manage Profiles

Use the **Manage Profiles** task to create, edit, copy, delete, or activate a profile for the selected partition.

A partition profile contains the resource configuration for the partition. You can modify the processor, memory, and adapter assignments for a profile by editing the profile.

The default partition profile for a logical partition is the partition profile that is used to activate the logical partition if no other partition profile is selected. You cannot delete the default partition profile unless you first designate another partition profile as the default partition profile. The default profile is defined in the status column.

Choose **Copy** to create an exact copy of the selected partition profile. This allows you to create multiple partition profiles that are nearly identical to one another by copying a partition profile and changing the copies as needed.

Manage Custom Groups

Groups are comprised of logical collections of objects. You can report status on a group basis, allowing you to monitor your system in a way that you prefer. You can also nest groups (a group contained within a group) to provide hierarchical or topology views.

One or more user-defined groups might already be defined on your HMC. Default groups are listed under **Custom Groups** node under **Server Management**. The default groups are **All Partitions** and **All Objects**. You can create others, delete the ones that were created, add to created groups, create groups using the pattern match method, or delete from created groups by using the **Manage Custom Groups** task.

Use the online Help if you need additional information for working with groups.

Save Current Configuration

Save the current configuration of a logical partition to a new partition profile by entering a new profile name.

This procedure is useful if you change the configuration of a logical partition using dynamic logical partitioning and you do not want to lose the changes when you restart the logical partition. You can perform this procedure at any time after you initially activate a logical partition.

Hardware Information

Display information about the hardware attached to a selected managed system.

Adapters

View information about the Host Ethernet Adapters (HEA, also referred to as Integrated Virtual Ethernet adapters) or Host Channel Adapters (HCA) for a selected managed system.

For more information about HEAs, see Host Ethernet Adapter.

Host Ethernet Adapter (HEA):

A Host Ethernet Adapter (HEA) allows multiple logical partitions to share a single physical Ethernet adapter.

Unlike most other types of I/O devices, you can never assign the HEA itself to a logical partition. Instead, multiple logical partitions can connect directly to the HEA and use the HEA resources. This allows these logical partitions to access external networks through the HEA without having to go through an Ethernet bridge on another logical partition.

Use the **Host Ethernet** task to display or configure the ports of the physical HEAs on a selected managed system.

To configure a physical port on an HEA, select the port from the list and select **Configure**.

Use the online Help for additional information on configuring HEA ports.

Host Channel Adapter (HCA):

Host Channel Adapters (HCAs) provide a managed system with port connections to other InfiniBand devices. That port can be connected to another HCA, a target device, or a switch that redirects the data coming in on one of its ports out to a device attached to another of its ports.

You can show a list of the HCAs for the managed system. You can select an HCA from the list to display the current partition usage for the HCA.

From this task you can display the following:

- The physical location of each HCA on the managed system.
- The number of globally unique identifiers (GUIDs) that are in use on each HCA.
- The number of GUIDs on each HCA that are available to be assigned to logical partitions.
- HMC management status. HCAs that are unable to be managed by an HMC are in an error state.
- The logical partition usage for a selected HCA.

Switch Network Interface:

Use the **Switch Network Interface** task to display a list of the Switch Network Interface (SNI) adapters for the selected managed system.

Displayed is the SNI adapter handle, the name of the partition to the adapter is assigned, the physical location of the adapter, and the host name or IP address of the adapter.

Dynamic Logical Partitioning

Dynamic Logical Partitioning (DLPAR) tasks allow you to dynamically add or remove processors, memory, and adapters to and from logical partitions.

For detailed information about Dynamic Logical Partitioning, see Managing logical partition resources dynamically using the HMC.

Processor

Add or remove processor resources from a logical partition or to move processor resources from one logical partition to another.

Use the **Add or Remove** task to add processor resources to or remove processor resources from the selected logical partition without restarting the logical partition.

Use the **Move** task to move processor resources from the selected logical partition to another logical partition without restarting either logical partition.

Use the online Help for more information on adding, removing, or moving processor resources.

Memory

Add or remove memory resources from a logical partition or to move memory resources from one logical partition to another.

Use the **Add or Remove** task to add memory to or remove memory from the selected logical partition without restarting the logical partition.

Use the **Move** task to move memory from the selected logical partition to another logical partition without restarting either logical partition.

Use the online Help for more information on adding, removing, or moving processor resources.

Physical Adapters

Add I/O slots to a logical partition without restarting the partition or to move or remove I/O slots from a logical partition without restarting the partition.

Use the **Add** task to add I/O slots to a logical partition without restarting the partition. When you add an I/O slot to a logical partition, the I/O adapter in that I/O slot and the devices that are controlled by the I/O adapter can be used by the logical partition. This function is typically used to share infrequently used devices among logical partitions by moving these devices from one logical partition to another.

Use the **Move or Remove** task to remove I/O slots from a logical partition or move I/O slots between logical partitions without restarting the logical partitions. When you remove an I/O slot from a logical partition, the I/O adapter in that I/O slot and the devices that are controlled by the I/O adapter are also removed from the logical partition. If you choose to move the I/O slot to another logical partition, the I/O adapter and the devices that are controlled by the I/O adapter are also moved to the other logical partition. This function is typically used to share infrequently used devices among logical partitions by moving these devices from one logical partition to another.

Vary off the I/O slot and all I/O adapters and devices connected to the I/O slot before you remove the I/O slot from the logical partition.

Virtual Adapter

This task displays a list of all of the virtual adapters that currently exist for this logical partition or partition profile.

Use this task to create, change, or remove a virtual adapter on a logical partition or in a partition profile.

From this task you can:

- Display the properties of a virtual adapter.
- Edit the properties of a virtual adapter.
- Create a new virtual adapter.
- Delete a virtual adapter.

Use the online Help for more information on managing virtual adapters.

Host Ethernet

Use **Host Ethernet** tasks to add Logical Host Ethernet Adapter (LHEA) logical ports dynamically to a running logical partition.

Use the **Add** task to add LHEA logical ports dynamically to a running logical partition. These logical ports allow the logical partition to access and use the physical port resources on a physical HEA.

Some operating system or system software versions do not allow you to add logical ports dynamically. Consult the documentation for the operating system or system software for more information.

To add logical ports dynamically to the logical partition, select the HEA whose resources you want to use, select the physical port for which you want to create a logical port, and click **Configure**. You can then configure the logical port and return to this window. If you change your mind about adding a logical port to the logical partition, select the physical port that corresponds to the logical port and click **Reset**. You can then configure a different logical port for that physical port.

When you are done adding logical ports to the running logical partition, click **OK**.

Use the **Move or Remove** task to move LHEA logical ports dynamically from the selected logical partition.

These logical ports allow the logical partition to access and use the physical port resources on a physical HEA. You can move the logical ports dynamically to another running logical partition, or you can leave the logical ports as unassigned.

Some operating system or system software versions do not allow you to move or remove logical ports dynamically. Consult the documentation for the operating system or system software for more information.

To remove logical ports dynamically from the logical partition, select the HEA whose logical ports you want to remove, select the physical port whose logical ports you want to remove and click **OK**.

To move logical ports dynamically from the logical partition to another running logical partition, select the HEA whose logical ports you want to remove, select the physical port whose logical ports you want to move, select the destination logical partition in Logical Partition, and click **OK**.

Console window

Use the **Open Terminal Window** task to open a terminal window to the operating system running on the selected partition.

Use the **Close Terminal Connection** task to close the connection.

Use the **Open Shared 5250 Console** task to open a shared console with an IBM i partition.

Use the **Open Dedicated 5250 Console** task to open a dedicated console with an IBM i partition.

Serviceability

Problem Analysis on the HMC automatically detects error conditions and reports to you any problem that requires service to repair it.

These problems are reported to you as serviceable events. Use the **Manage Events** task to view specific events for selected systems. However, if you notice a problem occurred or you suspect a problem is affecting the system but Problem Analysis has not reported it to you, use the **Create Serviceable Event** task to report the problem to your service provider.

Manage Serviceable Events

Problems on your managed system are reported to the HMC as serviceable events. You can view the problem, manage problem data, call home the event to your service provider, or repair the problem.

To set the criteria for the serviceable events you to view, do the following:

1. From the tasks pad, open **Manage Serviceable Events**.
2. Provide event criteria, error criteria, and FRU criteria.
3. Click **OK**.
4. If you do not want the results filtered, select **ALL**.

The Serviceable Events Overview window displays all of the events that match your criteria. The information displayed in the compact table view includes the following:

- Problem Number
- PMH Number
- Reference Code - Click on the Reference code to display a description of the problem reported and actions that may be taken to fix the problem.
- Status of the problem
- Last reported time of the problem
- Failing MTMS of the problem

The full table view includes more detailed information, including reporting MTMS, first reported time, and serviceable event text.

Select a serviceable event and use the **Selected** drop down menu to:

- **View event details:** Field-replaceable units (FRUs) associated with this event and their descriptions.
- **Repair the event:** Launch a guided repair procedure, if available.
- **Call home the event:** Report the event to your service provider.
- **Manage event problem data:** View, call home, or offload to media data and logs associated with this event.
- **Close the event:** After the problem is solved, add comments and close the event.

Use the online Help if you need additional information on managing serviceable events.

Reference Code History

Use the **Reference Code History** task to view reference codes that have been generated for the selected logical partition. Reference codes are diagnostic aids that help you determine the source of a hardware or operating system problem.

By default, only the most recent reference codes that the logical partition has generated are displayed. To view more reference codes, enter the number of reference codes that you want to view into **View history** and click **Go**. The window displays that number of the latest reference codes, with the date and time at which each reference code was generated. The window can display up to the maximum number of reference codes stored for the logical partition.

Control Panel Functions

This task displays the available virtual control panel functions for the partition selected. The tasks are:

(21) Activate Dedicated Service Tools

Starts Dedicated Service Tools (DST) on the partition.

(65) Disable Remote Service

Deactivates remote service on the partition.

(66) Enable Remote Service

Activates remote service on the partition.

(67) Disk Unit IOP Reset/Reload

Disk unit IOP reset/reload is enabled only by specific disk unit error conditions.

(68) Concurrent Maintenance Power Off Domain

Concurrent maintenance power domain Power Off.

(69) Concurrent Maintenance Power On Domain

Concurrent maintenance power domain Power On.

(70) IOP Control Storage Dump

This IOP dump function is enabled by specific error conditions.

Systems Management for Frames

Set up, configure, view current status, troubleshoot, and apply solutions for frames.

This section describes the tasks you can perform when you select a frame.

To launch these tasks, see “Launching tasks for managed objects” on page 7. The following sets of tasks are represented in the tasks pad, tasks menu, or context menu. The tasks listed in the tasks pad change as selections are made in the work area. The context is always listed at the top of the tasks pad in the format Task: Object. These tasks are listed when a managed system is selected and the context is Tasks: *Frame Name*.

Properties

Display the selected frame properties.

These properties include the following:

General

The **General** tab displays the frame name and number, state, type, model, and serial number.

Managed Systems

The **Managed Systems** tab displays all of the managed systems contained in the frame and their cage numbers. A cage is a division of the enclosure that holds the managed systems, the I/O units, and the bulk power assemblies (BPAs).

I/O Units

The **I/O Units** tab displays all of the I/O units contained in the frame, their cage numbers, and their assigned managed systems. A cage is a division of the enclosure that holds the managed systems, the I/O units, and the BPAs. If the System column displays **Not owned**, the corresponding I/O unit has not been assigned to a managed system.

Update Password

Use the Update Password task to update HMC access and Advanced System Management Interface (ASMI) passwords on the managed system.

The first time you access a managed system using an HMC, the system prompts you to enter passwords for each of the following:

- Hardware Management Console: HMC access
- Advanced System Management Interface: General
- Advanced System Management Interface: Admin

If you are using an HMC to access the managed system before all required passwords have been set, enter the appropriate password for each password that is presented in the Update Password task.

If another HMC subsequently needs access to this managed system, upon attempting to access this HMC the user is presented with the Update Password Failed Authentication window, which will prompt for the HMC access password you entered.

In the event that the HMC access password changes while you are logged in to the managed system, your HMC will discover that it can no longer authenticate after it attempts to reconnect to that managed system. This will result in a state of *Failed Authentication* for that managed system. You will be required to enter the new password before any actions can be performed.

Operations

Perform tasks on managed frames.

Initialize

Initialize a managed frame.

When you initialize a managed frame, all of the frames managed by the HMC are powered on. As each individual frame is powered on, the I/O units that are contained within the frame are powered on as well. When all the I/O units for the frame have been powered on, then the managed systems that are contained within the frame are powered on. The complete initialization process may take several minutes to complete.

Note: Managed systems that are already powered on will not be affected (meaning they will not be powered off and back on again).

Rebuild

Update frame information on the HMC interface.

Updating, or rebuilding, the frame acts much like a refresh of the frame information. Rebuilding the frame is useful when the system's state indicator in the Work pane of the HMC is shown as *Incomplete*. The *Incomplete* indicator signifies that the HMC cannot gather complete resource information from the managed system within the frame.

No other tasks can be performed on the HMC during this process, which may take several minutes.

Change Password

Change the HMC access password on the selected managed frame.

After the password is changed, you must update the HMC access password for all other HMCs from which you want to access this managed frame.

Enter the current password. Then enter a new password and verify it by entering it again.

Power On/Off IO Unit

Power off an IO unit using the HMC interface.

Only units or slots that reside in a power domain can be powered off. The corresponding power on/off buttons will be disabled for location codes that are not controllable by the HMC.

Configuration

Configuration contains the tasks for configuring your frame. You can manage custom groups using the Configuration task.

Manage Custom Groups

You can report status on a group basis, allowing you to monitor your system in a way that you prefer.

You can also nest groups (a group contained within a group) to provide hierarchical or topology views.

One or more user-defined groups might already be defined on your HMC. Default groups are listed under **Custom Groups** node under **Server Management**. The default groups are **All Partitions** and **All Objects**. You can create others, delete the ones that were created, add to created groups, create groups using the pattern match method, or delete from created groups by using the **Manage Custom Groups** task.

Use the online Help if you need additional information for working with groups.

Connections

Connections tasks allow you to view the HMC connection status to frames or reset those connections.

Bulk Power Assembly (BPA) Status

Use the **Bulk Power Assembly Status** task to view the state of the connection from the Hardware Management Console (HMC) to side A and side B of the bulk power assembly. The HMC will operate normally with a connection to either side A or side B. However, for code update operations and some concurrent maintenance operations, the HMC needs connections to both sides.

The HMC displays the following:

- IP address
- BPA Role
- Connection Status
- Connection Error code

If the status is not Connected, the Connection status may be one of the following:

Starting/Unknown

One of the Bulk Power Assemblies (BPAs) contained in the frame is in the process of starting. The state of the other BPA cannot be determined.

Standby/Standby

Both of the BPAs contained in the frame are in the standby state. A BPA in the standby state is operating normally.

Standby/Starting

One of the BPAs contained in the frame is operating normally (in standby state). The other BPA is in the process of starting.

Standby/Not Available

One of the BPAs contained in the frame is operating normally (in the standby state), but the other BPA is not operating normally.

Pending frame number

A change to the frame number is in progress. No operations can be performed when the frame is in this state.

Failed Authentication

The HMC access password for the frame is not valid. Enter a valid password for the frame.

Pending Authentication - Password Updates Required

The frame access passwords have not been set. You must set the required passwords for the frame, to enable secure authentication and access control from the HMC.

No Connection

The HMC cannot connect to the frame.

Incomplete

The HMC failed to get all of the necessary information from the managed frame. The frame is not responding to requests for information.

Reset

Reset the connection between the HMC and the selected managed frame.

When you reset the connection with a managed frame, the connection is broken and then reconnected. Reset the connection with the managed frame if the managed frame is in a No Connection state and you have verified that the network settings are correct on both the HMC and the managed frame.

Hardware Information

Display information about the hardware attached to a selected managed frame.

View RIO Topology

Display the current RIO topology for the selected managed frame and any discrepancies between the current topology and the last valid topology.

High Speed Link (HSL), also known as Remote I/O (RIO), resources provide the connection between system I/O busses and the system processor. HSL/RIO resources are normally configured in loops with the system unit having an HSL/RIO controller resource that handles routing of the data between the system processor and the system I/O busses. System I/O busses connect to the loop with HSL I/O adapter or RIO adapter resources.

Use this task to display the current RIO topology of the selected managed system. Current Topology displays the current topology. Any discrepancies between the current topology and the last valid topology are identified as errors. The following information is shown:

- The starting location of the physical RIO cable and the RIO connection (cable to port)
- The ending location of the physical RIO cable and the RIO connection (cable to port)
- Starting Node Type Displays the values of the node. Possible values are Local Bridge, Local NIC, Remote Bridge, and Remote NIC
- Link Status Displays the leading port status
- Cable Length Displays the length of the RIO cables. Errors occur when the actual cable lengths are different from the expected cable lengths
- The serial number of the power-controlling managed system
- The serial number of the function-controlling managed system

Serviceability

Problem Analysis on the HMC automatically detects error conditions and reports to you any problem that requires service to repair it. These problems are reported to you as serviceable events. you can view specific events for selected systems and add, remove, or exchange a Field Replaceable Unit (FRU).

Manage Serviceable Events

Problems on your managed frame are reported to the HMC as serviceable events. You can view the problem, manage problem data, call home the event to your service provider, or repair the problem.

To set the criteria for the serviceable events you want to view, do the following:

1. From the tasks pad, open **Manage Serviceable Events**.
2. Provide event criteria, error criteria, and FRU criteria.
3. Click **OK**.
4. If you do not want the results filtered, select **ALL**.

The Serviceable Events Overview window displays all of the events that match your criteria. The information displayed in the compact table view includes the following:

- Problem Number
- PMH Number
- Reference Code - Click on the Reference code to display a description of the problem reported and actions that may be taken to fix the problem.
- Status of the problem
- Last reported time of the problem
- Failing MTMS of the problem

The full table view includes more detailed information, including reporting MTMS, first reported time, and serviceable event text.

Select a serviceable event and do the following:

- **View event details:** FRUs associated with this event and their descriptions.
- **Repair the event:** Launch a guided repair procedure, if available.
- **Call home the event:** Report the event to your service provider.
- **Manage event problem data:** View, call home, or offload to media data and logs associated with this event.
- **Close the event:** After the problem is solved, add comments and close the event.

Use the online Help if you need additional information on managing serviceable events.

Hardware

These tasks are used to add, exchange, or remove hardware from the managed frame. From the hardware tasks you can display a list of installed FRUs or enclosures and their locations. Select a FRU or an enclosure and launch a step-by-step procedure to add, exchange, or remove the unit.

Add FRU:

Use the **Add FRU** task to locate and add a FRU.

To add a FRU, do the following:

1. From the drop down list, select an enclosure type.
2. Select an FRU type.
3. Click **Next**.
4. Select a location code.
5. Add the selected enclosure location to Pending Actions by clicking **Add**.

6. Begin adding the selected FRU type to the enclosure locations identified in Pending Actions by clicking **Launch Procedure**.
7. When you have completed the FRU installation process, click **Finish**.

Add Enclosure:

Use the Add Enclosure task to locate and add an enclosure.

To add an enclosure, do the following:

1. Select an enclosure type, then click **Add** to add the selected enclosure type's location code to Pending Actions.
2. To begin adding the enclosures identified in Pending Actions to the selected system, click **Launch Procedure**.
3. When you have completed the enclosure installation process, click **Finish**.

Exchange FRU:

Exchange one FRU with another.

To exchange a FRU, do the following:

1. Select an installed enclosure type.
2. Select an FRU type.
3. Click **Next**.
4. Select a location code for a specific FRU.
5. Click **Add**.
6. Select **Launch Procedure**.
7. When you have completed the installation, click **Finish**.

Exchange Enclosure:

Exchange one enclosure for another.

To exchange an enclosure, do the following:

1. Select an installed enclosure, then click **Add** to add the selected enclosure's location code to Pending Actions.
2. Begin replacing the enclosures identified in Pending Actions in the selected system by clicking **Launch Procedure**.
3. When you have completed the enclosure replacement process, click **Finish**.

Remove FRU:

Remove a FRU from your managed system.

To remove a FRU, do the following:

1. Select an enclosure from the drop down list.
2. Select an FRU type from the displayed list of FRU types for this enclosure.
3. Click **Next**.
4. Select a location code for a specific FRU.
5. Click **Add**.
6. Select **Launch Procedure**.
7. When you have completed the removal procedure, click **Finish**.

Remove Enclosure:

Remove an enclosure identified by the HMC.

To remove an enclosure, do the following:

1. Select an enclosure type, then click **Add**.
2. Click **Launch Procedure**.
3. When you have completed the enclosure removal process, click **Finish**.

System Plans

Display the tasks used to record or import specifications for logical partitions, partition profiles, or hardware specifications on a chosen system.

To display the tasks available for a system plan, select a system plan from the System Plan work pane table.

View System Plan

Review the detailed information in the selected system plan.

The System Plan Viewer consists of four main areas:

Title pane

Displays basic information about the System Plan Viewer and the application from which you accessed the viewer.

Navigation pane

Provides a navigation tree of the system plan that you are viewing.

Contents pane

Provides the detailed view of the information in the system plan that you are viewing.

Actions pane

Contains action buttons that allow you to work with the system plan.

Use the navigation tree to determine which aspects of the system plan to view. Some levels of the tree can be expanded or collapsed to reveal more entries.

Use the online Help for more information on viewing a system plan.

Create System Plan

This task is used to create a new system plan for a system that this HMC manages. The new system plan contains specifications for the logical partitions and partition profiles of the managed system that you used to create the plan.

The new system plan also can contain hardware information that the HMC is able to obtain from the selected managed system. However, the HMC might not be able to detect all system hardware and partition settings. For example, the HMC is not able to detect the types of disk drives installed on the managed system unless the HMC uses Resource Monitoring and Control (RMC) to monitor resources on the managed system.

To maximize the information that the HMC can obtain from the managed system, power on the managed system and activate the logical partitions on the managed system before creating the new system plan.

When you use the HMC to create a system plan for a managed system, you can capture partition configuration information and a limited amount of associated hardware configuration information. Additionally, you can set up Resource Monitoring and Control (RMC) prior to creating a system plan to capture more detailed information. Although it may cause the creation of the system plan to take several

more minutes to finish processing, by using RMC you can capture disk drive and tape drive configuration information for a managed system in the system plan.

Use the online Help for more information on creating a system plan.

Deploy System Plan

Select the system plan that you want to deploy and the name of the managed system on which you want to deploy the plan.

This task uses the Deploy System Plan wizard to perform the following actions, depending on the contents of the system plan. To learn more about deploying system plans, read the following:

- If the system plan contains logical partition information, you can use the wizard to create the specified logical partitions on the managed system. You can choose to create all the logical partitions specified within the system plan, or you can choose which logical partitions in the system plan that you want to create.
- If the system plan contains operating environment installation information, you can use the wizard to install the operating environment for a specified partition. You can use the wizard to specify the resource location that the wizard needs for installing the operating system environment, as well as to specify or change operating environment installation settings. Currently, the wizard provides support for installing a Virtual I/O Server (VIOS) operating environment only.
- If the system plan contains VIOS provisioning information for a partition, you can use the wizard to provision the partition. The wizard can configure one or more client partitions and provision certain resources for the partitions when the system plan contains this type of provisioning information.

Use the online Help for more information on deploying a system plan.

Export System Plan

This task is used to export a system plan to other systems or other HMCs.

You have three options for exporting the selected system-plan file:

- You can export the system file to the local system on which you are running the browser to access the HMC.
- You can export the system-plan file to removable media that is currently mounted to the HMC, such as optical discs or USB Mass Storage devices.
- You can export the system-plan file to a remote file transfer protocol (FTP) site. Exporting a system-plan file by means of FTP allows you to import the system-plan file into a different HMC. You can then deploy a system plan in the file to a system that the other HMC manages.

Use the online Help for more information on exporting a system plan.

Import System Plan

This task is used to import a system plan to other systems or other HMCs.

You can save this system plan and import the plan on other systems that this HMC manages that have hardware that is identical to the hardware in the system plan. You can import the system plan on another HMC and use it to deploy the system plan to other systems the target HMC manages that have hardware that is identical to the hardware in the system plan.

You can also import a system plan created using the System Planning Tool (SPT) at <http://www.ibm.com/systems/support/tools/systemplanningtool/>. The SPT is available to assist you in system planning, design, validation and to provide a system validation report that reflects your system requirements while not exceeding system recommendations. The SPT is a PC-based browser application designed to be run in a standalone environment. The SPT emulates an LPAR configuration and validates

that the planned partitions are valid. It allows you to test the placement of hardware within the system to ensure that the placement is valid. When you have prepared your partitioning plan using the SPT, you can save this plan in a system plan file. You can import this file into your HMC and deploy the system plan to a managed system that is managed by the HMC. When you deploy the system plan, the HMC creates the logical partitions from the system plan on the managed system.

You can import a system-plan file from one of three sources:

- You can import a system file from the local system on which you are running the browser to access the HMC.
- You can import a system-plan file from removable media that is currently mounted to the HMC, such as optical discs or USB Mass Storage devices.
- You can import a system-plan file from a remote file transfer protocol (FTP) site. Importing a system-plan file by means of FTP allows you to deploy a system plan from a source other than the current HMC.

Use the online Help for more information on importing a system plan.

Remove System Plan

This task is used to permanently remove the specified system plan from the HMC.

Note: Removing the system plan from the HMC does not undo any partition or hardware configuration changes that occurred if the specified system plan was deployed on a managed system.

Use the online Help for more information on removing a system plan.

HMC Management tasks

This chapter alphabetically describes the tasks that are available on the Hardware Management Console (HMC) for the **HMC Management** tasks.

To open these tasks, see “HMC Management” on page 12.

Note: Depending on the task roles assigned to your user ID you may not have access to all the tasks. See Table 3 on page 78 for a listing of the tasks and the user roles allowed to access them.

Back up HMC Data

This task backs up (or archives) the data that is stored on your HMC hard disk that is critical to support HMC operations.

Back up the HMC data after changes have been made to the HMC or information associated with logical partitions.

The HMC data stored on the HMC hard drive can be saved to a DVD-RAM on a local system, a remote system mounted to the HMC file system (such as NFS), or sent to a remote site using File Transfer Protocol (FTP).

Using the HMC, you can back up all important data, such as the following:

- User-preference files
- User information
- HMC platform-configuration files
- HMC log files
- HMC updates through Install Corrective Service.

Note: Use the archived data only in conjunction with a reinstallation of the HMC from the product CDs.

To back up the HMC critical data:

1. Open the **Back up HMC Data** task from the HMC Management work pane.
2. From the **Back up HMC Data** window, choose the archive option you want to perform.
3. Click **Next**, then follow the appropriate instructions depending on the option you chose.
4. Click **OK** to continue with the backup process.

Use the online Help if you need additional information for backing up the HMC data.

Change Date and Time

Change the time and date of the battery-operated HMC clock and add or remove time servers for the Network Time Protocol (NTP) service.

Use this task in the following situations:

- If the battery is replaced in the HMC.
- If your system is physically moved to a different time zone.

Note: The time setting will adjust automatically for daylight saving time in the time zone you select.

To change the date and time, do the following:

1. In the HMC Management work pane, click **Change Date and Time**.
2. Click the **Customize Console Date and Time** tab.
3. Enter the date and time information.
4. Click **OK**.

To change the time server information, do the following:

1. In the HMC Management work pane, click **Change Date and Time**.
2. Click the **NTP Configuration** tab.
3. Provide the appropriate information for the time server.
4. Click **OK**.

If you need additional information for changing the date and time of the HMC or for adding or removing time servers for the Network Time Protocol (NTP) service, use the online Help.

Change Language and Locale

This task sets the language and location for the HMC. After you select a language, you can select a locale associated with that language.

The language and locale settings determine the language, the character set, and other settings specific to the country or region (such as formats for date, time, numbers, and monetary units). Changes made in the **Change Language and Locale** window affect only the language and locale for the HMC itself. If you access the HMC remotely, the language and locale settings on your browser determine the settings that the browser uses to display the HMC interface.

To change the language and locale on the HMC:

1. Open the **Change Language and Locale** task from the HMC Management Work pane.
2. From the **Change Language and Locale** window, choose the applicable language and locale.
3. Click **OK** to apply the change.

Use the online Help if you need additional information for changing the language and locale of the HMC.

Change Network Settings

This task allows you to view the current network information for the HMC and to change network settings.

1. Open the **Change Network Settings** from the HMC Management work pane.
2. From the **Change Network Settings** window, you can work with the following tabs:

Identification

Contains the host name and domain name of the HMC.

Console name

Your HMC user name, the name that identifies your console to other consoles on the network. This is the short host name, for example: hmc1.

Domain name

A name that Domain Name Services (DNS) can translate to the IP address. For example, DNS might translate the domain name www.example.com to 198.105.232.4. (The long host name consists of the console name plus a period plus the domain name, for example: hmc.endicott.yourcompany.com.)

Console description

This is for your use only. An example might be: Main HMC for customer finance.

LAN Adapters

A summarized list of all (visible) Local Area Network (LAN) adapters. You can select any of these and click **Details...** to open a window allowing you to change addressing, routing, other LAN adapter characteristics, and firewall settings.

Name Services

Specify the DNS and domain suffix values for configuring the console network settings.

Routing

Specify the routing information and default gateway information for configuring the console network settings.

The **Gateway address** is the route to all networks. The default gateway address (if defined) informs this HMC where to send data if the target station does not reside on the same subnet as the source. If your machine can reach all stations on the same subnet (usually a building or a sector within a building), but cannot communicate outside the area, it is usually because of an incorrectly configured default gateway.

You can assign a specific LAN to be the **Gateway device** or you can choose “any.”

You can select **Enable ‘routed’** to start the routed daemon, which allows it to run and allows any routing information to be exported from the HMC.

3. Click **OK** when you have completed this task.

Note: Depending on the type of change that you make, the network or console automatically restarts or the console automatically reboots.

Use the online Help to get additional information for customizing the network settings.

Change User Interface Settings

Customize settings that control how the HMC interface appears. You can display or hide certain user interface components and icons, display or hide specific navigation nodes, and determine whether or not to save user interface settings changes.

Note: User interface changes apply to the currently logged on user ID only.

To change user interface settings, do the following:

1. From the HMC Management work pane, click **Change User Interface Settings**. Optionally, you can also open the task by clicking on the logged on user name link displayed in the task bar below the banner. All items are selected in the Change User Interface Settings window by default.
2. Click **Apply** or **OK** for the change to take affect.

3. If you select **Save settings as my defaults at logoff**, any customization done to the following items are saved when the user logs off:
 - Displayed user interface components, such as the banner and tasks pad
 - Displayed navigation and work pane icons
 - Displayed nodes in the navigation pane
 - Table view customization, such as filters, sorts, column sizing, ordering, and visibility settings
4. To restore all of the user interface settings to the original defaults, click **Factory Defaults**.

For additional information for changing the user interface settings, use the online Help.

Change User Password

This task allows you to change your existing password used for logging onto the HMC. A password verifies your user ID and your authority to log in to the console.

To change your password:

1. Open the **Change User Password** task from the HMC Management work pane.
2. From the **Change User Password** window specify your current password, specify a new password you want to use, and respecify the new password to confirm in the fields provided.
3. Click **OK** to proceed with the changes.

Use the online Help if you need additional information for changing your password.

Create Welcome Text

This task allows you to customize the welcome message or to display a warning message that appears on the **Welcome** window before you log onto the HMC. You can use this text to notify users of certain corporate policies or security restrictions applying to the system.

To create a message:

1. Open the **Create Welcome Text** task from the HMC Management work pane.
2. From the **Create Welcome Text** window, enter a message in the input area.
3. Click **OK** to apply the change. The next time you log in to the HMC, your message is displayed.

Use the online Help to get additional information about displaying a message before logging onto the HMC.

Format Media

This task formats a DVD-RAM, diskette, or USB 2.0 Flash Drive Memory Key.

You can use this task to format the following DVD-RAMs:

- Backup/restore
- Service data.

You can format a diskette by supplying a user-specified label.

To format a DVD-RAM, diskette, or USB 2.0 Flash Drive Memory Key, do the following:

1. Open the **Format Media** task from the HMC Management work pane.
2. From the **Format Media** window, select the type of media you want to format, then click **OK**.
3. Make sure your media has been correctly inserted, then click **Format**. The **Format Media** progress window is displayed. When the media is formatted, the **Format Media Completed** window is displayed.
4. Click **OK** and then click **Close** to end the task.

Use the online Help if you need additional information for formatting a DVD-RAM, diskette, or USB 2.0 Flash Drive Memory Key.

KDC Configuration

View the key distribution center (KDC) servers that are used by this HMC for Kerberos remote authentication.

From this task you can do the following:

- View existing KDC servers
- Modify existing KDC server parameters including realm, ticket lifetime, and clock skew
- Add and configure a KDC server on the HMC
- Remove a KDC server
- Import a service key
- Remove a service key

Kerberos is a network authentication protocol designed to provide strong authentication for client/server applications by using secret-key cryptography.

Under Kerberos, a client (generally either a user or a service) sends a request for a ticket to the KDC. The KDC creates a ticket-granting ticket (TGT) for the client, encrypts it using the client's password as the key, and sends the encrypted TGT back to the client. The client then attempts to decrypt the TGT, using its password. If the client successfully decrypts the TGT (i.e., if the client gave the correct password), it keeps the decrypted TGT, which indicates proof of the client's identity.

The tickets have a time availability period. Kerberos requires the clocks of the involved hosts to be synchronized. If the HMC clock is not synchronized with the clock of KDC server, authentication will fail.

A Kerberos realm is an administrative domain, site, or logical network that uses Kerberos remote authentication. Each realm uses a master Kerberos database that is stored on a KDC server and that contains information about the users and services for that realm. A realm might also have one or more slave KDC servers, which store read-only copies of the master Kerberos database for that realm.

To prevent KDC spoofing, the HMC can be configured to use a service key to authenticate to the KDC. Service key files are also known as keytabs. Kerberos verifies the TGT requested was issued by the same KDC that issued the service key file for the HMC. Before you can import a service key file into an HMC, you must generate a service key for the host principal of the HMC client.

Note: For MIT Kerberos V5 *nix distributions, create a service key file by running the `kadmin` utility on a KDC and using the `ktadd` command. Other Kerberos implementations may require a different process to create a service key.

You can import a service key file from one of these sources:

- Removable media that is currently mounted to the HMC, such as optical discs or USB Mass Storage devices. You must use this option locally at the HMC (not remotely), and you must mount the removable media to the HMC before using this option.
- A remote site using secure FTP. You can import a service-key file from any remote site that has SSH installed and running.

To use Kerberos remote authentication for this HMC, complete the following:

- You must enable the Network Time Protocol (NTP) service on the HMC and set the HMC and the KDC servers to synchronize time with the same NTP server. You can enable the NTP service on the HMC by accessing the **“Change Date and Time” on page 52** task under **HMC Management**.

- You must set the user profile of each remote user to use Kerberos remote authentication instead of local authentication. A user that is set to use Kerberos remote authentication will always use Kerberos remote authentication, even when the user logs onto the HMC locally.

Note: You do not need to set all users to use Kerberos remote authentication. You can set some user profiles so that the users can use local authentication only.

- Use of a service key file is optional. Before using a service key file, you must import it into the HMC. If a service key is installed on the HMC, realm names must be equivalent to the network domain name. The following is an example of creating the service key file on a Kerberos server using the `kadmin.local` command assuming the HMC hostname is `hmc1`, the DNS domain is `example.com`, and the Kerberos realm name is `EXAMPLE.COM`:

```
- # kadmin_local kadmin.local: ktadd -k /etc/krb5.keytab host/hmc1.example.com@EXAMPLE.COM
```

Using the Kerberos `ktutil` on the Kerberos server, verify the service key file contents. The output should look like the following:

```
- # ktutil
ktutil: rkt /etc/krb5.keytab
ktutil: l
slot KVNO Principal
-----
1 9 host/hmc1.example.com@EXAMPLE.COM
2 9 host/hmc1.example.com@EXAMPLE.COM
```

- The HMC Kerberos configuration can be modified for SSH (Secure Shell) login without a password using GSSAPI. For remote login without a password through Kerberos to an HMC, configure the HMC to use a service key. Once the configuration is completed use `kinit -f principal` to obtain forwardable credentials on a remote Kerberos client machine. Then issue the following command to log in to the HMC without having to enter a password: `$ ssh -o PreferredAuthentications=gssapi-with-mic user@host`

View KDC Server

Display existing KDC servers on the HMC.

To view existing KDC Servers on your HMC, In the **HMC Management** work pane, click **Configure KDC**. If no servers exist and NTP has not yet been enabled, a warning panel message displays. Enable the NTP service on the HMC and configure a new KDC server as desired.

Modify KDC Server

To modify existing KDC server parameters, do the following:

1. In the **HMC Management** pane, click the **KDC Configuration** task.
2. Select a KDC Server.
3. Select a value to modify:
 - **Realm.** A realm is an authentication administrative domain. Normally, realms always appear in upper case letters. It is good practice to create a realm name that is the same as your DNS domain (in upper case letters). A user belongs to a realm if and only if the user shares a key with the authentication server of that realm. Realm names must be equivalent to the network domain name if a service key file is installed on the HMC.
 - **Ticket Lifetime.** Ticket lifetime sets the lifetime for credentials. The format is an integer number followed by one of **s** seconds, **m** minutes, **h** hours, or **d** days. Enter a Kerberos lifetime string such as `2d4h10m`.
 - **Clock skew.** Clock skew sets the maximum allowable amount of clock skew between the HMC and the KDC server before Kerberos considers messages invalid. The format is an integer number that represents number of seconds.

4. Click **OK**.

Add KDC server

Add a Key Distribution Center (KDC) server to this HMC.

To add a new KDC server, do the following:

1. In the **HMC Management** work pane click **KDC Configuration**.
2. From the **Actions** drop down list, select **Add KDC Server**.
3. Enter the host name or IP address of the KDC server.
4. Enter the KDC server realm.
5. Click **OK**.

To modify the default values for ticket lifetime or clock skew, see “Modify KDC Server” on page 56.

Remove KDC server

Kerberos authentication on the HMC remains enabled until all KDC servers are removed.

To remove a KDC server:

1. Open the **KDC Configuration** task from the **HMC Management** work pane.
2. Select the KDC server from the list.
3. From the **Actions** drop down list, select **Remove KDC Server**.
4. Click **OK**.

Import Service Key

Before you can import a service key file into an HMC, a service key file must first be created on the Kerberos server for the HMC host. The service key file contains the host principal of the HMC client, for example, `host/example.com@EXAMPLE.COM`. In addition to KDC Authentication, the host service key file is used to enable password-less SSH (Secure Shell) login using GSSAPI.

Note: For MIT Kerberos V5 *nix distributions, create a service key file by running the `kadmin` utility on a KDC and using the `ktadd` command. Other Kerberos implementations may require a different process to create a service key.

To import a service key:

1. Open the **KDC Configuration** task from the **HMC Management** work pane.
2. From the **Actions** drop down list, select **Import Service Key**.
3. Select from one of the following:
 - **Local** - The service key must be located on removable media currently mounted on the HMC. You must use this option locally at the HMC (not remotely), and you must mount the removable media to the HMC before using this option. Specify the full path of the service key file on the media.
 - **Remote** - The service key must be located on a remote site available to the HMC via secure FTP. You can import a service key file from any remote site that has SSH (Secure Shell) installed and running. Specify the hostname of the site, a user ID and password for the site, and the full path of the service key file on the remote site.
4. Click **OK**.

Implementation of the service key file will not take effect until the HMC is rebooted. For information on rebooting the HMC, see “Shut Down or Restart” on page 66.

Remove Service Key

To remove the service key from the HMC:

1. Open the **KDC Configuration** task from the **HMC Management** work pane.

2. From the **Actions** drop down list, select **Remove Service Key**.
3. Click **OK**.

You must reboot the HMC after removing the service key. Failure to reboot may cause login errors. For information on rebooting the HMC, see “Shut Down or Restart” on page 66.

Configuring the HMC so that it uses LDAP authentication

Configure your HMC so that it uses LDAP (Lightweight Directory Access Protocol) authentication.

Note: Before you configure the HMC so that it uses LDAP authentication, you must ensure that a working network connection exists between the HMC and the LDAP servers.

To configure your HMC so that it uses LDAP authentication, do the following:

1. In the Navigation area, click **HMC Management**.
2. In the Contents area, click **LDAP Configuration**. The LDAP Server Definition window opens.
3. Select **Enable LDAP**.
4. Define an LDAP server to use for authentication.
5. Define the distinguished name tree, also known as the search base, for the LDAP server.
6. Click **OK**.
7. Next, you must configure each remote user’s profile so that it uses LDAP remote authentication instead of local authentication. To learn more about user profiles and access, see “Manage User Profiles and Access” on page 62.

Launch Guided Setup Wizard

This task uses a wizard to set up your system and HMC.

1. Open the **Launch Guided Setup Wizard** from the HMC Management work pane.
2. From the **Launch Guided Setup Wizard - Welcome** window it is recommended that you have certain prerequisites on hand. Click **Prerequisites** in the **Launch Guided Setup Wizard - Welcome** window for the information. When you have completed that, this wizard takes you through the following tasks required to set up your system and HMC. As you complete each task, click **Next** to proceed.
 - a. Change HMC Date and Time
 - b. Change HMC passwords
 - c. Create additional HMC users
 - d. Configure HMC Network Settings (This task cannot be performed if you are accessing the **Launch Guided Setup Wizard** remotely.)
 - e. Specify contact information
 - f. Configure connectivity information
 - g. Authorize users to use the Electronic Service Agent™ software tool and configure notification of problem events.
3. Click **Finish** when you have completed all the tasks in the wizard.

For more information about installing and configuring your HMC, see Installing and configuring the Hardware Management Console .

Launch Remote Hardware Management Console

This task is used to start a session to another Hardware Management Console (HMC).

Note: You cannot perform this task remotely.

To open another HMC:

1. Open the **Launch Remote Hardware Management Console** task from the HMC Management work pane.

2. From the **Remote Hardware Management Console Addressing Information** window, specify the TCP/IP address or host name of the remote HMC to be contacted.
3. Click **OK** to proceed.

Use the online Help if you need additional information for contacting another HMC.

Lock HMC Screen

This task is used to lock the HMC screen.

Note: You cannot perform this task remotely.

To lock the HMC screen:

1. Open the **Lock HMC Screen** task from the HMC Management work pane. The HMC screen is immediately locked.
2. To unlock the screen and get back to the HMC workplace:
 - a. Press the Enter key
 - b. Specify the password of the user ID you are logged in as

Logoff or Disconnect

End the current user session and log off of the HMC or disconnect while your tasks continue running.

If you disconnect, you can reconnect at a later time to continue working. However, a disconnected session is eventually ended. (This is because disconnected sessions exist only while the HMC application is running. If the HMC is restarted or the console is shut down or rebooted, all session information is lost.) If you log off, this means you no longer need access to the HMC. Logging off the console does not affect the status of the managed systems.

To log off or disconnect from the HMC, do the following:

1. Click **Logoff** from the task bar or click the red **X** in the upper right corner of the workplace. The **Choose to Logoff or Disconnect** window appears.
2. Select whether you want to logoff or disconnect, click **OK** to proceed. After you log off or disconnect, the **Welcome to the HMC** window is displayed.

If you chose to disconnect rather than logoff, when you login again, the **Choose a Disconnected Session** window appears. You can do one of the following:

- Select the disconnected session to continue working (click **Reconnect**)
- Start a new session (click **New Session**)
- Delete a selected session (click **Delete**)
- Cancel from connecting (click **Cancel**)

Note: The number of windows displayed when you reconnect depends on the state of the session when it was disconnected. One of the windows is the main user interface; additional windows are for each task that was running when the session was disconnected.

Manage Certificates

Use this task to manage the certificates used on your HMC. It provides the capability of getting information on the certificates used on the console. This task allows you to create a new certificate for the console, change the property values of the certificate, and work with existing and archived certificates or signing certificates.

All remote browser access to the HMC must use Secure Sockets Layer (SSL) encryption. With SSL encryption required for all remote access to the HMC, a certificate is required to provide the keys for this encryption. The HMC provides a self-signed certificate that allows this encryption to occur.

To manage your certificates:

1. Open the **Manage Certificates** task from the HMC Management work pane.
2. Use the menu bar from the **Manage Certificates** window for the actions you want to take with the certificates:
 - To create a new certificate for the console, click **Create**, then select **New Certificate**. Determine whether your certificate will be self-signed or signed by a Certificate Authority (CA), then click **OK**.
 - To modify the property values of the self-signed certificate, click **Selected**, then select **Modify**. Make the appropriate changes, then click **OK**.
 - To work with existing and archived certificates or signing certificates, click **Advanced**. Then you can choose the following options:
 - Delete existing certificates
 - Work with archived certificates
 - Import certificates
 - View issuer certificates
3. Click **Apply** for all changes to take effect.

Use the online Help if you need additional information for managing your certificates and see “Remote operations” on page 93 for more information on remotely accessing the HMC.

Manage Data Replication

This task enables or disables customized data replication. Customized data replication allows another HMC to obtain customized console data from or send data to this HMC.

The following types of data can be configured:

- Customer information data
 - Administrator information (customer name, address, telephone number, etc.)
 - System information (administrator name, address, telephone of your system)
 - Account information (customer number, enterprise number, sales branch office, etc.)
- Group data
 - All user-defined group definitions.
- Modem configuration data
 - Configure modem for remote support.
- Outbound connectivity data
 - Configure local modem to RSF
 - Enable an internet connection
 - Configure to an external time source.

Note: Customizable console data is accepted from other HMCs only after specific HMCs and their associated allowable customizable data types have been configured.

For more detailed information on customizing console data for data replication, see “Customizable data replication” on page 98.

Use the online Help to get additional information for enabling or disabling customizable data replication.

Managing Install Resources

Add or remove operating environment installation resources for your HMC.

You can use the HMC to deploy a system plan that contains information for installing one or more operating environments on one or more logical partitions. To install an operating environment as part of deploying a system plan, the HMC must be able to access and to use an installation resource for that operating environment.

An operating environment installation resource is the necessary set of installation files for a specific version of an operating environment at a specific release and modification level. The installation resource can be on the local hard drive for the HMC or it can be on a Network Installation Management (NIM) server that the HMC can access.

When you define and create a local installation resource, you must meet the following prerequisites:

- You can define only one local installation resource for a specific operating environment version and modification level. For example, you can define a local installation resource for AIX 5.3 and another for AIX 6.1 but you cannot define two local installation resources for the same AIX version and modification level. This restriction applies to all listed operating environments.
- The HMC must have enough free hard disk space for the necessary set of operating environment installation files. The HMC creates the installation resource in the same local hard drive location that the HMC uses for main store dumps. Consequently, it is recommended that you maintain a certain amount of free hard drive space to avoid potential main store dump problems because main store dumps are necessary to help resolve some types of HMC errors. The typical main store dump averages between 4 to 8 gigabytes (GB), so consider maintaining at least 10 GB of free hard drive space for these dumps when you define and create local installation resources for the HMC.
- You must have the operating environment installation media available to copy to the HMC local hard drive. The type of media that you need varies based on the type of operating environment you want to be able to install. You can use CDs or DVDs as the installation image source for Red Hat and SLES operating environments. However, you can use DVDs only as the installation image source for AIX and Virtual I/O Server operating environments.

When you define a remote NIM server installation resource, you must meet a number of prerequisite conditions to ensure that the HMC can access and use the installation resource:

- The complete set of necessary operating environment installation files must exist on the NIM server within a uniquely named NIM resource group. Note: You can define a remote resource for AIX and Virtual I/O Server operating environments only.
- You can define multiple remote installation resources for a specific operating environment version and modification level, as long as each installation resource is within a different NIM named resource group.
- You must know the fully qualified host name of the NIM server.
- You must know the resource group name that contains the necessary set of operating environment installation files.
- You must set up the HMC to be able to access the NIM server and use the operating environment installation files during system plan deployment. The HMC must be able to run secure shell commands by means of an ssh connection to access the NIM server successfully. Consequently, you must ensure that the HMC can provide an appropriate cryptographic key to the NIM server by completing the following steps:
 1. Open an HMC command prompt and run the following command to generate the RSA keys that the HMC needs for ssh connections and to place the keys in an accessible file in the HMC HOME directory: `ssh-keygen -t rsa -f /home/hscroot/ssh_keys`. This command creates two files: one called `ssh_keys` and one called `ssh_keys.pub` that contain the needed RSA keys. The `ssh_keys` file contains the private key that the HMC needs for establishing an ssh connection and this file needs to remain in the `/home/hscroot` subdirectory; the `ssh_keys.pub` file contains the public key that the NIM server must have to complete the ssh connection with the HMC.
 2. On the remote NIM server, append or copy the content of the `/home/hscroot/ssh_keys.pub` file into the `/.ssh/authorized_keys` file on the NIM server.

Note: Remote clients defined on the NIM server remain in place after installation of the operating environment on a partition for post installation management. The short hostname of the system will identify this remote client.

Each installation resource that you define and create for the HMC is available for selection in the **Customize Operating Environment Install** step of the Deploy System Plan Wizard. If the installation resource that you want to use for a selected partition is not available when you perform this step, you can click **New Install Resource** to open the Manage Install Resources window to define and create a new installation resource. For more information about System Plans, see “System Plans” on page 11.

Manage Task and Resource Roles

Use this task to define and customize user roles.

Note: Predefined roles (default roles) cannot be modified.

A *user role* is a collection of authorizations. A user role can be created to define the set of tasks allowed for a given class of user (*task roles*) or it can be created to define the set of managed objects that are manageable for a user (*managed resource roles*). Once you have defined or customized the user roles you can use the **Manage User Profiles and Access** task to create new users with their own permissions. (See “Manage User Profiles and Access.”)

The predefined managed resource roles include:

- All System Resources

The predefined task roles include:

- hmcservicerep (Service Representative)
- hmcviewer (Viewer)
- hmcoperator (Operator)
- hmcpe (Product Engineer)
- hmcsuperadmin (Super Administrator)

To customize managed resource roles or task roles:

1. Open the **Manage Task and Resource Roles** task from the HMC Management work pane.
2. From the **Manage Task and Resource Roles** window, select either **Managed Resource Roles** or **Task Roles**.
3. To add a role, click **Edit** from the menu bar, then click **Add...** to create a new role.
or
To copy, remove, or modify an existing role, select the object you want to customize, click **Edit** from the menu bar, then click **Copy...**, **Remove**, or **Modify...**
4. Click **Exit** when you have completed the task.

Use the online Help to get additional information for customizing managed resource roles and task roles.

Manage User Profiles and Access

Manage your system users that log on to the HMC. A user profile is a combination of a user ID, server authentication method, permissions, and a text description. Permissions represent the authority levels assigned to the user profile for the objects the user has permission to access.

Users can be authenticated using local authentication on the HMC, by using Kerberos remote authentication, or by using LDAP authentication. For more information on setting up Kerberos authentication on the HMC, see “KDC Configuration” on page 55. For more information about LDAP authentication, see “Configuring the HMC so that it uses LDAP authentication” on page 58.

If you are using local authentication, the user ID and password are used to verify a user’s authorization to log on the HMC. The user ID must start with an alphabetic character and consist of 1 to 32 characters. The password has the following rules:

- Must begin with an alphanumeric character.

- Must contain at least seven characters, however, this limit may be changed by your system administrator.
- The characters should be standard 7-bit ASCII characters.
- Valid characters to use for the password can be: A-Z, a-z, 0-9 and special characters (~ ! @ # \$ % ^ & * () _ + - = { } [] \ : " ; ').

If you are using Kerberos authentication, specify a Kerberos remote user ID.

The user profile includes managed resource roles and task roles that are assigned to the user. The *managed resource roles* assign permissions for a managed object or group of objects and the *task roles* define the access level for a user to perform on a managed object or group of objects. You can choose from a list of available default managed resource roles, task roles, or customized roles created by using the **Manage Task and Resource Roles** task.

See “HMC tasks and user roles and IDs” on page 78 for a listing of all the HMC tasks and the predefined default user IDs that can perform each task.

The default managed resource roles include:

- All System Resources

The default task roles include:

- hmcservicerep (Service Representative)
- hmcviewer (Viewer)
- hmcoperator (Operator)
- hmcpe (Product Engineer)
- hmcsuperadmin (Super Administrator).

To add or customize a user profile, do the following:

1. Open the **Manage User Profiles and Access** task from the HMC Management work pane.
2. From the **User Profiles** window, if you are creating a new user ID, point to **User** on the menu bar and when its menu is displayed, click **Add...** The **Add User** window is displayed.

or

From the **User Profiles** window, if the user ID already exists in the window, select the user ID from the list, and then point to **User** on the menu bar and when its menu is displayed, click **Modify...** The **Modify User** window is displayed.

3. Complete or change the fields in the window, click **OK** when you are done.

Use the online Help if you need additional information for creating, modifying, copying, or removing a user profile.

Manage Users and Tasks

Display the logged on users and the tasks they are running.

1. In the HMC Management work pane, click **Manage Users and Tasks**.
2. In the Manage Users and Tasks window, the following information displays:
 - User you are logged in as
 - Time you logged in
 - Number of tasks running
 - Your access location
 - Information about tasks that are running:
 - Task ID
 - Task name
 - Targets (if any)

– Session ID

3. Choose to log off or disconnect from a session that is currently running by selecting the session from the Users **Logged On** list, then click **Logoff** or **Disconnect**.

Alternately, you can choose to switch to another task or end a task by selecting the task from the **Running Tasks** list, then click **Switch To** or **Terminate**.

4. When you have completed this task, click **Close**.

Open 5250 Console

Use this task to open a 5250 emulator session so you can communicate with an IBM i logical partition.

Note: You cannot perform this task remotely.

To open a 5250 console:

1. Open the **Open 5250 Console** task from the HMC Management work pane. The **5250 Setup** window is displayed.
2. From the **5250 Setup** window, you can configure and start your 5250 emulator.

Open Restricted Shell Terminal

Open a command line session.

Note: You cannot perform this task remotely.

In the HMC Management work pane, click **Open Restricted Shell Terminal**.

From the **Restricted Shell** window you can issue commands remotely through secure shell access to the managed system. This provides consistent results and automates administration of managed systems.

Remote Command Execution

This task is used to enable remote command execution using the ssh facility.

1. Open the **Remote Command Execution** task from the HMC Management work pane.
2. From the **Remote Command Execution** window, select **Enable remote command execution using the ssh facility**.
3. Click **OK**.

See “Remote operations” on page 93 for more information.

Remote Operation

This task is used to allow the HMC to be accessed at a remote workstation through a web browser.

To enable the HMC remote access:

1. Open the **Remote Operation** task from the HMC Management work pane.
2. Select **Enabled** from the Remote Operation drop-down list, then click **OK**. The HMC can be accessed from a remote workstation using a Web browser.

Use the online Help to get additional information for allowing remote access to the HMC.

Remote Virtual Terminal

A Remote Virtual Terminal connection is a terminal connection to a logical partition from another remote HMC. Use this task to enable Remote Virtual Terminal access for remote clients.

1. Open the **Remote Virtual Terminal** task from the HMC Management work pane.
2. From the **Remote Virtual Terminal** window, you can enable this task by selecting **Enable remote virtual terminal connections**.

3. Click **OK** to activate your changes.

Use the online Help to get additional information for enabling a remote terminal connection.

Restore HMC Data

This task is used to select a remote repository for restoring critical backup data for the HMC.

1. Open the **Restore HMC Data** task from the HMC Management work pane.
2. From the **Restore HMC Data** window, you can choose to restore data from a Network File System (NFS) server or a File Transfer Protocol (FTP) server.
3. Click **Next** to proceed or **Cancel** to exit the task without making any changes.

Use the online Help if you need additional information about restoring critical backup data for this HMC.

Save Upgrade Data

This task uses a wizard to save upgrade data to selected media. This data consists of files that were created or customized while running the current software level. Saving this data to selected media is performed prior to an HMC software upgrade.

1. Open the **Save Upgrade Data** task from the HMC Management work pane.
2. From the **Save Upgrade Data** window, this wizard takes you through the steps required for saving your data. Select the type of media you want to save your data to, then click **Next** to proceed through the task windows.
3. Click **Finish** when you have completed the task.

Use the online Help if you need additional information for saving upgrade data.

Schedule Operations

Create a schedule for certain operations to be performed on the HMC itself without operator assistance.

Scheduled operations are helpful for situations where automatic, delayed, or repetitious processing of system operations is necessary. A scheduled operation is started at a specified time, without operator assistance to perform the operation. A schedule can be set for one operation or repeated many times.

For example, you could schedule a backup of important HMC information to DVD to occur once, or set up a repeating schedule.

The **Scheduled Operations** task displays the following information for each operation:

- The processor that is the object of the operation.
- The scheduled date
- The scheduled time
- The operation
- The number of remaining repetitions

From the **Scheduled Operations** window you can:

- Schedule an operation to run at a later time
- Define operations to repeat at regular intervals
- Delete a previously scheduled operation
- View details for a currently scheduled operation
- View scheduled operations within a specified time range
- Sort scheduled operations by date, operation, or managed system

An operation can be scheduled to occur one time or it can be scheduled to be repeated. You will be required to provide the time and date that you want the operation to occur. If the operation is scheduled to be repeated, you will be asked to select:

- The day or days of the week that you want the operation to occur. (optional)
- The interval, or time between each occurrence. (required)
- The total number of repetitions. (required)

The operation that can be scheduled for the HMC is:

Backup Critical Console Data

Schedules an operation to back up the critical console hard disk information for the HMC.

To schedule operations on the HMC, do the following:

1. Open the **Schedule Operations** task from the HMC Management work pane.
2. From the **Schedule Operations** window, click **Options** from the menu bar to display the next level of options:
 - To add a scheduled operation, point to **Options** and then click **New...**
 - To delete a scheduled operation, select the operation you want to delete, point to **Options** and then click **Delete**.
 - To update the list of scheduled operations with the current schedules for the selected objects, point to **Options** and then click **Refresh**.
 - To view a scheduled operation, select the operation you want to view, point to **View** and then click **Schedule Details...**
 - To change the time of a scheduled operation, select the operation you want to view, point to **View** and then click **New Time Range...**
 - To sort the scheduled operations, point to **Sort** and then click one of the sort categories that appears.
3. To return to the HMC workplace, point to **Options** and then click **Exit**.

Use the online Help to get additional information for scheduling an operation.

Shut Down or Restart

This task enables you to shut down (power off the console) or to restart the console.

1. Open the **Shut Down or Restart** task from the HMC Management work pane.
2. From the **Shut Down or Restart** window, you can:
 - Select **Restart the HMC** to automatically restart the HMC once the shut down has occurred.
 - Do not select **Restart the HMC** if you do not want to automatically restart the HMC.
3. Click **OK** to proceed with the shut down, otherwise click **Cancel** to exit the task.

Use the online Help if you need additional information about shutting down or restarting the HMC.

Test Network Connectivity

Display network diagnostic information for the console's TCP/IP connection. Send an echo request to a remote host.

To view information concerning the networking configuration on this HMC, do the following:

1. In the HMC Management work pane, click **Test Network Connectivity**. The Test Network Connectivity window opens.
2. Click the following tabs to view the network information.
 - Ping
 - Interfaces
 - Ethernet Settings
 - Address
 - Routes

- Address Resolution Protocol (ARP)
 - Sockets
 - Transmission Control Protocol (TCP)
 - User Datagram Protocol (UDP)
 - Internet Protocol (IP)
3. Click **Cancel** when you have completed this task.

Use the online Help to get additional information on your console's network information.

Tip of the Day

View information about using the HMC. When you enable this feature, a different fact or tip is displayed each time you log in.

The Tip of the Day window opens as long as **Show tips each time you log on** is selected on the window. You can also look at additional information by clicking **Previous Tip** or **Next Tip**.

To prevent this window from displaying each time you log in, you can deselect **Show tips each time you log on**, then click **Close**.

To access this task at any time, do the following:

1. In the HMC Management work pane, click **Tip of the Day**.
2. Select options as previously specified.
3. To save the changes or exit the task, click **Close**.

View HMC Events

View a record of system events occurring on the HMC. System events are individual activities that indicate when processes occur, begin and end, succeed or fail.

To view HMC events, do the following:

1. In the HMC Management work pane, click **View HMC Events**. Use the menu bar to change to a different time range, or to change how the events display in the summary. You can also use the table icons or the **Select Action** menu on the table toolbar to display different variations of the table.
2. When you are done viewing the events, select **View** on the menu bar, then click **Exit**.

Use the online Help for additional information about viewing HMC events.

View Licenses

View the Licensed Internal Code (LIC) that you have agreed to for this HMC.

You can view licenses at any time. To view licenses, do the following:

1. In the HMC Management work pane, click **View Licenses**.
2. Click on any of the license links to view more information.

Note: This list does not include programs and code provided under separate license agreements.

3. Click **OK**.

View Network Topology

Display a tree view of the network nodes known to this Hardware Management Console. Examples of such nodes are managed systems, logical partitions, storage, and other Hardware Management Consoles.

To view the network topology, do the following:

1. In the HMC Management work pane, click **View Network Topology**.

2. Do the following:
 - View attributes of a node by selecting the node in the tree view that is shown in the left pane. Attributes vary according to the type of node. Some examples are IP address, host name, location code, and status. Click **Refresh** to rediscover the topology and to query the nodes again for status and other attributes.
 - Save a snapshot of the current topology (select an item in the **Current Topology**, then click **Save**) and view it in the saved reference topology. You can view attributes of a node in the saved topology by selecting the node in the tree view that is shown in the left pane under **Saved Topology**.
 - Test network connectivity to a node by selecting the node in either the current or the saved topology views and clicking **Ping Current Node** or **Ping Saved Node**, available only for nodes that include an IP address or a host name.
3. When you have completed this task, click **Close**.

Use the online Help if you need additional information for viewing the network topology of the HMC.

Service Management tasks

This chapter alphabetically describes the tasks that are available on the HMC for the **Service Management** tasks.

To open these tasks, see “Service Management” on page 12.

Note: Depending on the task roles assigned to your user ID you may not have access to all the tasks. See Table 3 on page 78 for a listing of the tasks and the user roles allowed to access them.

Create Serviceable Event

This task reports problems that occurred on your Hardware Management Console to the service provider (for example, the mouse does not work) or lets you test problem reporting.

Submitting a problem is dependent upon whether you have customized this Hardware Management Console to use the Remote Support Facility (RSF) and if it is authorized to automatically call for service. If so, the problem information and service request is sent to the service provider automatically with a modem transmission.

To report a problem on your Hardware Management Console, do the following:

1. Open the **Create Serviceable Event** task from the tasks pad.
2. From the **Report a Problem** window, select a problem type from the list displayed.
3. Enter a brief description of your problem in the **Problem Description** input field and then click **Request Service**.

or

To test problem reporting from the **Report a Problem** window:

1. Select **Test automatic problem reporting** and enter *This is just a test* in the **Problem Description** input field.
2. Click **Request Service**. The problems are reported to the service provider for the Hardware Management Console. Reporting a problem sends to the service provider the information you provide on **Report a Problem** window, and machine information that identifies the console.

Use the online Help if you need additional information for reporting a problem or testing if problem reporting works.

Manage Serviceable Events

This task allows you to select the criteria for the set of serviceable events you want to view. When you finish selecting the criteria, you can view the serviceable events that match your specified criteria.

To set the criteria for the serviceable events you to view:

1. Open the **Manage Serviceable Events** task from the Service Management work pane.
2. From the **Manage Serviceable Events** window, provide event criteria, error criteria, and FRU criteria.
3. Click **OK** when you have specified the criteria you want for the serviceable events you want to view.

Use the online Help if you need additional information managing events.

Load Serviceable Events

This task allows you to load or reload serviceable events from an XML file.

To load serviceable events, do the following

1. Open the **Load Serviceable Events** task from the Service Management work pane.
2. From the **Load Serviceable Events** window, specify the path and name of the XML file.
3. Click **press for update** to proceed.

Manage Remote Connections

This task enables you to manage remote connections.

Note: The HMC's call-home server service must be enabled for you to use this task. (See "Manage Systems Call-Home" on page 71 for more information.)

The HMC manages remote connections automatically. It puts requests on a queue and processes them in the order in which they are received. However, this task allows you to manage the queue manually, if necessary. You can stop transmissions, move priority requests ahead of others, or delete requests.

To manage remote connections, do the following:

1. Open the **Manage Remote Connections** task from the Service Management work pane.
2. From the **Manage Remote Connections** window, a list of transmitting requests being and a list of waiting requests transmitted are displayed. You can select requests from either list and display the available options by clicking **Options** on the menu bar. The options permit you to:
 - Prioritize a selected request (move it to the top of the queue)
 - Cancel selected requests
 - Cancel all active requests (those being transmitted)
 - Cancel all waiting requests
 - Hold the queue (puts queue on hold after completing current active request)
 - Release the queue
 - Close the window and exit

Use the online Help if you need additional information for manually managing remote connections.

Manage Remote Support Requests

This task views or manages call-home requests that the console has submitted.

1. Open the **Manage Remote Support Requests** task from the Service Management work pane.
2. From the **Manage Remote Support Requests** window, a list of active requests and a list of waiting requests are displayed. You can select requests from either list and display the available options by clicking **Options** on the menu bar. The options permit you to:
 - View all call-home servers
 - Cancel selected requests

- Cancel all active requests
- Cancel all waiting requests
- Close the window and exit

Use the online Help if you need additional information for manually managing remote connections.

Format Media

This task formats a DVD-RAM, diskette, or USB 2.0 Flash Drive Memory Key.

You can use this task to format the following DVD-RAMs:

- Backup/restore
- Service data.

You can format a diskette by supplying a user-specified label.

To format a DVD-RAM, diskette, or USB 2.0 Flash Drive Memory Key, do the following:

1. Open the **Format Media** task from the HMC Management work pane.
2. From the **Format Media** window, select the type of media you want to format, then click **OK**.
3. Make sure your media has been correctly inserted, then click **Format**. The **Format Media** progress window is displayed. When the media is formatted, the **Format Media Completed** window is displayed.
4. Click **OK** and then click **Close** to end the task.

Use the online Help if you need additional information for formatting a DVD-RAM, diskette, or USB 2.0 Flash Drive Memory Key.

Manage Dumps

This task manages procedures for dumps of the selected system.

To manage a dump, do the following:

1. Open the **Manage Dumps** task from the Service Management work pane.
2. From the **Manage Dumps** window, select a dump and perform one of the following dump-related tasks:

From **Selected** on the menu bar:

- Copy the dump to media.
- Copy the dump to a remote system.
- Use the call home feature to transmit the dump to your service provider.
- Delete a dump.

From **Actions** on the menu bar:

- Initiate a dump of the hardware and server firmware for the managed system.
- Initiate a dump of the service processor.
- Initiate a dump of the Bulk Power Control service processor.
- Modify the dump capability parameters for a dump type.

From **Status** on the menu bar, you can view the offload progress of the dump.

3. Click **OK** when you have completed this task.

Use the online Help to get additional information for managing dumps.

Transmit Service Information

Transmit service information so that it can be used for problem determination.

To transmit service information, do the following:

1. In the Service Management work pane, click **Transmit Service Information**.
2. Click one of the following tabs:
 - **Transmit**. Use this page to schedule when to transmit service data to your service provider (specifying frequency in days and time of day) and how you want to transmit the service and performance management information.
 - **FTP**. Use this page to configure the File Transfer Protocol (FTP) information for the FTP server, with or without a firewall, for off loading service information. This service information is extended error data consisting of problem related-data about problems opened on the HMC for the HMC or managed system.
 - **Transmit Service Data to IBM**. Use this page to provide the ability to send information that is stored on the HMC hard disk that can be used for problem determination. The data may be traces, logs, or dumps and the destination for the data may be the IBM Service Support System, a diskette, USB flash memory drive, or a DVD-RAM. Before you can send information to the IBM Service Support System, Phone Server and Remote Service must be enabled. To enable remote service, see "Remote Operation" on page 64. To enable telephone server, see "Manage Outbound Connectivity."
3. Click **OK**.

Use the online Help for additional information about transmitting service information.

Manage Systems Call-Home

This task allows you enable or disable the call-home state for managed systems.

Note: If Customizable Data Replication is **Enabled** on this HMC (using the **Manage Data Replication** task), the data specified in this task may change depending on automatic replication from other HMCs configured on your network. For more information on data replication, see "Manage Data Replication" on page 60.

By enabling the call-home state for a managed system this causes the console to automatically contact a service center when a serviceable event occurs. When a managed system is disabled, your service representative is not informed of serviceable events.

To manage call-home for the system(s):

1. Open the **Manage Systems Call-Home** task from the Service Management work pane.
2. From the **Manage Systems Call-Home** window, select a system or systems you want to enable or disable the call-home state.
3. Click **OK** when you have completed the task.

Use the online Help if you need additional information for managing serviceable events notification.

Manage Outbound Connectivity

Customize the means for outbound connectivity for the HMC to use to connect to remote service.

Note: If Customizable Data Replication is **Enabled** on this HMC (using the **Manage Data Replication** task), the data specified in this task may change depending on automatic replication from other HMCs configured on your network. For more information on data replication, see "Manage Data Replication" on page 60.

You can configure this HMC to attempt connections through the local modem, Internet, Internet Virtual Private Network (VPN), or through a remote pass-through system. Remote service is a two-way communication between the HMC and the IBM Service Support System for the purpose of conducting automated service operations. The connection can only be initiated by the HMC. IBM Service Support System cannot and never attempts to initiate a connection to the HMC.

To customize your connectivity information, do the following:

1. Open the **Manage Outbound Connectivity** task from the Service Management work pane.
2. From the **Manage Outbound Connectivity** window select **Enable local server as call-home server** (a check mark appears) before proceeding with the task.

Note: You must first **Accept** the terms described about the information you provided in this task. This allows the local HMC to connect to your service provider's remote support facility for call-home requests.

3. The dial information window displays the following tabs for providing input:
 - Local Modem
 - Internet
 - Internet VPN
 - Pass-Through Systems
4. If you want to allow connectivity over a modem, use the **Local Modem** tab, then select **Allow local modem dialing for service**.
 - a. If your location requires a prefix to be dialed in order to reach an outside line, click **Modern Configuration...** and enter the **Dial prefix** in the **Customize Modem Settings** window required by your location. Click **OK** to accept the setting.
 - b. Click **Add...** from the **Local Modem** tab page to add a telephone number. When local modem dialing is allowed, there must be at least one telephone number configured.
5. If you want to allow connectivity over the Internet, use the **Internet** tab, then select **Allow an existing internet connection for service**.
6. If you want to configure the use of a VPN over an existing Internet connection to connect from the local HMC to your service provider's remote support facility, use the **Internet VPN** tab.
7. If you want to allow the HMC to use the pass-through systems as configured by the TCP/IP address or host name, use the **Pass-Through Systems** tab.
8. When you complete all the necessary fields, click **OK** to save your changes.

Use the online Help if you need additional information for customizing outbound connectivity information.

Manage Inbound Connectivity

This task allows your service provider to temporarily access your local console, such as the HMC, or the partitions of a managed system.

To manage inbound connectivity, do the following:

1. Open the **Manage Inbound Connectivity** task from the Service Management work pane.
2. From the **Customize Inbound Connectivity** Settings window:
 - Use the **Remote Service** tab to provide the information necessary to start an attended remote service session.
 - Use the **Call Answer** tab to provide the information necessary to accept incoming calls from your service provider to start an unattended remote service session.
3. Click **OK** to proceed with your selections.

Use the online Help if you need additional information on managing the inbound connectivity.

Manage Customer Information

This task enables you to customize the customer information for the HMC.

Note: If Customizable Data Replication is *Enabled* on this HMC (using the **Manage Data Replication** task), the data specified in this task may change depending on automatic replication from other HMCs configured on your network. For more information on data replication, see “Manage Data Replication” on page 60.

The **Manage Customer Information** window displays the following tabs for providing input:

- Administrator
- System
- Account

To customize your customer information, do the following:

1. Open the **Manage Customer Information** task from the Service Management work pane.
2. From the **Manage Customer Information** window, provide the appropriate information on the **Administrator** page.

Note: Information is required for fields with an asterisk (*).

3. Select the **System** and **Account** tabs from the **Manage Customer Information** window to provide additional information.
4. Click **OK** when you have completed the task.

Use the online Help to get additional information about customizing your account information.

Authorize User

Request authorization for Electronic Service Agent. Electronic Service Agent associates your system with a user ID and allows access to system information through the Electronic Service Agent facility. This registration is also used by your operating system to automate service processes for your AIX or IBM i operation system.

To register a user ID, do the following:

1. In the Service Management work pane, click **Authorize User**.
2. Provide a user ID that is registered with the Electronic Service Agent. If you need a user ID, you can register at the IBM Registration website, <https://www.ibm.com/account/profile>.
3. Click **OK**.

Use the online Help if you need additional information for registering a customer user ID with the eService web site.

Manage Serviceable Event Notification

This task adds email addresses that notify you when problem events occur on your system and configures how you want to receive notification of system events from the Electronic Service Agent.

To set up notification:

1. Open the **Manage Serviceable Event Notification** task from the Service Management work pane.
2. From the **Manage Serviceable Event Notification** window, you can do the following:
 - Use the **Email** tab to add the email addresses that will be notified when problem events occur on your system.
 - Use the **SNMP Trap Configuration** tab to specify locations for sending Simple Network Management Protocol (SNMP) trap messages for Hardware Management Console application program interface events.
3. Click **OK** when you have completed this task.

Use the online Help if you need additional information for managing serviceable events notification.

Manage Connection Monitoring

This task configures the timers that connection monitoring uses to detect outages and enables or disables connection monitoring for selected machines.

You can view and, if authorized, change connection monitoring settings by machine. Connection monitoring generates serviceable events when communication problems are detected between the HMC and managed systems. If you disable connection monitoring, no serviceable events are generated for networking problems between the selected machine and this HMC.

To monitor the connections, do the following:

1. Open the **Manage Connection Monitoring** task from the Service Management work pane.
2. From the **Manage Connection Monitoring** window, adjust the timer settings, if required, and enable or disable the server.
3. Click **OK** when you have completed the task.

Use the online Help if you need additional information about connection monitoring.

Manage POWER4 Service Agent

This task enables or disables the Electronic Service Agent Connection Manager function and specifies the port location for the connection. Electronic Service Agent Connection Manager allows POWER4™ systems to use Electronic Service Agent to call home to transmit service and system information to IBM by specifying the port used for connectivity for a single, secure connection.

To manage POWER4 Service Agent, do the following:

1. Open the **Manage POWER4 Service Agent** task from the Service Management work pane.
2. From the **Manage POWER4 Service Agent** window, select **Enable Service Agent Connection Manager** (a check mark appears), then provide the connectivity features for the HMC.
3. Click **OK** when you have supplied the necessary information.

Use the online Help if you need additional information for enabling or disabling Electronic Service Agent.

Call-Home Setup Wizard

Learn how to open the Call-Home Setup wizard using the HMC interface.

To open the Call-Home Setup wizard, do the following:

1. In the navigation area, select **Service Management**.
2. In the contents area, select **Call-Home Setup Wizard**. The Connectivity and Call-Home Servers wizard opens. Follow the instructions in the wizard to configure call-home.

Updates

Display tasks to manage Licensed Internal Code (LIC) on your HMC, managed system, power subsystem, or I/O adapters.

Use the **Update HMC** button to update Licensed Internal Code on the HMC. Before updating LIC on the HMC, see “Update HMC” on page 75.

Other tasks are used to update managed system, power subsystem, and I/O adapter LIC. To launch these tasks, see “Launching tasks for managed objects” on page 7. The following sets of tasks are represented in the tasks pad, tasks menu, or context menu. The tasks listed in the tasks pad change as selections are made in the work area. The context is always listed at the top of the tasks pad in the format Task: Object.

To display the tasks, do the following:

1. Select the **Updates** node in the navigation pane.
2. Select a managed object to apply updates on.
3. From the tasks pad, click on the task you want to perform.

Update HMC

Identify HMC version, release, service and build levels.

When you click **Updates**, the HMC displays the following information:

- Version
- Release
- Service Pack
- Build Level
- Base Version
- Serial Number of the HMC
- Bios Version on the HMC

For more information about updating your HMC code, see *Updating, upgrading, and migrating your HMC machine code*.

Managed System Updates

When a managed system is selected, Updates tasks perform a guided update of managed system, power subsystem, or I/O Licensed Internal Code.

Licensed Internal Code (LIC) can be changed in two ways. You can upgrade the LIC installed on a managed system to a new release, or update the existing LIC running on the system.

An update of a current LIC release may fix problems or add additional function. Updating LIC may or may not be a disruptive process. Updates that do not disrupt the system are called concurrent updates. To update the LIC currently installed on the managed system, click **Change Licensed Internal Code for the current release** task.

A new release of LIC may add support for new hardware or add new function. Upgrading LIC to a new release is *always a disruptive process* requiring a complete shut down, power off, and restart of the system. To upgrade LIC to a new release, click **Upgrade Licensed Internal Code to a new release**.

Concurrent updates allow the system and the applications running on the system to continue to run as the LIC update is applied. This appreciably lessens the system downtime associated with LIC maintenance. Most updates released will be concurrent. However, certain types of problems are critical to fix and can be fixed only with a disruptive update. **View system information** allows you to view the levels of LIC available in a repository and determine which of the available updates are concurrent and which are disruptive.

If the update is disruptive, you are given the option of installing and activating (incurring the disruption) or deferring the activation to a more convenient time. Concurrent updates can only be done for managed system LIC.

Note: Checking is done before LIC update to assure that the system is in the correct state for an update. The state of the system must not change during a code update. For example, partitions should not be shut down during an LIC update.

New releases of LIC (upgrades) and updates to these releases are available from the following repositories:

- IBM service web site

- IBM support system
- DVD - a DVD can be ordered from IBM or a DVD may be created that contains downloaded LIC
- FTP site - a site accessible to your HMC by FTP that contains a previously downloaded level of LIC
- HMC hard drive - LIC may be downloaded directly to the HMC's hard drive or the hard drive may contain a previously downloaded level of LIC

Fixes and upgrades to LIC can be ordered or downloaded from the Fix Central web site at <http://www.ibm.com/eserver/support/fixes/fixcentral>.

Use the **Flash Side Selection** task to select which flash side will be active after the next activation. (This task is intended for service user mode only.)

Use the **Check system readiness** task to check that all systems selected are in the correct state for LIC update.

Choose the **View system information** task to view the level of LIC currently installed on your managed system or I/O. When a repository is selected, **View system information** also displays retrievable levels of LIC available in the repository.

Change Licensed Internal Code for the current release

Use this task to apply updates to the currently installed Licensed Internal Code (LIC) on your system.

This task requires access to a service repository, either a remote location, the HMC hard drive, or a DVD drive.

LIC updates can be downloaded directly from IBM's service web site or IBM's support system during the update process.

If you have completed a code update from a repository to one of your managed systems or power subsystems, that code is available in the Hard Drive repository on the HMC for installation on other systems. You can select **Hard Drive** to update other managed systems or power subsystems with the same code.

LIC updates can also be downloaded and written to a DVD or to another system available to your HMC using FTP. You can select DVD drive or FTP site to install the LIC update from these locations.

Multiple managed systems can be updated simultaneously by selecting them from the target list.

Files are selectively downloaded to the HMC to apply LIC updates. From this task, you can:

- View current levels of Licensed Internal Code on a managed system, power subsystem, or I/O.
- View retrievable levels of Licensed Internal Code in a repository.
- Install and activate LIC updates (update to a new level of LIC).
- Remove and activate LIC updates (downgrade to a previous level of LIC).

Select **Start Change Licensed Internal Code wizard** to perform a guided update of managed system, power, and I/O Licensed Internal Code (LIC), do the following:

1. A **System readiness check** is automatically performed to check that the system is in the right state for LIC update. If the readiness check fails, actions needed to correct the problems preventing the update are reported to you.
2. Choose a repository from which to update your system. You can update from IBM's service web site, IBM's support system, or, if you have already downloaded an update to the HMC, an FTP site, or a DVD and if you want to update from those locations, choose that option.
3. If you choose **FTP site**, you are prompted for a user ID, password, and the directory in which the update is located.

4. Select the type of update to install, **Managed system and Power LIC** or **I/O LIC**. If there are no LIC updates available in the repository for the type of update chosen, no prompts for installation occur.
5. Confirm that the update as displayed is the correct update. Displayed is the chosen repository, the target or targets of the update, the concurrency status of the target (disruptive or concurrent), and the type of installation. To change the update, select **Advanced Options**.
6. If no changes are desired, continue with the update. Accept the license agreement.
7. Confirm the update.
8. A progress window displays until the update completes.

Select **View system information** to examine current LIC levels on a managed system, power subsystem, or I/O, including levels retrievable from a repository.

Select **Advanced features** to update managed system and power LIC with more options and additional targeting choices.

Upgrade Licensed Internal Code to a new release

A new release level of Licensed Internal Code (LIC) supports major new function such as the introduction of new hardware models and significant function or features enabled by firmware. In addition to the new function and hardware support, new release levels also contain fixes. Upgrading from one release level to another is disruptive to system operations.

Release levels can be skipped. You can upgrade from release level A to release level D without having to install release level B and C. New release levels of LIC are installed with this task.

To install a new release of Licensed Internal Code, do the following:

1. When you select **Upgrade Licensed Internal Code to a new release**, a readiness check is performed on the system before the task progresses. If the readiness check fails, actions needed to correct the problems preventing the upgrade will be reported to you.
2. Choose a repository from which to upgrade your system. You may upgrade from IBM's service web site, IBM's support system, or, if you have already downloaded an upgrade to the HMC, an FTP site, or a DVD and want to upgrade from those locations, choose that option.
3. Select the desired LIC update, managed system or power subsystem. Once verification of the repository content and targeted systems completes, the license agreement panel displays.
4. Select **Accept** on the license agreement panel, and the confirmation panel displays.
5. If any actions are listed at the bottom of the confirmation panel, complete them, and then click **OK** to confirm that the upgrade should begin. A progress panel displays the results as the upgrade proceeds. At the end of the process, the new release level of LIC will be installed on both the t-side (temporary side) and the p-side (permanent side).

Flash Side Selection

Select which flash side will be active after the next activation.

Note: This task is intended for Service User mode only.

Attention: If you select p-side for the next activation, this action disables concurrent Licensed Internal Code (LIC) update.

The flash side is the nonvolatile storage location in the flexible service processor (FSP), divided into t-side (temporary side) and p-side (permanent side), allowing for storing two levels of code. When the p-side is selected, concurrent LIC update is disabled.

Check system readiness

Use this task to confirm that the managed system is in the correct state to perform a Licensed Internal Code update or upgrade successfully.

Before updating or upgrading Licensed internal code, all managed systems to be updated must be in Operating, Standby, Power Off, or Recovery state. All flexible service processors (FSP) for the managed system must be correctly connected to the HMC. Any problems found during the check will be reported to you to correct before updating LIC. A readiness check will automatically be performed before any update or upgrade begins.

View system information

Examine current LIC levels on the managed system, including installed, activated, and accepted levels. If a repository is selected, this task also displays retrievable levels available in a repository.

The **Installed** level of LIC is the level that will be activated and loaded into memory at the next system restart. The **Activated** level of LIC is the level that is activated and loaded into memory at this time. The **Accepted** level of LIC is a committed level of LIC that can be returned to, if necessary. This is the level of code on the p-side (permanent side). The **Unactivated Deferred** level of LIC is the latest unactivated level that contains deferred updates. A deferred update requires a system restart to activate.

Concurrent LIC update status indicates whether concurrent LIC update is enabled or disabled. A concurrent update can be installed and activated without rebooting any partitions or disrupting applications.

Reason for disablement indicates why concurrent LIC update is disabled. This might include the following:

- The permanent side is active
- A temporary LIC level is active

A concurrent LIC update can be installed and activated without rebooting partitions or disrupting applications.

HMC tasks and user roles and IDs

This appendix lists the tasks you can perform using the Hardware Management Console (HMC) and the user roles and IDs that are associated with that task.

You can, however, create customized user profiles that allow you to have unique user IDs and multiple user roles. The management of these user roles is performed by using the **Manage Task and Resource Roles** task. The **Manage User Profiles and Access** task provides the ability to define which user role is associated with each specific user ID.

Table 3 alphabetically lists the HMC Management and Service Management tasks and the corresponding user roles and IDs that can perform these tasks.

Table 4 on page 83 lists the Systems Management tasks that can be performed on managed objects and the corresponding user roles that can perform these tasks.

Table 3. HMC Management tasks, commands, and default user roles

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Back up HMC Data "Back up HMC Data" on page 51 bkconsdata	X	X		X

Table 3. HMC Management tasks, commands, and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Change Date and Time “Change Date and Time” on page 52 chhmc lshmc	X	X		X
Change Language and Locale “Change Language and Locale” on page 52 chhmc lshmc	X	X	X	X
Change Network Settings “Change Network Settings” on page 52 chhmc lshmc	X	X		X
Change User Interface Settings “Change User Interface Settings” on page 53	X	X	X	X
Change User Password “Change User Password” on page 54 chhmcusr	X	X	X	X
Configure KDC “KDC Configuration” on page 55 chhmc		X		
View KDC Server “View KDC Server” on page 56 lshmc		X		
Modify KDC Server “Modify KDC Server” on page 56 chhmc		X		

Table 3. HMC Management tasks, commands, and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Add KDC Server “Add KDC server” on page 57 chhmc		X		
Remove KDC Server “Remove KDC server” on page 57 chhmc		X		
Configure LDAP “Configuring the HMC so that it uses LDAP authentication” on page 58 lshmldap		X		
Create Welcome Text “Create Welcome Text” on page 54 chusrta	X	X		
Launch Guided Setup Wizard “Launch Guided Setup Wizard” on page 58		X		
Launch Remote Hardware Management Console “Launch Remote Hardware Management Console” on page 58	X	X	X	X
Lock HMC Screen “Lock HMC Screen” on page 59	X	X	X	X
Logoff or Disconnect “Logoff or Disconnect” on page 59	X	X	X	X
Manage Certificates “Manage Certificates” on page 59		X		
Manage Data Replication “Manage Data Replication” on page 60	X	X		

Table 3. HMC Management tasks, commands, and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Manage Install Resources “Managing Install Resources” on page 60				
Manage Task and Resource Roles “Manage Task and Resource Roles” on page 62 chaccfg lssacfg mkaccfg rmaccfg		X		
Manage User Profiles and Access “Manage User Profiles and Access” on page 62 chhmcusr lshmcusr mkhmcusr rmhmcusr		X		
Manage Users and Tasks “Manage Users and Tasks” on page 63	X	X	X	X
Open 5250 Console “Open 5250 Console” on page 64	X	X		X
Open Restricted Shell Terminal “Open Restricted Shell Terminal” on page 64	X	X	X	X
Remote Command Execution “Remote Command Execution” on page 64	X	X		X
Remote Operation “Remote Operation” on page 64	X	X	X	X

Table 3. HMC Management tasks, commands, and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Remote Virtual Terminal “Remote Virtual Terminal” on page 64	X	X		X
Restore HMC Data “Restore HMC Data” on page 65	X	X		X
Save Upgrade Data “Save Upgrade Data” on page 65 rstupgdata saveupgdata	X	X		X
Schedule Operations “Schedule Operations” on page 65	X	X		
Shut Down or Restart “Shut Down or Restart” on page 66 hmcshutdown	X	X		X
Test Network Connectivity “Test Network Connectivity” on page 66 ping	X	X	X	X
Display Tip of the Day “Tip of the Day” on page 67	X	X	X	X
View HMC Events “View HMC Events” on page 67 lssvcevents	X	X		X
View Licenses “View Licenses” on page 67	X	X	X	X
View Network Topology “View Network Topology” on page 67	X	X	X	X

Table 4. Service Management tasks, commands, and default user roles

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Create Serviceable Event "Create Serviceable Event" on page 68		X		X
Manage Serviceable Events "Manage Serviceable Events" on page 69		X		X
Load Serviceable Events "Load Serviceable Events" on page 69	X	X	X	X
Manage Remote Connections "Manage Remote Connections" on page 69	X	X		X
Manage Remote Support Requests "Manage Remote Support Requests" on page 69	X	X	X	X
Format Media "Format Media" on page 54	X	X		X
Manage Dumps "Manage Dumps" on page 70 dump cpdump getdump lsdump startdump	X	X		X
Transmit Service Information "Transmit Service Information" on page 70 chsacfg lssacfg	X	X		
Manage Systems Call-Home "Manage Systems Call-Home" on page 71	X	X		X
Manage Outbound Connectivity "Manage Outbound Connectivity" on page 71	X	X		X

Table 4. Service Management tasks, commands, and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles and IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Manage Inbound Connectivity “Manage Inbound Connectivity” on page 72	X	X		X
Manage Customer Information “Manage Customer Information” on page 72	X	X		X
Authorize User “Authorize User” on page 73		X		
Manage Serviceable Event Notification “Manage Serviceable Event Notification” on page 73 chsacfg lssacfg	X	X		X
Manage Connection Monitoring “Manage Connection Monitoring” on page 74	X	X	X	X
Manage POWER4 Service Agent “Manage POWER4 Service Agent” on page 74	X	X		
Call-Home Setup Wizard “Call-Home Setup Wizard” on page 74		X		X

Table 5. Systems Management tasks and associated commands performed on managed objects and default user roles

HMC Interface Tasks and Associated Commands	User roles/IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
View Properties “Properties” on page 15	X	X	X	X
Update Password “Update Password” on page 15		X		
Change Default Profile “Change Default Profile” on page 35	X	X		
Operations				

Table 5. Systems Management tasks and associated commands performed on managed objects and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles/IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Power On "Power On" on page 16	X	X		X
Power Off "Power Off" on page 16 chsysstate	X	X		X
Activate "Activate" on page 35	X	X		X
Restart "Restart" on page 36	X	X		X
Shut Down "Shut Down" on page 36	X	X		X
LED Status: View System Attention LED "Manage Attention LED" on page 37 lsled	X	X	X	X
LED Status: Identify LED "Manage Attention LED" on page 37 lsled	X	X	X	X
LED Status: Test LED "Manage Attention LED" on page 37 lsled	X	X	X	X
Manage Attention LED "Manage Attention LED" on page 37 chled	X	X	X	X
Schedule Operations "Schedule Operations" on page 37	X	X		
Advanced System Management (ASM) "Advanced System Management" on page 19 asmmenu	X	X		X
Utilization Data: Enable "Utilization Data" on page 20 chlparutil	X	X		X

Table 5. Systems Management tasks and associated commands performed on managed objects and default user roles (continued)

HMC Interface Tasks and Associated Commands	User roles/IDs			
	Operator (hmcoperator)	Super Administrator (hmcsuperadmin)	Viewer (hmcviewer)	Service Representative (hmcservicerep)
Utilization Data: Disable "Utilization Data" on page 20 chlpoutil	X	X		X
Utilization Data: View "Utilization Data" on page 20 lslpoutil	X	X	X	X
Utilization Data: Refresh "Utilization Data" on page 20 lslpoutil	X	X		X
Rebuild "Rebuild" on page 20 chsysstate	X	X		
Change Password "Change Password" on page 20 chsypwd		X		

Configuration				
Create Logical Partition: AIX or Linux "Create Logical Partition" on page 20 mksyscfg	X	X		
Create Logical Partition: VIO Server "Create Logical Partition" on page 20	X	X		
Create Logical Partition: IBM i "Create Logical Partition" on page 20	X	X		
System Plans: Create "System Plans" on page 21		X		
System Plans: Deploy "System Plans" on page 21		X		
System Plans: Import "System Plans" on page 21		X		
System Plans: Export "System Plans" on page 21		X		

System Plans: Remove "System Plans" on page 21		X		
System Plans: View "System Plans" on page 21		X		
Manage Custom Groups "Manage Custom Groups" on page 22	X	X		X
View Workload Management Groups "View Workload Management Groups" on page 22 lshwres lssyscfg	X	X	X	X
Partition Availability Priority "Partition Availability Priority" on page 21 chsyscfg lssyscfg mksyscfg	X	X		
Manage System Profiles "Manage System Profiles" on page 23 chsyscfg chsysstate lssyscfg mksyscfg rmsyscfg	X	X	X	X
Manage Partition Data: Restore "Manage Partition Data" on page 22 rstprofdata	X	X		
Manage Partition Data: Initialize "Manage Partition Data" on page 22	X	X		
Manage Partition Data: Backup "Manage Partition Data" on page 22 bkprofdata	X	X		X
Manage Partition Data: Delete "Manage Partition Data" on page 22 rmprofdata	X	X		

Save Current Configuration "Save Current Configuration" on page 39	X	X		
---	---	---	--	--

Connections				
--------------------	--	--	--	--

Service Processor Status "Viewing HMC connection status" on page 24	X	X	X	X
Reset or Remove Connections "Viewing HMC connection status" on page 24	X	X		
Disconnect Another HMC "Viewing HMC connection status" on page 24		X		
Add Managed System "Viewing HMC connection status" on page 24	X	X		

Hardware (Information)				
-------------------------------	--	--	--	--

Adapters: GX+ "Adapters" on page 28	X	X	X	X
Adapters: Host Channel "Host Channel Adapter (HCA)" on page 29 lshwres	X	X	X	X
Adapters: Host Ethernet "Host Ethernet Adapter (HEA)" on page 29 chhwres lshwres	X	X	X	X
Adapters: Switch Network Interface "Switch Network Interface" on page 40	X	X	X	X
View RIO Topology "View Hardware Topology" on page 30	X	X	X	X
Virtual I/O Adapters "Virtual IO Adapters" on page 29	X	X	X	X

Dynamic Logical Partitioning				
-------------------------------------	--	--	--	--

Processor "Processor" on page 40	X	X		X
Memory "Memory" on page 40	X	X		X

Physical Adapters "Physical Adapters" on page 40	X	X		X
Virtual Adapter "Virtual Adapter" on page 41	X	X		X
Host Ethernet "Host Ethernet" on page 41	X	X		X

Updates				
Change Licensed Internal Code for the current release "Change Licensed Internal Code for the current release" on page 76 lslic updlic		X		X
Upgrade Licensed Internal Code to a new release "Upgrade Licensed Internal Code to a new release" on page 77 lslic updlic		X		X
Flash Side Selection "Flash Side Selection" on page 77 lslic updlic		X		X
Check system readiness "Check system readiness" on page 77 lslic updlic		X		X
View system readiness "View system information" on page 78 lslic updlic		X		X
Console Window				
Open Terminal Window "Open Restricted Shell Terminal" on page 64	X	X		X
Close Terminal Connection	X	X		X
Open Shared 5250 Console "Open 5250 Console" on page 64	X	X		X

Open Dedicated 5250 Console "Open 5250 Console" on page 64	X	X		X
Serviceability				
Manage Serviceable Events "Manage Serviceable Events" on page 69 chsvcevent lssvcevents		X		X
Create Serviceable Event "Create Serviceable Event" on page 68		X		X
Reference Code History "Reference Code History" on page 31 lsrefcode	X	X	X	X
Control Panel Functions: (20) Type, Model, Feature "Control Panel Functions" on page 32 lssyscfg	X	X		
Hardware: Add FRU "Add FRU" on page 32		X		X
Hardware: Add Enclosure "Add Enclosure" on page 32		X		X
Hardware: Exchange FRU "Exchange FRU" on page 32		X		X
Hardware: Exchange Enclosure "Exchange Enclosure" on page 32		X		X
Hardware: Remove FRU "Remove FRU" on page 33		X		X
Hardware: Remove Enclosure "Remove Enclosure" on page 33		X		X
Hardware: Power on/off I/O Unit "Power On/Off IO Unit" on page 33		X		X
Manage Dumps "Manage Dumps" on page 33	X	X		X
Collect VPD "Collect VPD" on page 34	X	X	X	X
Edit MTMS "Edit MTMS" on page 34		X		

FSP Failover: Setup "FSP Failover" on page 34		X		
FSP Failover: Initiate "FSP Failover" on page 34		X		

Capacity on Demand (CoD)				
Enter CoD code "Capacity on Demand" on page 34 chcod lscod		X		
View History Log "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor: View Capacity Settings "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/CUoD: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/On/Off CoD: Manage "Capacity on Demand" on page 34 chcod lscod		X		
Processor/On/Off CoD: View Capacity Settings "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/On/Off CoD: View Billing Information "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/On/Off CoD: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X

Processor/Trial CoD: Stop "Capacity on Demand" on page 34 chcod		X		
Processor/Trial CoD: View Capacity Settings "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/Trial CoD: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/Reserve CoD: Manage "Capacity on Demand" on page 34 chcod		X		
Processor/Reserve CoD: View Capacity Settings "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/Reserve CoD: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X
Processor/Reserve CoD: View Shared Processor Utilization "Capacity on Demand" on page 34 lscod	X		X	X
PowerVM (formerly known as Advanced POWER Virtualization): Enter Activation Code "Capacity on Demand" on page 34 chcod		X		
PowerVM: View History Log "Capacity on Demand" on page 34 lscod	X	X	X	X
PowerVM: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X

Enterprise Enablement: Enter Activation Code "Capacity on Demand" on page 34 chcod		X		
Enterprise Enablement: View History Log "Capacity on Demand" on page 34 lscod	X	X	X	X
Enterprise Enablement: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X
Other Advanced Functions: Enter Activation Code "Capacity on Demand" on page 34 chcod		X		
Other Advanced Functions: View History Log "Capacity on Demand" on page 34 lscod	X	X	X	X
Other Advanced Functions: View Code Information "Capacity on Demand" on page 34 lscod	X	X	X	X

Remote operations

Connect to and use the HMC remotely.

Remote operations use the GUI used by a local HMC operator or the command line interface (CLI) on the HMC. You can perform operations remotely in the following ways:

- Use a remote HMC
- Use a Web browser to connect to a local HMC
- Use an HMC remote command line

The *remote HMC* is an HMC that is on a different subnet from the service processor, therefore the service processor cannot be autodiscovered with IP multicast.

To determine whether to use a remote HMC or Web browser connected to a local HMC, consider the scope of control that you need. A remote HMC defines a specific set of managed objects that are directly controlled by the remote HMC, while a Web browser to a local HMC has control over the same set of managed objects as the local HMC. The communications connectivity and communications speed is an additional consideration; LAN connectivity provides acceptable communications for either a remote HMC or Web browser control.

Using a remote HMC

A remote HMC gives the most complete set of functions because it is a complete HMC; only the process of configuring the managed objects is different from a local HMC.

As a complete HMC, a remote HMC has the same setup and maintenance requirements as a local Hardware Management Console. A remote HMC needs LAN TCP/IP connectivity to each managed object (service processor) that is to be managed; therefore, any customer firewall that may exist between the remote HMC and its managed objects must permit HMC to service processor communications to occur. A remote HMC may also need communication with another HMC for service and support. Table 6 shows the ports a remote HMC uses for communications.

Table 6. Ports used by a Remote HMC for Communications

Port	Use
udp 9900	HMC to HMC discovery
tcp 9920	HMC to HMC commands

A remote HMC needs connectivity to IBM (or another HMC that has connectivity to IBM) for service and support. The connectivity to IBM may be in the form of access to the internet (through a company firewall), or a dialed connection through a customer-provided switched phone connection using the supplied modem (see “Manage Outbound Connectivity” on page 71). A remote HMC cannot use the supplied modem for communication with a local HMC or a service processor.

Performance and the availability of the status information and access to the control functions of the service processor depends on the reliability, availability, and responsiveness of the customer network that interconnects the remote HMC with the managed object. A remote HMC monitors the connection to each service processor and attempts to recover any lost connections and can report those connections that cannot be recovered.

Security for a remote HMC is provided by the HMC user-login procedures in the same way as a local HMC. As with a local HMC, all communication between a remote HMC and each service processor is encrypted. Certificates for secure communications are provided, and can be changed by the user if desired (see “Manage Certificates” on page 59).

TCP/IP access to the remote HMC is controlled through its internally managed firewall and is limited to HMC related functions.

Using a Web browser

If you need occasional monitoring and control of managed objects connected to a single local HMC, use a Web browser. An example of using the Web browser might be an off-hours monitor from home by an operator or system programmer.

Each HMC contains a Web server that can be configured to allow remote access for a specified set of users. If a customer firewall exists between the Web browser and the local HMC, the ports must be accessible, and the firewall should allow incoming requests on these ports. Table 7 shows the ports a Web browser needs for communicating with an HMC.

Table 7. Ports used by a Web browser for communications to the HMC

Port	Use
tcp 443	Secure browser access to Web server communication
tcp 8443	Secure browser access to Web server communication
tcp 9960	Browser applet communication

After an HMC has been configured to allow Web browser access, a Web browser gives an enabled user access to all the configured functions of a local HMC, except those functions that require physical access to the HMC, such as those that use the local diskette or DVD media. The user interface presented to the remote Web browser user is the same as that of the local HMC and is subject to the same constraints as the local HMC.

The Web browser can be connected to the local HMC using a LAN TCP/IP connection and using only encrypted (HTTPS) protocols. Logon security for a Web browser is provided by the HMC user-login procedures. Certificates for secure communications are provided, and can be changed by the user (see “Manage Certificates” on page 59).

Performance and the availability of the status information and access to the control functions of the managed objects depends on the reliability, availability, and responsiveness of the network that interconnects the Web browser with the local HMC. Because there is no direct connection between the Web browser and the individual managed objects, the Web browser does not monitor the connection to each service processor, does not do any recovery, and does not report any lost connections. These functions are handled by the local HMC

The Web browser system does not require connectivity to IBM for service or support. Maintenance of the browser and system level is the responsibility of the customer.

If the URL of the HMC is specified using the format `https://xxx.xxx.xxx.xxx` (where `xxx.xxx.xxx.xxx` is the IP address) and Microsoft Internet Explorer is used as the browser, a hostname mismatch message is displayed. To avoid this message, a Firefox browser is used or a hostname is configured for the HMC, using the **Change Network Settings** task (see “Change Network Settings” on page 52), and this hostname is specified in the URL instead of an IP address. For example, you can use the format `https://hostname.domain_name` or `https://hostname` (for example, using `https://hmc1.ibm.com` or `https://hmc1`).

Using the HMC remote command line

An alternative to performing tasks on the HMC graphical user interface is using the command line interface (CLI).

You can use the command line interface in the following situations:

- When consistent results are required. If you have to administer several managed systems, you can achieve consistent results by using the command line interface. The command sequence can be stored in scripts and run remotely.
- When automated operations are required. After you have developed a consistent way to manage the managed systems, you can automate the operations by invoking the scripts from batch-processing applications, such as the **cron** daemon, from other systems.

From a local HMC, the interface is available by doing the following:

1. Right-click on the HMC desktop (outside of the HMC web user interface screen).
2. Click **Terminals**.
3. Click **rshlogin**.

A restricted shell command line window opens. You can also open the **Open Restricted Shell Terminal** task from the HMC Management work pane.

Setting up secure script execution between SSH clients and the HMC

You must ensure that your script executions between SSH clients and the HMC are secure.

HMCs typically are placed inside the machine room where managed systems are located, so you might not have physical access to the HMC. In this case, you can remotely access it using either the remote client or the remote command line interface.

Note: To enable scripts to run unattended between an SSH client and an HMC, the SSH protocol must already be installed on the client's operating system.

To enable scripts to run unattended between an SSH client and an HMC, do the following:

1. Open the **Remote Command Execution** task from the HMC Management work pane.
2. From the **Remote Command Execution** window, select **Enable remote command execution using the ssh facility**.
3. Create an HMC user with one of the following roles:
 - Super administrator (hmcsuperadmin)
 - Service representative (hmcservicerep)

4. On the client's operating system, run the SSH protocol key generator. To run the SSH protocol key generator, do the following:
 - a. To store the keys, create a directory named \$HOME/.ssh (either RSA or DSA keys can be used).
 - b. To generate public and private keys, run the following command:

```
ssh-keygen -t rsa
```

The following files are created in the \$HOME/.ssh directory:

```
private key: id_rsa
public key: id_rsa.pub
```

The write bits for both group and other are turned off. Ensure that the private key has a permission of 600.

5. On the client's operating system, use ssh and run the **mkauthkeys** command to update the HMC user's authorized_keys2 file on the HMC by using the following command:

```
ssh userid@hostname "mkauthkeys -add '<the key string from $HOME/ .ssh/id_dsa
```

To delete the key from the HMC, you can use the following procedure:

1. On the logical partition, use the **scp** command to copy the authorized_keys2 file from the HMC to the logical partition, as follows:

```
scp userid@host_name :.ssh/authorized_keys2 /tmp/mykeyfile
```

2. In the /tmp/mykeyfile file, remove the line that contains the key and host name of the system that you want to be able to run HMC commands remotely.

3. On a logical partition, use the **scp** command to copy the new file to the HMC:

```
scp /tmp/mykeyfile userid@host_name ".ssh/authorized_keys2"
```

4. If you want to enable password prompting for all hosts that access the HMC through **ssh**, use the **ssh** command to remove the key file from the HMC:

```
scp userid@hostname:.ssh/authorized_keys2 authorized_keys2
```

5. Edit the authorized_keys2 file and remove all lines in this file, then copy it back to the HMC. For example:

```
scp authorized_keys joe@somehost:.ssh/authorized_keys2
```

To delete the key from the HMC, you can also use the command line. For example:

```
ssh userid@hostname "mkauthkeys --remove 'joe@somehost'"
```

Enabling and disabling HMC remote commands

You can enable or disable the remote command line interface access to the HMC by using the SSH facility.

To enable or disable remote commands, you must have a user ID with one of the following roles:

- Super administrator
- Service representative

To enable or disable remote commands, do the following:

1. Open the **Remote Command Execution** task from the HMC Management work pane.
2. From the **Remote Command Execution** window:
 - To enable remote commands, select **Enable remote command execution using the ssh facility**.
 - To disable remote commands, make sure **Enable remote command execution using the ssh facility** is not selected.
3. Click **OK**.

Web browser requirements

Learn about the requirements your Web browser must meet to monitor and control the HMC.

HMC Web browser support requires HTML 2.0, JavaScript1.0, Java Virtual Machine (JVM), and cookie support in browsers that will connect to the HMC. Contact your support personnel to assist you in determining if your browser is configured with a Java Virtual Machine. The Web browser must use the HTTP 1.1 protocol; and if you are using a proxy server, the HTTP 1.1 protocol must be enabled for the proxy connections. Additionally, pop-ups must be enabled for all HMCs addressed in the browser if running with pop-ups disabled. The following browsers have been tested:

Microsoft Internet Explorer 6.0 or later

If the Microsoft Internet Explorer browser is configured to use an internet proxy, then include local intranet addresses in the exception list. Consult your network administrator for more information. If you still need to use the proxy, access the HMC then enable **Use HTTP 1.1 through proxy connections** under the **Advanced** tab in your **Internet Options** window.

Firefox 1.5.0.6 or later

For Firefox 2.0, make sure to enable the JavaScript option to raise or lower windows and move or resize existing windows is enabled.

Preparing to use the Web browser

Perform the necessary steps to prepare to use a Web browser to access the HMC.

Before you can use a Web browser to access an HMC, you must do the following:

- Configure the HMC to allow remote control for specified users.
- For LAN-based connections, know the TCP/IP address of the HMC to be controlled, and have correctly set up any firewall access between the HMC and the Web browser.
- Have a valid user ID and password assigned by the access administrator for HMC Web access.

Logging in to the HMC from a LAN-connected Web browser

Log in to the HMC remotely from a LAN-connected Web browser.

Use the following steps to log in to the HMC from a LAN-connected Web browser:

1. Ensure that your Web browser PC has LAN connectivity to the desired HMC.
2. From your Web browser, enter the URL of the desired HMC, using the format **https://hostname.domain_name** (for example: **https://hmc1.ibm.com**) or **https://xxx.xxx.xxx.xxx**.

If this is the first access of the HMC for the current Web browser session, you can receive a certificate error. This certificate error is displayed if:

- The Web server contained in the HMC is configured to use a self-signed certificate and the browser has not been configured to trust the HMC as an issuer of certificates,
- The HMC is configured to use a certificate signed by a Certificate Authority (CA) and the browser has not been configured to trust this CA.

In either case, if you know that the certificate being displayed to the browser is the one used by the HMC, you can continue and all communications to the HMC will be encrypted.

If you do not want to receive notification of a certificate error for the first access of any browser session, you can configure the browser to trust the HMC or the CA. In general, to configure the browser, use one of the following methods:

- You must indicate that the browser will permanently trust the issuer of the certificate
- By viewing the certificate and installing, to the database of trusted CAs, the certificate of the CA that issued the certificate used by the HMC.

If the certificate is self-signed, the HMC itself is considered the CA that issued the certificate.

3. When prompted, enter the user name and password assigned by your administrator.

Customizable data replication

The Customizable Data Replication service provides the ability to configure a set of Hardware Management Consoles (HMCs) to automatically replicate any changes to certain types of data so that the configured set of HMCs automatically keep this data synchronized without manual intervention.

Note: Before enabling this replication service, you may want to save your original data settings in case you need to restore these settings at a future time. See “Save Upgrade Data” on page 65.

The following types of data can be configured:

- Customer information data
 - Administrator information (customer name, address, telephone number, and so on.)
 - System information (administrator name, address, telephone of your system)
 - Account information (customer number, enterprise number, sales branch office, and so on.)
- Group data
 - All user-defined group definitions
- Modem configuration data
 - Configure modem for remote support
- Outbound connectivity data
 - Configure local modem to RSF
 - Enable an internet connection
 - Configure to an external time source

The Customizable Data Replication service can be enabled for the following types of operations:

- **Peer-to-Peer** (see “Peer-to-Peer replication”).
Provides automatic replication of the selected customized data types between peer HMCs. Changes made on any of these consoles are replicated to the other consoles.
- **Master-to-Slave** (see “Master-to-Slave replication” on page 99).
Provides automatic replication of the selected customized data types from one or more designated master HMCs to one or more designated slave HMCs. Changes made on a master console are automatically replicated to the slave console.

Peer-to-Peer replication

Configure automatic replication of the selected customized data types between peer HMCs.

To configure automatic replication of the selected customized data types between peer HMCs, do the following:

1. Log in the HMC using a user ID that has administrator roles.
2. In the HMC Management work pane, click **Manage Data Replication**.
3. Select **Enable**.
4. Click **New**.
5. Select an HMC to be used as a data source from the list, and click **Add**.

or

In the **TCP/IP Address Information** field, type the TCP/IP address of the Hardware Management Console to be used as a data source, and then click **Find**.

6. In the **Customizable Data Types** list, select the types of data that you want to replicate from a peer HMC currently selected.
7. Choose one of the following actions:
 - Click **Save** to close the Manage Data Replication window.
 - Click **Push to Slaves** to transfer all local levels to any communicating slave. The slaves, if they are running this level of code, are instructed to accept the levels from the master, regardless of the value of their current levels.
 - Click **Sync from Master** to invalidate the local levels for all properties that are defined to have a master. This results in an immediate level set where the master provide their levels to the local machine. This option is not available if the local HMC is not defined to have any data sources.
 - Click **Status** to show the status of this task on this machine.
8. Repeat these steps on each of the HMCs that you want to act as peers with one another. Once communication is established between the HMCs, the requested types of customizable data are automatically replicated from one HMC to the other immediately following the change in the data itself.

Master-to-Slave replication

Master-to-Slave replication provides automatic replication of the selected customized data types from one or more designated master HMCs to one or more designated slave HMCs.

To set up a master console, do the following:

1. Log in the HMC using a user ID that has administrator roles.
2. From the HMC Management work pane, click **Manage Data Replication**.
3. Select **Enable**, then click **Save**.

Note: If you want to configure additional master consoles, see “Peer-to-Peer replication” on page 98

To set up the slave console, do the following:

1. Log in the HMC using a user ID that has administrator roles.
2. Select **Manage Data Replication**.
3. Select **Enable**.
4. Click **New**.
5. Select an HMC to be used as a master data source from the list, then click **Add**.

or

In the **TCP/IP Address Information** field, enter the TCP/IP address of the HMC to be used as the master data source, then click **Find**.

6. Select the types of data that you want to accept from the HMC.

Note: When configuring a HMC as a slave, you should check the types of customizable data from the **Local Customizable Data Change Warnings** list that should generate warnings to a user when manual changes are made to that data on this HMC. Manually updating data on the slave HMC will change the local data level to a higher level than the master. Changes on the master HMC will then not replicate to this HMC until the master data level exceeds that on the slave, or a **Sync from Master** or **Push to Slaves** task is run to resynchronize the data levels on master and slave.

7. Choose one of the following actions:
 - Click **Save** to close the Manage Data Replication window.

- Click **Push to Slaves** to transfer all local levels to any communicating slave. The slaves, if they are running this level of code, are instructed to accept the levels from the master, regardless of the value of their current levels.
 - Click **Sync from Master** to invalidate the local levels for all properties that are defined to have a master. This results in an immediate level set where the masters provide their levels to the local machine. This option is not available if the local Hardware Management Console is not defined to have any data sources.
 - Click **Status** to show the status of this task on this machine.
8. Repeat these steps on any additional HMCs that you want to configure as a slave.
 9. Once communication is established between all of the HMCs, the master consoles remains synchronized with each other, providing redundancy in the event that one of the master consoles becomes unavailable. The slave consoles are kept synchronized with whichever master console provides the data to them first.

Data replication

As data is replicated from one HMC to another, an internal level indicator for the data being replicated is recorded each time the data is altered on the data source. Learn about how to force the replication of data from one or more data sources.

Each HMC keeps track of the level indicator for each type of data and will not accept data from a data source when the level indicator is not greater than that on the receiving HMC.

If you need to force the replication of data from one or more data sources and the level indicator on the receiving HMC is greater than that of the data sources, do the following:

1. Log in the HMC using a user ID that has administrator roles.
2. In the HMC Management work pane, click **Manage Data Replication**.
3. Deselect all the data types from the **Customizable Data Types** list.

Note: If you just want to reset the level indicator for a particular data type, just deselect that data type.

4. Click **Save**.
5. In the HMC Management work pane, click **Manage Data Replication**.
6. Select the types of data from the **Customizable Data Types** list you just deselected.
7. Click **Save**.

Note: Deselecting and then reselecting the data types resets the internal level indicators for the specified types of data and forces replication of the data from the data sources.

Appendix. Notices

This information was developed for products and services offered in the U.S.A.

The manufacturer may not offer the products, services, or features discussed in this document in other countries. Consult the manufacturer's representative for information on the products and services currently available in your area. Any reference to the manufacturer's product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any intellectual property right of the manufacturer may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any product, program, or service.

The manufacturer may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to the manufacturer.

For license inquiries regarding double-byte character set (DBCS) information, contact the Intellectual Property Department in your country or send inquiries, in writing, to the manufacturer.

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: THIS INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. The manufacturer may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to Web sites not owned by the manufacturer are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this product and use of those Web sites is at your own risk.

The manufacturer may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact the manufacturer.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement, IBM License Agreement for Machine Code, or any equivalent agreement between us.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have

been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning products not produced by this manufacturer was obtained from the suppliers of those products, their published announcements or other publicly available sources. This manufacturer has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to products not produced by this manufacturer. Questions on the capabilities of products not produced by this manufacturer should be addressed to the suppliers of those products.

All statements regarding the manufacturer's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

The manufacturer's prices shown are the manufacturer's suggested retail prices, are current and are subject to change without notice. Dealer prices may vary.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to the manufacturer, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. The manufacturer, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs.

Each copy or any portion of these sample programs or any derivative work, must include a copyright notice as follows:

© (your company name) (year). Portions of this code are derived from IBM Corp. Sample Programs. © Copyright IBM Corp. _enter the year or years_. All rights reserved.

If you are viewing this information in softcopy, the photographs and color illustrations may not appear.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the Web at Copyright and trademark information at www.ibm.com/legal/copytrade.shtml.

INFINIBAND, InfiniBand Trade Association, and the INFINIBAND design marks are trademarks and/or service marks of the INFINIBAND Trade Association.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft is a trademark of Microsoft Corporation in the United States, other countries, or both.

Java and all Java-based trademarks and logos are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Red Hat, the Red Hat "Shadow Man" logo, and all Red Hat-based trademarks and logos are trademarks or registered trademarks of Red Hat, Inc., in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Terms and conditions

Permissions for the use of these publications is granted subject to the following terms and conditions.

Personal Use: You may reproduce these publications for your personal, noncommercial use provided that all proprietary notices are preserved. You may not distribute, display or make derivative works of these publications, or any portion thereof, without the express consent of the manufacturer.

Commercial Use: You may reproduce, distribute and display these publications solely within your enterprise provided that all proprietary notices are preserved. You may not make derivative works of these publications, or reproduce, distribute or display these publications or any portion thereof outside your enterprise, without the express consent of the manufacturer.

Except as expressly granted in this permission, no other permissions, licenses or rights are granted, either express or implied, to the publications or any data, software or other intellectual property contained therein.

The manufacturer reserves the right to withdraw the permissions granted herein whenever, in its discretion, the use of the publications is detrimental to its interest or, as determined by the manufacturer, the above instructions are not being properly followed.

You may not download, export or re-export this information except in full compliance with all applicable laws and regulations, including all United States export laws and regulations.

THE MANUFACTURER MAKES NO GUARANTEE ABOUT THE CONTENT OF THESE PUBLICATIONS. THESE PUBLICATIONS ARE PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE.

BULL CEDOC
357 AVENUE PATTON
B.P.20845
49008 ANGERS CEDEX 01
FRANCE

REFERENCE
86 A1 42EV 05