



EVIDEN

BullSequana EXR & AI100R

# Installation Guide



The following copyright notice protects this book under Copyright laws which prohibit such actions as, but not limited to, copying, distributing, modifying, and making derivative works.

Copyright ©Bull SAS 2025, part of Eviden group. Eviden is a registered trademark of Eviden SAS. This document, or any part of it, may not be reproduced, copied, circulated and/or distributed nor quoted without prior written approval from Bull SAS.

## **Trademarks and Acknowledgments**

We acknowledge the right of proprietors of trademarks mentioned in this manual.

All brand names and software and hardware product names are subject to trademark and/or patent protection.

Quoting of brand and product names is for information purposes only and does not represent trademark and/or patent misuse.

### **Hardware**

**January 2025**

**Eviden  
30 bis rue du Nid de Pie  
49000 Angers  
FRANCE**

The information in this document is subject to change without notice. Eviden will not be liable for errors contained herein, or for incidental or consequential damages in connection with the use of this material.



---

# Table of contents

<b>Preface</b>	<b>p-1</b>
Intended readers	p-1
Important user information	p-1
<b>Chapter 1. Checking the delivery contents</b>	<b>1-1</b>
1.1. General recommendations	1-1
1.2. Inspecting packaging	1-2
1.3. Checking the delivery	1-3
1.4. Checking labels	1-4
1.4.1. Identification label	1-4
1.4.2. QR code label	1-6
1.4.3. MAC address labels	1-6
1.4.4. Fan hazard safety label	1-8
1.4.5. Processor label	1-9
<b>Chapter 2. Installing the server</b>	<b>2-1</b>
2.1. Installing the antennas	2-2
2.2. Preparing the rail assemblies	2-9
2.3. Installing the server into the rack cabinet	2-18
<b>Appendix A. Screws, washers and nuts</b>	<b>A-1</b>







---

## Preface

This guide explains how to install the server for the first time.

---

**See** The Bull support web site for the most up-to-date product information, documentation, firmware updates, software fixes and service offers:  
<https://support.bull.com>

---

---

## Intended readers

This guide is intended for use by instructed or skilled personnel in charge of installing the server.

---

## Important user information

Read this document and the other product documents about installation, configuration, operation, and maintenance of the product before installing, configuring, operating or servicing it.

Activities including installation, adjustments, putting into service, use, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If the product is used in a manner not specified by the manufacturer, the protection provided by the product may be impaired.



**DANGER D049**

**The product must not be used in life support system or other applications where failure could threaten injury or life, and any such use voids the limited warranty associated to the product.**







---

## Chapter 1. Checking the delivery contents

---

**Important**    **ATTENTION:** Please read carefully the safety instructions before you perform the procedures described in this manual.  
See the *Multilingual Safety Notices Guide* for translated versions of the safety notices.

---

### 1.1. General recommendations



**WARNING W020**

The server drawer must not be unpacked before it has reached the room temperature (24 hours in the computer room).



## 1.2. Inspecting packaging

Before unpacking, check the indicators on the shockwatch and tiltwatch labels, stuck on the packaging.

If one of the labels is red, make a note on the delivery slip and check packaging contents.

Label	Description
	Shockwatch label
	Transport label
	Tiltwatch label



---

## 1.3. Checking the delivery

According to the configuration, the following items are included.

- Antennas
- Screws and washers
- Kit for installation
- The BullSequana EXR & AI100R server



## 1.4. Checking labels


Safety warning labels, including safety notices and graphic symbols, are present on the server. Check that the electrical installation complies with the label details.

### 1.4.1. Identification label

#### Location

The label is located under the server.

#### Description



Mark	Description
A	Model name
B	Serial number



Mark	Description
C	Electrical characteristics
D	Recycling symbol: it is mandatory to reuse and recycle electronic and electrical equipment properly
E	Electric hazard symbol: Caution! Risk of electric shock
F	Multiple power sources symbol: Caution! The system has more than one power source, which must all be disconnected before servicing to avoid shock hazard
G	Altitude symbol: the system must not be operated at an altitude higher than 2000 meters
H	Tropicalization symbol: the system must be operated within the adequate limits of temperature and humidity
I	Nominal power



#### **CAUTION C044**

**This unit has more than one power supply cord. Disconnect all power supply cords from the unit before servicing. Proceed as follows:**

- 1. Power OFF the system**
- 2. Switch OFF the site power breakers**
- 3. Remove all power supply cords from the system**



#### **WARNING W071**

**This device complies with Part 15 of the FCC Rules.**

**Operation is subject to the following two conditions:**

- (1) this device may not cause harmful interference and**
- (2) this device must accept any interference received including interference that may cause undesired operation.**


#### **Model names**

Model name	Commercial name	Serial number
BSEXRI	BullSequana EXR & AI100R 1U server with 1200W power supply and M.2 internal storage	XAN-ORH-xxxxx
BSEXR2	BullSequana EXR & AI100R 1U server with 1200W power supply and SATA storage	XAN-ORH-xxxxx



### 1.4.2. QR code label

The label is on the cover, at the rear of the server. Scan the QR code to access the [Quick Start Guide](#).



### 1.4.3. MAC address labels

---


<b>Important</b>	<b>It is recommended to write down the MAC address in case the label is lost.</b>
------------------	---

---

#### External label

The label is on the front of the server, behind the front bezel.


The illustration below shows a server with M.2 NVMe disks but the location of the label is the same for a server 2.5 inch SATA disks..





## Internal label


The label is on the motherboard, next to the memory modules.





#### 1.4.4. Fan hazard safety label


The labels are on the fans, inside the server.





**1.4.5. Processor label**

The label is on top of the processor assembly.



Mark	Description
A	Torque value
B	Warning symbol
C	Locking symbols
C	Locking instructions







---

## Chapter 2. Installing the server



### **CAUTION C050**

The device must be installed in a location where the transmitting antenna is at least 20 cm from any people in order to comply with radio frequency exposure regulatory requirements.



### **WARNING W079**

Devices and antennas must not be operated with other antennas or transmitters. Only devices and antennas, tested and approved by the manufacturer, should be used. It is prohibited to change the configuration of devices or antennas. Any changes will violate safety rules.



### **WARNING W080**

Use only antennas which have been provided and approved by the manufacturer. Non-approved antennas may produce excessive radio frequency transmitting power and may exceed FCC/IC limits. Non-approved antenna use is prohibited.



## 2.1. Installing the antennas

### Required tools


- Cross-headed screwdriver
- T10 Torx screwdriver

### Procedure

#### 1. Locate the position of each antenna



Rear view




	Configuration 1 2 antennas	Configuration 2 3 antennas	Configuration 3 3 antennas
A	<ul style="list-style-type: none"><li>▪ Dual-band 2.4-5.9 GHz WIFI</li><li>▪ LoRa</li></ul>	Dual-band 2.4-5.9 GHz WIFI	LTE/5G
B		LTE/5G	<ul style="list-style-type: none"><li>▪ Dual-band 2.4-5.9 GHz WIFI</li><li>▪ LoRa</li></ul>
C	LTE/5G	Dual-band 2.4-5.9 GHz WIFI	LTE/5G




## 2. Remove the top cover

1. Loosen the captive screw to unlock the cover latch.



2. Push the button (A) to release the latch. The upper part (B) rises up.
3. Slide the cover back slightly and lift it up.






### 3. Remove the dummy bracket from each position where an antenna is to be installed

Remove the screws to detach the dummy bracket.



Rear view



### 4. Install each antenna cable



For each antenna, perform the following operations:

1. Remove the connector from the antenna.






2. Remove the nut and the washer from the connector.




3. Insert the connector into the cutout from inside the server.





4. Install the washer and the nut onto the connector.



5. Connect the other end of the cable to the corresponding card.


**5. Connect each antenna cable to the adequate card**




## 6. Install the top cover

1. Position the cover on the server and slide it forward until it is in place.
2. Lower the upper part of the cover latch.

 **Top view**



3. Tighten the captive screw to lock the cover latch.






**7. Turn each antenna to fix it into place**



Rear view



**8. Fold the antennas down for the installation of the server in the rack**

---

**Note** The antennas may be installed after the server has been inserted into the rack, providing there is access to the rear of the server.

---



---

## 2.2. Preparing the rail assemblies

### Required tools

- PH1 cross-headed screwdriver
- PH2 cross-headed screwdriver
- 3 mm flat screwdriver
- Two slide rails
- Two rear brackets
- Two front brackets
- Screws, washers and nuts

---

**See** [Appendix A. Screws, washers and nuts](#)

---




**Procedure**

- 1. Unpack the slide rails**
- 2. Remove the inner rails**

For each slide rail, perform the following operations:

- 1. Pull the inner rail (C) out until it clicks.
- 2. Push the release latch in.




Mark	Description
A	Outer rail
B	Middle rail
C	Inner rail

- 3. Remove the inner rail completely.




### 3. Install the inner rails onto the server

1. Ensure that the inner rail protruding edge is at the front of the server.




2. Tighten the screws.






#### 4. Install a front bracket onto each outer rail

1. Pull the middle rail (A) out until it clicks.
2. Check that the outer rail (B) mount holes underneath are exposed.





3. Attach the front bracket to the outer rail.




Mark	Description
A	Middle rail
B	Outer rail
C	Rear edge



## 5. Install a rear bracket onto each outer rail

1. Place a rear bracket onto the outer rail.




2. Adjust the rear bracket position on the outer rail to match the rack cabinet depth.

According to the rack cabinet depth the number of rear bracket mount holes (A) used varies from three to six.

### 600 mm deep rack cabinet




Rear view






 **Front view**




**900 mm deep rack cabinet**

 **Rear view**








3. Partially tighten the screws to secure the rear brackets into place.
4. Check that the distance between edge of the rear bracket and the edge of the front bracket matches the rack depth.

#### 6. Insert a guide pin into the front and rear brackets of the rail assembly

The rail assembly consists of the middle rail and the outer rail with the front bracket and the rear bracket attached.




Mark	Description
A	Middle rail
B	Front bracket
C	Outer rail
D	Rear bracket



## 7. Push the middle rail back to its original position

1. Lift the middle rail release latch (A) up.
2. Push the middle rail (B) in until it clicks back into place.





## 2.3. Installing the server into the rack cabinet



### CAUTION C045

Two people are required to perform this operation.

### Required tools

T25 Torx screwdriver

---

See [Appendix A. Screws, washers and nuts](#)


---

### Procedure


#### 1. Install the rail assemblies into the rack cabinet

For each rail assemblies, perform the following operations:

1. Move the rail assembly into place.




2. If necessary, adjust the length of the rail assembly by sliding the rear bracket.







3. Position the rail assembly using the guide pins at each end.



4. Secure the rail assembly into place.




5. Tighten the rear bracket nuts.






6. Pull the middle rails out.



## 2. Install the server into the rack cabinet


1. Using the inner rails attached to the server, slide the server into the middle rails.






2. When the rail assemblies click, push the release latch (A) on each side to allow the server to be pushed completely into the rack.

Use handles (B) to push the server.



3. Tighten the captive screws to secure the server into place.



























## Appendix A. Screws, washers and nuts

This appendix lists all the screws, washers and nuts included in the delivery.





### Screws

Mark	Head	Body	Diameter	Length	Description
S1			3 mm	4 mm	M3x4 Flat-headed screw
S2			3.5 mm	12 mm	Flat-head phillips #6-32 screw
S3			3 mm	6.5 mm	M3x6.5 standard screw
S4			5 mm	8.5 mm	M5 button head torx screw
S5			3 mm	6 mm	M3x6 Flat head torx screw
S6			6 mm	10 mm	Pan head screw
S7			4 mm	8 mm	CBLZ head screw M4x8 Black
S8			4 mm	6. mm	CX low head screw M4x6





### Washers

Mark	Head	Body	Diameter	Description
W1			5 mm	M5 Spring Lock Washer OD11



Mark	Head	Body	Diameter	Description
W2			6 mm	M6 Toothed Lock Washer
W3			4 mm	M4 conical spring lock washer

## Nuts

Mark	Head	Body	Diameter	Description
N1			3.5 mm	Hex serrated flange locknut #6-32
N2			6 mm	Hex nut #6







