

# README – OFFLINE procedure for updating Emulex firmwares

## Models :

4 Gb : LP1105-BU ( SFF )  
          LP1105-BC ( CFFv )  
8 Gb : LPE1205-CIOV

## Description :

Off-line procedure ( Blade shutdown )

Blade booting with a PreOS ( Windows PE 2.1) and firmware files and Emulex tool installed from an USB key.

## Procedure ( booting Windows PE and installation of tool and firmware files):

- Mount the ISO file via AMM ( remote console and drive ) and restart the Blade
- Message « Windows loading files »
- Splash screen « Microsoft Corporation »
- Auto start of Windows PE startup in the X: virtual partition ( X:\windows\system32>wpeinit )
- Getting the prompt : X: \windows\system32>
- Mount the USB key and find the drive letter for USB drive

Exemple X: \windows\system32> E:

E:\> dir

- Execute the Emulex setup

E:\> **setupElxAll-x86.exe**

- ELX tools « elxflash » and « winlpcfg » are installed under the following tool main directory  
X:\ Program Files\Emulex\Util\elxapp >

## Quick method for updating ( using « elxflash » tool ):

( firmware and bootcode will be updated in sequence )

Pre-requisite : firmware « .all » and bootcode « .prg » files must be installed under respective subdirectories < boot > and < firmware > under \ Program Files\Emulex\Util\elxapp >

- X:\ Program Files\Emulex\Util\elxapp > **elxflash /auto /update**

Waiting the end of update operation with message “ reset completed – command completed “

- X:\ Program Files\Emulex\Util\elxapp > **exit** ( blade rebooting )
- Unmount the ISO image and the USB key

## Step-by-step method ( using « winlpcfg » tool ):

- Copy the update files ( « .all » firmware , « .prg » bootcode ) under the tool main directory .
- X:\ Program Files\Emulex\Util\elxapp > **winlpcfg listhba**

( identifying the HBA model and firmware level on both adapter/port )

Adapter1 ...Firmware rev .... LP1105-BU/BC or LPE1205-CIOV

Adapter2....Firmware rev.....

- Command for upgrading mandatoty first the firmware and then bootcode ( done on both adapter/port )

X:\ Program Files\Emulex\Util\elxapp >

Exemple for 4Gb HBA ( SFF )

**winlpcfg download a=LP1105-BU i=bf282a3.all** ( firmware )

Exemple for 8Gb HBA

**winlpcfg download a=LPE1205-CIOV i=uu511x3** ( bootcode )

- Waiting the end of update operation with message “ reset completed – command completed “