

Date : 2021 March 24

The firmware packages of the present delivery can be used to update Emulex adapters on:
– **novascale bullion mono-module (use other package for multi-module server)**

Updating Firmware and Boot Code of Emulex adapters on novascale bullion servers.

There is one file per model of Emulex FC adapter:

- FW_LPe1150.ima applies to Emulex LPe1150 adapter
- FW_LPe1250.ima applies to Emulex LPe1250 adapter
- FW_LPe11002.ima applies to Emulex LPe11002 adapter
- FW_LPe12002.ima applies to Emulex LPe12002 adapter

Each .ima file contains :

- the utility to flash the adapter : doslpcfg.exe
- the firmware package : xxxxxxxx.all file
- the Boot Code package : xxxxxxxx.prg file

If the “boot on SAN” function is used , then it is mandatory to update the 'Boot code' as well as the firmware.

To proceed to the update :

Through the Remote Console, mount the appropriate .ima file as a Virtual Media device.

Reboot the bullion server using the corresponding Virtual Drive.

Note : the Virtual Drive linked to the .ima file will appear in the boot list as 'raritan' entry.

Then follows instructions displayed on the screen to update the adapters.