

This package is only for "bullion Extended Memory" servers (Mesca 64 DIMMs).

The change between TS61.02 and TS61.03 is relative to the BIOS. In this situation , the **STEP 1: updating PDBPIC,FPGA ILB and EMM Firmware** can be skipped.

From the "Remote Console", enter in the BIOS interface by pressing [Space bar] when the '*Hit [Space] for Boot Menu*' message is displayed.

Select '*Device Manager*' and press [Enter].

Select the right path through the menus

Example to enable the Kawela:

Advanced >> Boxboro Configuration >> General Configuration >> Kawela (Module 0 IOH1) >> Enable and press [Enter].

Save changes by F10 key, on the modified page

2. Return to the main menu by pressing [Esc] and exit the BIOS interface.

Most important BIOS Settings :

Refer to the document *ConfigurationRules.pdf* to have more details and to optimize the Bios Settings according to the type of server.

Console Serial Redirection

Device Manager >> Advanced >> Miscellaneous Configuration >> Console Serial Redirection

Value = always must be OFF

Max NUMA Nodes per module

Device Manager >> Advanced >> Memory RAS Configuration >> go on the line Numa Nodes per modules >> Select the wanted value >> hit "Enter" to change the value

Default value = 4

- bullion mono-module → Max NUMA Nodes = 4
- bullion bi-modules → Max NUMA Nodes = 4
- bullion quadri-module → Max NUMA Nodes = 2

Kawela Enabling

Device Manager >> Advanced >> Boxboro Configuration >> General Configuration
go on the line Kawela (Module i IOHj) >> 2 possible values PXE Enable/iSCSI Enable (hit "Enter" to toggle the value to "enable")

Default = All the Ethernet Kawela Controllers are disabled except the first one (kawela0 of IOH0 of Module0) which is '*Enable*'

NOTE: on a mono-module server, the kawela 1 can always be enabled.

Note the Boot List order

NOTE 2 : a BIOS update can change the boot list media and order. So, it is necessary to note the values before to update the BIOS, in case of loss of the correct boot order.

1. From the "Remote Console", enter in the BIOS interface by pressing [Space bar] when the '*Hit [Space] for Boot Menu*' message is displayed.
Select '*Boot Manager*'

2. Note the media used to boot, and their order

2) Updating the Technical State

- Unzip the package BIOS / EMM / FPGA to a local directory (A) or to the root of a USB memory stick (B).

STEP 1: updating PDBPIC,FPGA ILB and EMM Firmware

NOTE 1: **each module uses its own Firmware: PDBPIC and EMM.**

These firmware updates have to be done on each module.

Example: On a Quad Modules bullion server configured in two partitions of two drawers each, this will require updating the firmware on each of the four drawers.

NOTE 2: an EMM update doesn't change the settings of the BMC controller.

NOTE 3: the server must be power OFF.

Open a DOS command window and go on the working directory where the files were unzipped.

Run the script "*flashFW.bat*" with the following arguments:

<BMC IP@> <user name> <password> <module number>

Usage:

```
flashFW.bat BMC_IP@ user password module_number
```

Example :

```
flashFW.bat 10.1.1.2 super pass 0
```

Wait for the reboot of the BMC, and then reopen a "*Server Hardware Console*" session.

STEP 2: updating the BIOS

NOTE 1: **there is only one active BIOS per partition**

Updating the BIOS has to be done on the master module of each partition.

Example: On a Quad Modules bullion server configured in two partitions of two drawers each, this will require updating the Bios on each of the two master modules.

NOTE 2: a BIOS update can change the settings of the BIOS. So, it is necessary to note the values before to update the BIOS.

(A) if the BIOS / EMM / FPGA package was unzipped to a local directory:

- Open the Remote Console:

From the Server Hardware Console (SHC).

tab "*System Control*" → menu "*Remote Console / Launch*"

- From the *Remote Console*, mount the directory where the package was unzipped, as a virtual media

- Click on the "*Virtual Media*" icon, select the "*Local Folder*" tab and use the "*Browse*" button to choose your local directory, then connect it as a "*Virtual Drive*" by clicking on the "*Connect*" button.

(B) if the BIOS / EMM package was unzipped on a USB stick:

- Insert this key into a USB port on the novascale bullion server.

next step :

- Power ON the novascale bullion server
- From the "*Remote Console*", enter into the BIOS menu by pressing the space bar when the message "*Hit [Space] for Boot Menu*" is displayed, then from the BIOS menu go to the "*Boot Manager*" item:
The boot list is displayed in the "*Boot Manager*" screen. Move the cursor on the line "*EFI Internal Shell*", and then press "*Enter*".
- The procedure for updating the BIOS will automatically begin.
- At the end of this BIOS update, the server is automatically restarted.

Remove or disconnect the media containing the BIOS, to avoid running another BIOS update.

3) After Updating

Do not load the ESX Hypervisor before restoring the BIOS Settings. Take care to the state of the embedded Ethernet ports, see “Kawela Enabling” chapter, above.

Restoring the BIOS setting:

Depending on the versions, a BIOS update can change the values of the BIOS Settings. According to the type of system and the client configuration, some of these settings have to be restored after this update.

- Access to the BIOS Settings
- restore the values previously noted, before the update.
- Reboot the server.

Restoring the Boot List

In case of Loss of the correct Boot Order, restore the required boot order.

Example for VerbatimSTORE N GO (default):

1. Enter the BIOS interface by pressing [Space] when the Hit [Space] for Boot Menu message is displayed.
2. Select '*Boot Maintenance Manager*' >> '*Boot Options*' and press [Enter].
3. Select '*Change Boot Order*' and press [Enter], move the cursor on the line VerbatimSTORE N GO and push the line to the first place, using 'up' and 'down' key, then hit [Enter].
4. Save changes by selecting 'Commit Changes' and Exit and press [Enter].
5. Return to the main menu by pressing [Esc] and exit the BIOS interface.
6. Reboot the system

In case of Loss of the correct Boot Media (the required media doesn't appear in the list), restore the right Legacy Device for boot.

1. Enter the BIOS interface by pressing [Space] when the Hit [Space] for Boot Menu message is displayed.

2. Select '*Boot Maintenance Manager*' >> '*Boot Options*' and press [Enter].
 3. Set the boot order for each kind of Legacy Device:
 - floppy drives
 - hard-disk drives (includes the internal USB key)
 - CD-ROM drives
 - NET drives
 - BEV drives (network/PXE)
 4. Example for HardDisk Drive :
 - Select '*Set Legacy HardDisk Drive Order*'
 - In the list of Legacy Device, for the Device #0 select the required resource (to be displayed in the Boot list), then hit [Enter].
 5. Apply the changes using 'Commit Changes and Exit'
 6. Return to the main menu by pressing [Esc] and exit the BIOS interface.
 7. Boot the system on the required media from the Boot list.
-